

[Manuals.plus](#) /

› [EverNice](#) /

› EverNice 9033P Bobbins with Storage Box for Pfaff Sewing Machines User Manual

EverNice 9033P

EverNice 9033P Bobbins with Storage Box for Pfaff Sewing Machines User Manual

Model: 9033P

INTRODUCTION

This manual provides instructions for the EverNice 9033P bobbins and their accompanying storage box. These bobbins are designed for compatibility with a wide range of Pfaff sewing machines, ensuring smooth and efficient sewing operations. The transparent design allows for easy monitoring of thread levels.

COMPATIBILITY

The EverNice 9033P bobbins are compatible with numerous Pfaff sewing machine models. Please verify your machine's compatibility before use. Known compatible models include, but are not limited to:

- **Pfaff Creative Series:** 2144, 2170, 7510, 7530, 7550, 7560, 7562, 7570
- **Other Pfaff Models:** 90, 91, 92, 93, 94, 95, 96, 97, 130, 138, 229, 230, 234, 238, 259, 260, 261, 262, 284, 285, 285-1, 294, 295, 295-1, 296, 296-1, 297, 297-1, 331, 332, 333, 335, 360, 362, 368, 437, 438, 439, 463, 480, 801, 803, 806, 807, 809, 875, 876, 900, 904, 905, 906, 907, 916, 917, 919, 919-1, 927, 933, 935, 939, 946, 947, 953, 955, 975, 1000, 1011, 1013, 1014, 1015, 1018, 1019, 1027, 1029, 1035, 1037, 1047, 1050, 1051, 1067, 1069, 1071, 1100, 1147, 1150, 1151, 1171, 1196, 1197, 1911, 1209, 1211, 1212, 1213, 1214, 1216, 1217, 1221, 1222, 1222E, 1222SE, 1229, 1371, 1465, 1467, 1469, 1471, 1472, 1473, 1475, 1475CD, 1520, 1522, 1523, 1524, 1525, 1526, 1527, 1528, 1529, 1530, 1532, 1534, 1536, 1538, 1540, 1542, 1546, 1548, 2010, 2012, 2014, 2020, 2022, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2032, 2034, 2036, 2038, 2040, 2042, 2044, 2046, 2048, 2054, 2056, 2058, 2124, 2134, 2140, 6085, 6086, 6091, 6110, 6112, 6120, 6122, 6150, 6152, 6230, 6232, 6250, 6252, 6270, 9063.

SETUP AND PREPARATION

Before using the bobbins, ensure they are clean and free from any debris. The included storage box helps keep your bobbins organized and protected.

Winding the Bobbin

1. Place an empty EverNice bobbin onto the bobbin winder spindle of your Pfaff sewing machine.
2. Follow your sewing machine's specific instructions for threading the bobbin winder. This typically involves guiding

the thread from the spool pin through a tension disc and then around the bobbin.

3. Engage the bobbin winder and press the foot pedal or start button to begin winding. Ensure the thread winds evenly onto the bobbin.
4. Stop winding when the bobbin is full but not overfilled. Cut the thread.



Figure 1: Two EverNice 9033P bobbins. These transparent bobbins allow for easy visibility of thread levels.

OPERATING INSTRUCTIONS

Inserting the Bobbin into Your Sewing Machine

The method for inserting the bobbin varies depending on your Pfaff sewing machine model (top-loading or front-loading). Refer to your sewing machine's instruction manual for precise steps.

1. **For Top-Loading Bobbins:** Open the bobbin cover plate on the needle plate. Insert the wound bobbin into the bobbin case, ensuring the thread unwinds in the correct direction (usually counter-clockwise). Guide the thread through the tension spring and out the bobbin case opening.

2. **For Front-Loading Bobbins:** Remove the bobbin case from the shuttle hook area. Insert the wound bobbin into the bobbin case, ensuring the thread unwinds in the correct direction. Guide the thread through the tension spring. Reinsert the bobbin case into the machine.

Once the bobbin is correctly inserted and threaded, you can begin sewing according to your sewing machine's operational guidelines.

MAINTENANCE

Cleaning

Periodically inspect bobbins for any lint or thread residue. Clean them with a soft brush or cloth. Avoid using harsh chemicals that could damage the plastic.

Storage

Store bobbins in the provided storage box to keep them organized and protected from dust and damage. This also prevents thread from unwinding unintentionally.

TROUBLESHOOTING COMMON ISSUES

- **Uneven Bobbin Winding:** Ensure the thread is correctly routed through the bobbin winder tension disc. Check for any obstructions in the thread path.
- **Thread Nesting/Tangles:** Verify that the bobbin is inserted correctly and the thread is properly tensioned in the bobbin case. Also, check the upper thread tension.
- **Bobbin Not Fitting:** Confirm that you are using the correct size and type of bobbin for your specific Pfaff machine model. The EverNice 9033P bobbins are designed to match the original Pfaff specifications for compatible models.

SPECIFICATIONS

Brand	EverNice
Model Number	9033P
Material	Plastic
Color	Transparent
Quantity	25 Bobbins with Storage Box
Approximate Diameter	21.78 mm (as shown in measurement image)
Approximate Height	8.76 mm (as shown in measurement image)



Figure 2: Bobbin diameter measurement, approximately 21.78 mm.



Figure 3: Bobbin height measurement, approximately 8.76 mm.

WARRANTY AND SUPPORT

For any questions regarding the EverNice 9033P bobbins or for support, please contact the manufacturer directly through the retailer's platform or their official website. Keep your purchase receipt for any warranty claims.

© 2026 EverNice. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07XNGQMHL>

More documents and user manuals: **<https://manuals.plus/>**