Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CHOUBENBEN A75C2665

CHOUBENBEN Replacement AC Remote Control User Manual

Model: A75C2665

1. Introduction

This manual provides comprehensive instructions for the CHOUBENBEN A75C2665 replacement remote control. This remote is designed to operate various Panasonic air conditioner models, offering a direct replacement for original remote controllers such as A75C2664 and A75C2953, and compatible with units like CS-PC7KKD, CS-PA7GKD, CS-PA16KKD, CS-PA12GKD, and CS-PA9GKD.
Please read this manual carefully before using the remote control to ensure proper operation and to maximize its lifespan.

2. Safety Information

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period.
- Keep the remote control away from direct sunlight, heat sources, and moisture.
- Avoid dropping or subjecting the remote control to strong impacts.

3. Package Contents

- 1 x CHOUBENBEN A75C2665 Replacement AC Remote Control
- *Note: AAA 1.5V batteries are not included and must be purchased separately.*

4. Product Overview

The CHOUBENBEN A75C2665 remote control is an ergonomic, button-controlled device designed for ease of use. It utilizes infrared technology to communicate with your Panasonic air conditioner.



Image 1: Front view of the CHOUBENBEN A75C2665 Replacement AC Remote Control. The remote is black with various control buttons and a display screen at the top.

This remote features a clear display that shows temperature readings exclusively in Celsius. It includes standard functions for controlling your air conditioner, such as power on/off, mode selection, temperature adjustment, fan speed, and timer settings.

5. Setup

5.1. Installing Batteries

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two (2) new AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote control is ready for use. No programming is typically required for this replacement remote, as it is pre-programmed for compatible Panasonic models.

6. Operating Instructions

Point the remote control directly at the infrared receiver on your Panasonic air conditioner unit. Ensure there are no obstructions between the remote and the air conditioner.

6.1. Basic Functions

- **Power On/Off:** Press the **ON/OFF** button to turn the air conditioner on or off.
- **Mode Selection:** Press the **MODE** button repeatedly to cycle through available operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temperature Adjustment:** Use the **TEMP UP (▲)** and **TEMP DOWN (▼)** buttons to increase or decrease the desired temperature. *Note: Temperature display is in Celsius only.*
- **Fan Speed:** Press the **FAN** button to adjust the fan speed (e.g., Low, Medium, High, Auto).
- **Swing Function:** If your air conditioner supports it, press the**SWING** button to activate or deactivate the louver swing function.

6.2. Advanced Functions (if applicable)

Depending on your specific Panasonic air conditioner model, additional buttons on the remote may control functions such as Timer, Sleep Mode, or Quiet Mode. Refer to your air conditioner's original manual for detailed information on these specific functions.

7. Maintenance

7.1. Battery Replacement

When the remote control's display becomes dim or its range decreases, it is time to replace the batteries. Follow the steps in Section 5.1 "Installing Batteries" to replace the old batteries with new AAA 1.5V batteries.

7.2. Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

8. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Make sure you are within the effective operating range (typically 8 meters / 26 feet) and pointing directly at the unit.
- **Air conditioner not responding to specific functions:**
  - Verify that your Panasonic air conditioner model supports the specific function you are trying to use. Some advanced functions may vary between models.

- **Display is dim or blank:**
  - Replace the batteries.

9. Specifications

Brand	CHOUBENBEN
Model Number (Remote)	A75C2665
Compatible Devices	Panasonic Air Conditioners (e.g., A75C2664, A75C2953, CS-PC7KKD, CS-PA7GKD, CS-PA16KKD, CS-PA12GKD, CS-PA9GKD)
Connectivity Technology	Infrared
Controller Type	Button Control
Battery Type	2 x AAA 1.5V (not included)
Display Temperature Unit	Celsius Only
Special Feature	Ergonomic Design

10. Warranty and Support

This product is a replacement remote control and typically comes with a standard manufacturer's warranty against defects in materials and workmanship. For specific warranty details or technical support, please refer to the seller or contact CHOUBENBEN customer service through the retailer where the product was purchased.
Please retain your purchase receipt as proof of purchase for any warranty claims.

© 2023 CHOUBENBEN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XP8M3C2

More documents and user manuals: **https://manuals.plus/**