

[Manuals.plus](#) /

› [TRIXIE](#) /

› TRIXIE Race & Scratch Cat Toy Instruction Manual

TRIXIE 41415

TRIXIE Race & Scratch Cat Toy Instruction Manual

MODEL: 41415 | BRAND: TRIXIE

Introduction

The TRIXIE Race & Scratch Cat Toy is designed to provide interactive entertainment and a dedicated scratching surface for your cat. This circular track features a chase ball and a central corrugated cardboard scratching pad, promoting physical activity and mental stimulation.

Safety Instructions

- Always supervise your pet during play.
- Inspect the toy regularly for damage. Discontinue use if any part becomes loose or broken to prevent injury.
- Keep all packaging materials away from children and pets to avoid choking hazards.
- This product is intended for pet use only.

Package Contents

Ensure all components are present before assembly:

- 1 x TRIXIE Race & Scratch circular track (plastic)
- 1 x Removable corrugated cardboard scratching pad
- 1 x Plastic chase ball (can be opened)

Setup

1. Unpack all components from the packaging.
2. Place the circular track on a flat, stable surface. The toy is equipped with non-slip rubber feet for stability.
3. Insert the corrugated cardboard scratching pad into the central opening of the track. Ensure it sits securely.
4. The plastic ball is pre-installed in the track. If desired, the ball can be unscrewed to fill with catnip or a small rattle (catnip/rattle not included). Securely close the ball before placing it back in the track.



Image: The TRIXIE Race & Scratch toy with the central cardboard scratching pad removed, illustrating how it can be inserted or replaced.



Image: The fully assembled TRIXIE Race & Scratch Cat Toy, ready for use.

Operating Instructions

Place the TRIXIE Race & Scratch Cat Toy in an area accessible to your cat. The toy is designed for independent play:

- **Interactive Play:** Your cat can bat at the plastic ball within the circular track, encouraging chasing and playful interaction.
- **Scratching Surface:** The central corrugated cardboard pad provides an appealing surface for your cat to scratch, helping to maintain claw health and protect furniture.
- **Catnip Enhancement:** If you have filled the ball with catnip, the scent may further entice your cat to engage with the toy.



Image: A cat engaging with the TRIXIE Race & Scratch toy, demonstrating typical play behavior.

Maintenance

- **Cleaning the Plastic Track:** The plastic components can be cleaned by hand washing with mild soap and water. Rinse thoroughly and allow to air dry completely before reassembly.
- **Scratching Pad Replacement:** The central cardboard scratching pad is designed to be replaceable. When the pad becomes worn or heavily scratched, remove it and replace it with a new TRIXIE replacement scratching pad (Item No. 41415-10 or compatible).
- **Ball Maintenance:** If the plastic ball was filled with catnip, empty and clean it as needed. Ensure it is dry before refilling.

Troubleshooting

Issue: Cat is not interested in the toy.

Solution: Try placing the toy in a different location. Introduce fresh catnip into the ball or sprinkle it on the scratching pad. Engage with your cat using the toy initially to demonstrate its function.

Issue: Ball is not rolling smoothly.

Solution: Check the track for any debris or obstructions. Ensure the ball is properly closed if it was opened for catnip. The ball is designed to be batted by the cat, not to roll continuously on its own.

Issue: Scratching pad is quickly worn out.

Solution: This is normal wear and tear for a scratching surface. Replace the scratching pad with a new one (TRIXIE Item No. 41415-10 or compatible) to maintain its effectiveness.

Specifications

Brand	TRIXIE
Model Number	41415
Material	Plastic, Cardboard
Dimensions (L x W x H)	14.57" x 14.57" x 2.76" (37 cm diameter)
Item Weight	1.34 Pounds (0.61 Kilograms)
Color	Pink
Care Instructions	Hand Wash Only (plastic parts)

Warranty and Support

For warranty information or product support, please refer to the retailer where the product was purchased or visit the official TRIXIE website. Keep your proof of purchase for any warranty claims. You can find more information about TRIXIE products at the [TRIXIE Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07XQGMBW4>

More documents and user manuals: <https://manuals.plus/>