

setty gsm043160

setty PowerBank 10000 mAh User Manual

Model: gsm043160

INTRODUCTION

Thank you for choosing the setty PowerBank 10000 mAh. This portable power bank is designed to provide convenient and reliable charging for your mobile devices on the go. Its slim design makes it easy to carry, ensuring your devices stay powered throughout the day. Please read this manual carefully before using the product to ensure safe and optimal performance.

IMPORTANT SAFETY INFORMATION

WARNING: To prevent fire, electric shock, or injury, always follow basic safety precautions when using this product.

- Do not expose the power bank to extreme temperatures (above 45°C or below 0°C).
- Do not expose to direct sunlight, heat sources, or open flames.
- Do not disassemble, modify, or attempt to repair the device. This may result in fire, explosion, or other hazards.
- Do not drop, puncture, or apply strong impact to the power bank.
- Keep away from water, moisture, and corrosive materials.
- Do not use if the power bank is swollen, leaking, or shows any signs of damage.
- Dispose of the product responsibly according to local regulations.
- Keep out of reach of children.

If the power bank exhibits unusual behavior, such as swelling, overheating, or emitting smoke, immediately discontinue use and contact customer support.

PACKAGE CONTENTS

- setty PowerBank 10000 mAh
- Micro USB charging cable
- User Manual (this document)

PRODUCT OVERVIEW



Figure 1: Front view of the setty PowerBank 10000 mAh, showing the setty logo, 10000mAh indicator, and LED battery indicators. Two USB-A output ports and one Micro-USB input port are visible on the top edge.



Figure 2: The setty PowerBank 10000 mAh displayed within its retail packaging, highlighting key features such as dual output, micro USB cable included, fast charging, over discharge protection, and overheating protection.

The setty PowerBank features a compact design with essential ports for charging and recharging. It includes LED indicators to show the remaining battery level.

SETUP: INITIAL CHARGING

Before first use, it is recommended to fully charge your setty PowerBank.

1. Connect the small end of the included Micro USB cable to the Micro USB input port on the power bank.
2. Connect the standard USB end of the cable to a USB wall charger (not included) or a computer's USB port.
3. The LED indicators on the power bank will light up, indicating the charging progress. Each LED typically represents 25% of the battery capacity.
4. Once all LEDs are solid and no longer blinking, the power bank is fully charged. Disconnect the cable.

A full charge may take several hours depending on the power source.

OPERATING THE POWER BANK

Charging Your Devices

1. Connect your device's charging cable (e.g., USB-A to Lightning, USB-A to USB-C, or USB-A to Micro USB) to one of the USB-A output ports on the power bank.
2. Connect the other end of the cable to your mobile device.
3. The power bank should automatically begin charging your device. The LED indicators will show the remaining power level of the power bank.
4. When your device is fully charged, or when you wish to stop charging, disconnect the cable from both the power bank and your device.

The power bank features dual USB output ports, allowing you to charge two devices simultaneously.

Checking Battery Level

To check the remaining battery level of the power bank, briefly press the power button (if present, otherwise it might be automatic). The LED indicators will illuminate to show the current charge:

- **1 LED:** 0-25% remaining
- **2 LEDs:** 25-50% remaining
- **3 LEDs:** 50-75% remaining
- **4 LEDs:** 75-100% remaining

MAINTENANCE

- Clean the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- If not used for extended periods, recharge the power bank at least once every three months to maintain battery health.
- Avoid overcharging or completely discharging the power bank frequently, as this can reduce battery lifespan.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Cable not connected properly; faulty cable; power source issue; power bank fully charged.	Ensure cables are securely connected. Try a different Micro USB cable. Try a different USB wall adapter or computer port. Check LED indicators – if all are solid, it's fully charged.
Device not charging from power bank	Power bank battery empty; faulty cable; device not compatible; power bank in standby.	Recharge the power bank. Try a different charging cable for your device. Ensure your device is compatible with USB charging. Briefly press the power button on the power bank to activate output.
Power bank charges slowly	Low power input source; old/damaged cable.	Use a higher-output USB wall charger (e.g., 5V/2A). Try a different Micro USB cable.
Power bank gets warm during use/charging	Normal operation; excessive load.	It is normal for power banks to get slightly warm. If it becomes excessively hot, disconnect immediately and contact support. Ensure proper ventilation.

SPECIFICATIONS

- **Brand:** setty
- **Model:** gsm043160
- **Capacity:** 10000 mAh
- **Battery Type:** Li-Ion
- **Input:** 1x Micro-USB (Voltage: 5 Volts)
- **Output:** 2x USB-A (Dual Output 2 x 2.1 A)
- **Color:** Black
- **Special Feature:** Slim design

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official setty website. If you encounter any issues not covered in this manual, please contact setty customer service for assistance.

Please retain your proof of purchase for warranty claims.



© 2024 setty. All rights reserved.

Documents - setty – gsm043160

[\[pdf\]](#) Dimension Guide Catalog



Prezentacja programu PowerPoint Agnieszka Żołędziewska Katalog Setty EN scalone 360 telforceone pl katalogi |||

SETTY BASIC POWER BANK 5000 mAh Travel battery with a capacity of 5000 mAh is equipped with two U ... comfort of usage and performance of the battery. The set includes a micro USB cable. Catalog index: **GSM043160 WAY OF USE** The set does not include a charger. SPECIFICATION Capacity: 10000 mAh Batter...

lang:en score:21 filesize: 46.38 M page_count: 60 document date: 2019-07-31