

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Apple](#) /
- › [Apple iPhone 11 Pro Max Clear Case Instruction Manual](#)

Apple MX0H2ZM/A

Apple iPhone 11 Pro Max Clear Case Instruction Manual

1. INTRODUCTION

The Apple iPhone 11 Pro Max Clear Case is engineered to provide protection and maintain the aesthetic of your device. Constructed from a blend of optically clear polycarbonate and flexible TPU materials, this case offers a comfortable feel and robust protection against scratches and drops.

The design features a sturdy back combined with softer, more flexible sides that precisely fit over the iPhone's buttons, enhancing grip and usability. A scratch-resistant coating is applied to both the interior and exterior surfaces, and all materials are optimized to resist yellowing over time, ensuring long-lasting clarity.





Image 1.1: The Apple iPhone 11 Pro Max Clear Case showcasing its transparent design on a silver iPhone.

2. WHAT'S IN THE BOX

- Apple iPhone 11 Pro Max Clear Case

3. SETUP

To install the Apple iPhone 11 Pro Max Clear Case:

1. Ensure your iPhone 11 Pro Max is clean and free of dust or debris.
2. Align the iPhone with the case, starting with the top edge.
3. Gently press the iPhone into the case, ensuring all corners and edges are securely seated. The flexible sides will snap into place around the device.







Image 3.1: Side view of the clear case fitted on an iPhone 11 Pro Max, showing button alignment.

4. OPERATING THE CASE

The clear case is designed for seamless integration with your iPhone 11 Pro Max.

- **Button Access:** The flexible sides of the case are designed to fit directly over the iPhone's volume and side buttons, providing an improved tactile response.
- **Wireless Charging:** The case is fully compatible with Qi-certified wireless chargers. To charge your device wirelessly, simply place your iPhone (with the case on) onto a compatible wireless charging pad.

5. MAINTENANCE

To ensure the longevity and clarity of your Apple iPhone 11 Pro Max Clear Case:

- **Cleaning:** Regularly clean the case with a soft, damp cloth. For stubborn marks, a mild soap solution can be used. Avoid harsh chemicals or abrasive materials, as these can damage the scratch-resistant coating.
- **Preventing Yellowing:** The materials and coatings used are optimized to prevent yellowing over time. Regular cleaning and avoiding prolonged exposure to direct sunlight or extreme temperatures can help maintain its clear appearance.

6. TROUBLESHOOTING

- **Slippery Feel:** Some users may find the case to have a slightly slippery feel. Ensuring your hands are clean and dry can improve grip. The material is designed for a comfortable, smooth touch.
- **Stiff Buttons:** If the buttons feel stiff initially, this is normal. The flexible material will typically soften with continued use, leading to a more responsive button press over time.
- **Dust Accumulation:** If dust or debris accumulates between the case and your iPhone, remove the case and clean both the iPhone and the interior of the case with a soft, lint-free cloth before re-installing.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	62.19 x 30.65 x 3.19 inches
Item Weight	1.45 ounces
Manufacturer	Apple
ASIN	B07XQXZWVT
Item Model Number	MX0H2ZM/A
Brand	Apple

Compatible Phone Models	iPhone 11 Pro Max
Color	Clear
Compatible Devices	iPhone 11 Pro Max
Material	Polycarbonate

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to Apple's official support channels.

You can visit the official Apple Support website for comprehensive assistance and contact options:

support.apple.com

