

Apple iPhone 11 Pro Max Leather Case

Apple iPhone 11 Pro Max Leather Case - Midnight Blue User Manual

Model: MX0G2ZM/A

INTRODUCTION

This manual provides instructions for the proper installation, use, and maintenance of your Apple iPhone 11 Pro Max Leather Case in Midnight Blue. Please read this guide thoroughly to ensure optimal performance and longevity of your product.

PRODUCT OVERVIEW

The Apple iPhone 11 Pro Max Leather Case is designed to protect your device while maintaining a slim profile. It is constructed from European leather and features a microfiber lining.

Key Features:

- Crafted from specially tanned and finished European leather, which develops a natural patina over time.
- Features machined aluminum buttons that complement the case's finish.
- Includes a microfiber lining on the interior to help protect the iPhone's surface.
- Designed to allow wireless charging without removing the case.
- Undergoes extensive testing during design and manufacturing to ensure quality and protection against scratches and drops.






Figure 1: Rear view of the Midnight Blue leather case on an iPhone 11 Pro Max, illustrating the camera module and Apple logo.





Figure 2: Side view of the Midnight Blue leather case on an iPhone 11 Pro Max, illustrating the fit around the screen and the integrated side buttons.

INSTALLATION

Follow these steps to properly install or remove the leather case on your iPhone 11 Pro Max:

1. **To Install:** Hold your iPhone 11 Pro Max with the screen facing up. Align the top edge of the iPhone with the top edge of the case. Gently push the iPhone into the case, ensuring all corners snap securely into place. Verify that the buttons align correctly with the case's button covers.
2. **To Remove:** Hold the iPhone firmly. Starting from one of the bottom corners, gently peel the edge of the case away from the iPhone. Work your way around the edges until the iPhone can be safely lifted out of the case. Avoid excessive force to prevent damage to the case or phone.

USAGE

The leather case is designed for daily use and offers protection while maintaining full functionality of your iPhone 11 Pro Max.

- **Button Functionality:** The machined aluminum button covers are designed to provide tactile feedback and full access to the volume and side buttons.
- **Wireless Charging:** The case is compatible with wireless charging. You do not need to remove the case to charge your iPhone wirelessly.
- **Port Access:** The bottom of the case provides open access to the Lightning port and speakers.
- **Protection:** The case provides protection against scratches and minor drops. While designed for durability, it is not indestructible.

CARE AND MAINTENANCE

To maintain the appearance and integrity of your leather case, follow these care guidelines:

- **Cleaning:** Use a soft, slightly damp, lint-free cloth to clean the exterior of the case. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the leather finish.
- **Leather Patina:** Over time, the European leather will develop a natural patina, which is a characteristic of genuine leather and adds to its unique appearance. Exposure to oils from your skin and direct sunlight can accelerate this process.
- **Avoid Moisture:** Keep the case dry. Exposure to water or excessive moisture can cause discoloration or damage to the leather. If the case gets wet, gently wipe it dry with a soft cloth and allow it to air dry completely.

- **Avoid Extreme Temperatures:** Do not expose the case to extreme heat or cold, as this can affect the leather's texture and durability.

TROUBLESHOOTING

Most issues with a phone case are related to fit or cosmetic concerns. Here are some common points:

- **Case Not Fitting Correctly:** Ensure you have the correct case model for your iPhone 11 Pro Max. Verify that the iPhone is fully seated within the case and all corners are secured.
- **Buttons Not Responding:** Check that the case's button covers are properly aligned with the iPhone's physical buttons. If misaligned, remove and re-install the case.
- **Discoloration or Wear:** Leather is a natural material and will develop a unique patina over time. Minor scuffs and changes in color are normal and part of the leather's aging process. For significant damage, consider replacement.

SPECIFICATIONS

Feature	Detail
Brand	Apple
Compatible Phone Models	iPhone 11 Pro Max
Color	Midnight Blue
Material	Leather
Item Model Number	MX0G2ZM/A
Item Weight	1.65 ounces (approximately 46.77 grams)
Product Dimensions	62.19 x 30.65 x 3.19 inches <i>Note: Product dimensions provided may refer to packaging. The case is designed to precisely fit the iPhone 11 Pro Max.</i>
Manufacturer	Apple
Date First Available	September 11, 2019

WARRANTY AND SUPPORT

This Apple product is covered by Apple's standard limited warranty. For detailed warranty information, please refer to the documentation included with your iPhone or visit the official Apple Support website.

For technical assistance, product inquiries, or to find authorized service providers, please visit support.apple.com or contact Apple Support directly.

