

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Rfiver](#) /

› [Rfiver Mobile TV Cart Rolling TV Stand \(Model: 3-Shelf Mobile TV Stand for 32-70 inch\) User Manual](#)

Rfiver 3-Shelf Mobile TV Stand for 32-70 inch

Rfiver Mobile TV Cart Rolling TV Stand User Manual

Model: 3-Shelf Mobile TV Stand for 32-70 inch

IMPORTANT SAFETY INFORMATION

- Read all instructions thoroughly before assembly and use.
- Do not exceed the maximum weight capacity of 88 lbs (40 kg) for the television or 11 lbs (5 kg) per shelf.
- Ensure all screws and fasteners are tightened securely before placing a television on the stand or using the shelves.
- Move the stand slowly and carefully, especially on uneven surfaces. It is recommended to have two people move the unit when a television is mounted.
- Keep children and pets away from the stand during assembly and movement.
- Do not allow children to climb on the stand or shelves.

PACKAGE CONTENTS

Verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Main Column
- Base with Pre-installed Wheels
- TV Mounting Bracket
- Shelves (3)
- Hardware Kit (various screws, bolts, spacers, Allen wrenches, Phillips head screwdriver)
- Cable Management Ties
- Instruction Manual

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have two people for certain steps, especially when mounting the television.

Step 1: Attach Wheels to the Base

Secure the four 360° rotating wheels to the bottom of the base. Ensure the locking wheels are positioned at the front for easy access and stability.

Product Details



SAFETY LOCK
Prevent TV Dropping



CABLE MANAGEMENT
Say Goodby to Mess



LOCKABLE CASTOR
Flexible & Safe




Image: The base of the TV stand with lockable 360-degree rotating wheels. This image emphasizes the flexibility and safety provided by the wheels.

Step 2: Assemble the Main Column and Attach Shelves

Connect the main vertical column to the base using the provided hardware. Attach the three shelves to the main column at your desired heights. The shelves are designed to hold AV components.



Image: A fully assembled mobile TV stand with a television mounted and three shelves below for media components. This provides a visual reference for the completed product.

Step 3: Attach TV Mounting Bracket

Secure the TV mounting bracket to the main column. This bracket supports VESA patterns up to 400x400mm,

accommodating a wide range of televisions.



Image: A detailed diagram illustrating the TV mounting bracket's swivel capability (30 degrees left/right) and four levels of height adjustment for optimal viewing.

Step 4: Mount the TV

Attach the TV mounting arms to the back of your television using the appropriate screws and spacers from the hardware kit. Carefully lift and hang the TV onto the mounting bracket on the stand. Ensure the safety lock mechanism is engaged to prevent accidental dislodging.

Product Details




Image: Product details diagram showing overall dimensions (height 44.5" to 54.7", base 29.5" x 17.7") and VESA compatibility (100x100mm to 400x400mm). It also indicates the maximum TV weight capacity of 88 lbs.

Step 5: Cable Management

Use the provided cable management ties to organize and conceal cables along the back of the main column. This helps maintain a tidy appearance and prevents tripping hazards.



WOOD
more sturdy & safe



VS



GLASS
fragile

Image: A close-up diagram highlighting the safety lock mechanism to prevent TV dropping, the cable management solution for organizing wires, and the lockable 360-degree castor wheels.

OPERATING INSTRUCTIONS

Adjusting TV Height

The TV plate and hooks support different height levels. To adjust, carefully unmount the TV, reposition the hooks on the mounting arms to the desired height, and re-mount the TV. Ensure the safety lock is re-engaged after adjustment.

Swiveling the TV

The TV mount allows for a 30° swivel to the left or right. Gently push the television to achieve your desired viewing angle.

Moving the TV Stand

To move the stand, unlock the front wheels. Push the stand slowly and carefully to its new location. Once in

position, lock the wheels to secure the stand. For safety, it is recommended to have two people move the stand, especially with a television mounted.

MAINTENANCE

- Regularly check all screws and bolts to ensure they remain tight. Re-tighten as necessary.
- Clean the stand and shelves with a soft, dry cloth. Avoid using abrasive cleaners or harsh chemicals.
- Inspect the wheels periodically for any debris (e.g., hair, dust) that might hinder smooth movement and remove it.

TROUBLESHOOTING

TV is not stable or wobbles

- Ensure all assembly screws, especially those connecting the main column to the base and the mounting bracket, are securely tightened.
- Verify that the TV is properly seated on the mounting bracket and the safety lock is engaged.
- Check that the TV weight does not exceed the maximum capacity of 88 lbs (40 kg).

Wheels do not move smoothly or lock

- Check for any debris (e.g., hair, dust) caught in the wheels and remove it.
- Ensure the locking mechanism is fully disengaged when attempting to move the stand.
- Apply a light lubricant to the wheel axles if movement remains stiff.

Cables are not staying organized

- Re-secure the cable management ties. If the adhesive on the ties has worn out, replace them with new ones or use alternative cable management solutions.

SPECIFICATIONS

Feature	Detail
Brand	Rfiver
Model Number	3-Shelf Mobile TV Stand for 32-70 inch
Compatible TV Sizes	32-70 inches



Maximum TV Weight Capacity	88 lbs (40 kg)
VESA Compatibility	100x100mm, 200x100mm, 200x200mm, 300x200mm, 300x300mm, 400x200mm, 400x400mm
Swivel Angle	±30 Degrees
Height Adjustment	Adjustable TV plate and hooks
Number of Shelves	3
Shelf Weight Capacity	11 lbs (5 kg) per shelf
Product Dimensions (L x W x H)	29.5 x 17.7 x 44.5-58 inches
Item Weight	37 lbs
Material	Heavy-duty steel, wood base




WARRANTY AND SUPPORT

Rfiver products are designed for durability and performance. For specific warranty information or technical support, please refer to the official Rfiver website or contact their customer service department. It is advisable to keep your purchase receipt for any warranty claims.

For further assistance or to explore other products, visit the [Rfiver Store on Amazon](#).

Related Documents - 3-Shelf Mobile TV Stand for 32-70 inch

	<p>RFIVER TF3001U TV Stand Installation Manual</p> <p>Detailed installation guide for the RFIVER TF3001U TV Stand, including parts list, step-by-step assembly instructions, VESA compatibility chart, and safety guidelines. Learn how to safely mount your TV.</p>
	<p>Rfiver Universal Swivel Tabletop TV Stand Assembly Manual</p> <p>Assembly manual for the Rfiver Universal Swivel Tabletop TV Stand, Model UT2001. Provides step-by-step instructions and parts list for safe and proper installation.</p>
	<p>Rfiver TF2002 TV Stand Assembly Instructions and User Guide</p> <p>Comprehensive guide for assembling the Rfiver TF2002 TV stand. Includes parts list, step-by-step instructions, safety warnings, and cable management tips for your floor TV mount.</p>

	<p>RFIVER UT5002 TV Stand Assembly Instructions and User Guide</p> <p>This document provides assembly instructions, parts list, and safety notices for the RFIVER UT5002 TV Stand. Learn how to safely assemble and install your TV stand for optimal viewing.</p>
	<p>BEISHI Mobile TV Stand Installation Guide</p> <p>Comprehensive installation guide for the BEISHI mobile TV stand, featuring step-by-step instructions, accessory lists, and safety tips for assembling and mounting your TV.</p>
	<p>Espirion Optimum Mobile TV Stand Assembly Guide</p> <p>Assembly instructions and parts list for the Espiron Optimum Mobile TV Stand, a height-adjustable, rolling TV cart for 32-75 inch televisions, featuring tilt and swivel capabilities.</p>