

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [eKids](#) /

> [eKids Kids Frozen Headphones FRV126 Instruction Manual](#)

## eKids FRV126

# eKids Kids Frozen Headphones FRV126 Instruction Manual

Model: FRV126

## PRODUCT OVERVIEW

---

The eKids Kids Frozen Headphones (Model FRV126) are designed for young users, featuring a lightweight construction and a volume-reduced output to protect hearing. These headphones offer dual connectivity options: a traditional 3.5mm audio jack and Bluetooth wireless technology, providing flexibility for various devices.



*Figure 1: Front view of the eKids Kids Frozen Headphones, showing the light blue headband, white ear cushions, and attached 3.5mm audio cable. The right earcup features Frozen character artwork.*



*Figure 2: Rear view of the eKids Kids Frozen Headphones, highlighting the adjustable headband and soft white ear cushions.*

## SETUP AND CONNECTION

### Wired Connection (3.5mm Audio Jack)

1. **Identify the Audio Port:** Locate the 3.5mm audio jack on your device (e.g., smartphone, tablet, computer).
2. **Connect Headphones:** Insert the 3.5mm plug from the headphone cable firmly into your device's audio port.
3. **Adjust Volume:** Ensure your device's volume is set to a comfortable listening level. The headphones have a built-in volume reduction feature for safety.

### Bluetooth Wireless Connection

These headphones support Bluetooth 4.0 for wireless audio streaming.

1. **Power On Headphones:** Turn on the headphones. (Specific power button location and indicator light behavior are not detailed in provided data, refer to product packaging if available).
2. **Enable Bluetooth on Device:** Go to the Bluetooth settings on your audio device (e.g., smartphone, tablet).
3. **Pairing Mode:** The headphones should automatically enter pairing mode or have a dedicated pairing button/sequence (refer to product packaging for exact instructions). An indicator light typically flashes to show pairing mode.
4. **Select Headphones:** In your device's Bluetooth list, select "eKids Frozen Headphones" or a similar name to pair.
5. **Confirmation:** Once paired, the headphones will usually indicate a successful connection (e.g., a solid indicator light or an audible prompt).

## OPERATING INSTRUCTIONS

---

### Wearing the Headphones

- Gently place the earcups over your ears, ensuring the soft cushions fully cover them for optimal comfort and sound.
- Adjust the headband to fit comfortably over your head. The headband is designed to be adjustable for various head sizes.

### Volume Control

- The headphones feature a built-in volume reduction system to protect young ears. This means the maximum volume output is limited.
- Adjust the volume using the controls on your connected audio device. Some models may also include touch controls on the headphones themselves (refer to product packaging for specific control locations).

## MAINTENANCE

---

### Cleaning

- Wipe the plastic surfaces of the headphones with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- Do not immerse the headphones in water. While they are water-resistant, they are not waterproof.

### Storage

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- The compact design (1 x 1 x 1 inches) allows for easy storage and portability.
- If using the wired connection, gently coil the retractable cable to prevent tangling and damage.

## TROUBLESHOOTING

---

- **No Sound:**
  - Ensure the headphones are properly connected (either 3.5mm jack or Bluetooth).
  - Check the volume level on your audio device.
  - If using Bluetooth, ensure the headphones are charged and paired correctly.

- Test with another audio device to rule out device-specific issues.
- **Low Sound:**
  - Remember that these headphones feature a built-in volume limiter for hearing protection. The maximum volume will be lower than standard headphones.
  - Ensure your device's volume is at its maximum setting.
  - Check for any volume limits set on the connected audio device itself.
- **Bluetooth Connection Issues:**
  - Ensure the headphones are in pairing mode.
  - Turn off and on Bluetooth on your device, then try pairing again.
  - Move the headphones closer to the audio device to ensure they are within range.
  - Forget the device in your Bluetooth settings and re-pair.

## SPECIFICATIONS

Feature	Detail
Model Number	FRV126
Product Type	Headphones
Connectivity Technology	Bluetooth, 3.5 mm Jack
Bluetooth Version	4.0
Age Range (Description)	Kid
Material	Plastic
Control Type	Volume Control, Touch
Cable Feature	Retractable
Item Weight	5.4 Ounces
Product Dimensions	1 x 1 x 1 inches
Water Resistance Level	Water Resistant
Noise Control Features	Active Noise Cancellation
Included Components	Headphone
Country Of Origin	China

## PRODUCT VIDEO

Your browser does not support the video tag.

*Video 1: An official product video showcasing the eKids Kids Frozen Headphones, highlighting its features, design, and dual connectivity options.*

