

JONATHAN Y JYL9608A

JONATHAN Y JYL9608A Kate 48" 3-Light Glam Crystal Drum LED Ceiling Fan User Manual

Model: JYL9608A | Brand: JONATHAN Y

1. SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- All electrical connections must be in accordance with local codes and ordinances, National Electric Code (NEC), and ANSI/NFPA 70-1999.
- Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Disconnect power at the main circuit breaker before installation or servicing.
- Ensure the installation site allows the fan blades to rotate without obstruction.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

2. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, contact customer service for assistance.



Image: All components of the JONATHAN Y JYL9608A ceiling fan, including blades, motor housing, crystal shade, remote, downrods, and hardware.

- Ceiling Fan Motor Assembly
- Fan Blades (5)
- Blade Arms (5)
- Crystal Drum Light Shade
- LED Bulbs (3)
- Remote Control with Receiver

- Downrods (1x 5-inch, 1x 10-inch)
- Mounting Bracket and Hardware
- Crystal Strings for assembly

3. INSTALLATION

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before beginning. Refer to the official installation video for visual guidance.

Your browser does not support the video tag.

Video: Official installation guide for the JONATHAN Y JYL9608A ceiling fan, demonstrating each step of the assembly and mounting process.

Installation Steps:

1. Prepare the Downrod:

Remove the hanger ball from the downrod by loosening the set screw and removing the cross pin. This allows for easier assembly and selection of downrod length.



Image: A multi-panel image illustrating various installation steps, including removing the hanger ball from the downrod, attaching

blades to the arms, and connecting electrical wires.

2. Attach Downrod to Motor:

Feed the electrical wires from the fan motor through the selected downrod. Secure the downrod to the motor housing using the provided pin and screws. Ensure the downrod is firmly seated.




Image: A diagram illustrating the fan's dimensions, including its 48-inch width and adjustable height (21-26 inches) depending on the chosen 5-inch or 10-inch downrod.

3. Install Mounting Bracket:

Secure the mounting bracket to the ceiling outlet box using appropriate screws (e.g., screw AA). Ensure the bracket is securely fastened to support the fan's weight.

4. Wire Connection:

Connect the fan's electrical wires to the household wiring according to the wiring diagram. Ensure all connections are secure and insulated with wire nuts. Install the remote receiver within the canopy.



Image: A detailed wiring diagram showing connections for the fan motor, remote receiver, and household electrical supply (L, N, Ground wire).

5. Hang the Fan:

Carefully lift the fan assembly and hang it onto the mounting bracket. Ensure the hanger ball is properly seated in the bracket's opening.

6. Attach Fan Blades:

Attach each fan blade to its corresponding blade arm using the provided screws (e.g., screw DD). Then, attach the blade arm assemblies to the motor housing using screws (e.g., screw GG).



Image: A close-up view of the fan's silver blades and the intricate crystal drum light fixture, highlighting the detailed design.

7. Install Light Kit and Crystal Shade:

Connect the light kit wires and install the LED bulbs. Carefully attach the crystal drum light shade to the fan motor housing, securing it with screws (e.g., screw JJ). Finally, assemble and hang the decorative crystal strings onto the shade.



Image: The JONATHAN Y JYL9608A Kate 48-inch 3-Light Glam Crystal Drum LED Ceiling Fan with Remote, showcasing its chrome finish, five silver blades, and crystal light fixture.

Sloped Ceiling Installation:

This fan is compatible with sloped ceilings. Ensure the mounting bracket is installed correctly for angled surfaces, allowing the fan to hang plumb.



Image: The JONATHAN Y ceiling fan mounted on a sloped ceiling, demonstrating its adaptability to various room architectures.

4. OPERATING INSTRUCTIONS

The JONATHAN Y JYL9608A ceiling fan is operated via the included remote control.

Remote Control Functions:

- **Fan Speed:** The remote provides 3 different fan speeds (High, Medium, Low) to adjust airflow.
- **Light Control:** Turn the LED light on or off. The included LED bulbs provide warm, soft-white light.




Image: An illustration highlighting the key features of the JONATHAN Y ceiling fan: 3-speed settings, adjustable height via downrod options, and a reversible motor for seasonal use.

Reversible Motor Function:

The fan features a reversible motor for year-round comfort. A switch on the fan motor housing allows you to change the direction of blade rotation.

- **Summer Mode:** Blades rotate counter-clockwise, pushing cool air down.
- **Winter Mode:** Blades rotate clockwise, pulling cool air up and circulating warm air down.




Image: A visual representation of the fan's reversible motor function, illustrating airflow for summer cooling (downward) and winter heating (upward circulation).

5. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. For the crystal shade, gently wipe with a lint-free cloth.
- **Bulb Replacement:** The fan uses LED bulbs. When replacing, ensure power is off. The bulbs are GU5.3 base.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners on the fan blades and mounting hardware to prevent wobbling or noise.

6. TROUBLESHOOTING

If you experience issues with your fan, consult the following common troubleshooting steps:

- **Fan does not start:** Check that the circuit breaker is on and the wiring connections are secure. Ensure the remote control has fresh batteries and is paired correctly.
- **Light does not work:** Verify that the bulbs are correctly installed and not loose. Check the wiring connections for the light kit.
- **Excessive wobbling:** Ensure all blade screws are tightened. Check that the mounting bracket is securely fastened to the ceiling. Verify that the downrod is properly seated in the hanger ball.
- **Noisy operation:** Confirm all screws are tight. Check for any loose parts or obstructions. Some crystal jingle may occur at high speeds.
- **Missing parts:** If parts are missing upon delivery, contact JONATHAN Y customer service immediately.

7. SPECIFICATIONS

Feature	Specification
Brand	JONATHAN Y
Model Name	Glam Kate 3-Light Fandelier With Remote, Crystal Drum LED
Model Number	JYL9608A
Color	Chrome
Material	Iron, Metal/Crystal
Style	Contemporary
Product Dimensions	48"L x 48"W x 21"H
Item Weight	23.9 Pounds
Power Source	AC
Voltage	120 Volts
Wattage	40 watts
Light Source Type	LED
Number of Light Sources	3
Brightness	420 Lumen
Light Color	Warm White
Bulb Base	GU5.3
Control Method	Remote Control
Special Features	Remote Control, Reversible Motor, Sloped Ceiling Compatible
Certification	ETL, UL

8. WARRANTY AND SUPPORT

JONATHAN Y provides a **30-day manufacturer warranty for defects only**. This warranty does not cover normal wear and tear. Visible damages not noted upon delivery will be determined to be customer damage and will not be warranted. All products are inspected upon arrival and worn, dirty, or stained merchandise is not accepted for warranty claims.

For warranty information or support, please contact JONATHAN Y customer service. You may also refer to the official user guide PDF for additional details: [JONATHAN Y JYL9608A Installation Manual \(PDF\)](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question