

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GreenTech Environmental](#) /
- › [pureWash Pro X2 Detergent-Less Laundry System User Manual](#)

## GreenTech Environmental pureWash Pro X2

# pureWash Pro X2 Detergent-Less Laundry System User Manual

Model: pureWash Pro X2 | Brand: GreenTech Environmental

## 1. INTRODUCTION

---

The GreenTech Environmental pureWash Pro X2 is an innovative laundry system designed to clean clothes using the power of activated oxygen (ozone), significantly reducing or eliminating the need for traditional laundry detergents. This system connects directly to your washing machine's cold water line, transforming tap water into a powerful cleaning agent that leaves clothes cleaner, softer, and fresher.

By utilizing cold water and minimizing detergent use, the pureWash Pro X2 offers an environmentally friendly and cost-effective solution for your laundry needs. It is suitable for all types of washing machines and fabrics, including mixed loads of lights and darks.



Figure 1: The pureWash Pro X2 unit, showcasing its compact design and water inlet/outlet connections.

## 2. KEY FEATURES

- **Oxygen-Powered Cleaning:** Utilizes ozone to inactivate environmental irritants in clothes and fabrics, resulting in cleaner, softer, and fluffier laundry.
- **Cost Savings:** Reduces the need for hot water and significantly minimizes detergent usage (up to 75% less), leading to lower utility and supply expenses.
- **Sensitive Skin Friendly:** Helps reduce residual fabric cleaner and powder in fabrics, which can be beneficial for individuals with sensitive skin.
- **Continuous Freshness:** Clinically tested technology designed to clean laundry effectively without traditional detergents, leaving clothes smelling fresh.
- **Cold Water Operation:** Exclusively uses cold water, saving energy costs associated with heating water for laundry.
- **Universal Compatibility:** Works with both front-load and top-load washing machines using standard USA water hoses.

- **Easy Installation:** Designed for quick and straightforward setup.

**pureWash Pro X2**  
BY GREENTECH

**The pureWash Basics**

- **Spot Treat Stains**
- **Don't Use Detergent**
- **Use Only Cold Water**
- **Change Your Cartridge when Full**
- **Use "Household Water Out"**
- **Enjoy Your Fresh Laundry!**

**Needs Only Cold Water**

**Uses Little to No Detergent**

**Gently Freshens**

**Mix Your Light & Dark Clothes**

**Works with Any Washer**

**Quick & Easy Installation**

EXPERIENCE THE OXIDIZING POWER OF OZONE.

Figure 2: Visual representation of the pureWash Pro X2's core benefits and features.

### 3. SETUP AND INSTALLATION

The pureWash Pro X2 is designed for simple installation. It connects to your existing cold water supply and then to your washing machine.

#### 3.1. Before You Begin

- Ensure you have adequate space above or near your washing machine for mounting the unit.
- Locate your washing machine's cold water inlet and the main cold water supply valve.
- Turn off the main cold water supply to your washing machine before starting installation.

#### 3.2. Installation Steps

1. **Mount the Unit:** Securely mount the pureWash Pro X2 unit on a wall near your washing machine, ensuring it is level and stable. Use appropriate wall anchors and screws for your wall type.

2. **Connect Cold Water Inlet:** Connect the cold water supply hose from your wall outlet to the "COLD WATER IN" inlet on the pureWash Pro X2 unit. Ensure connections are tight to prevent leaks.
3. **Connect to Washing Machine:** Connect a new or existing cold water hose from the "TO WASHING MACHINE" outlet on the pureWash Pro X2 unit to your washing machine's cold water inlet. Ensure connections are secure.
4. **Optional Faucet Connection:** If your model includes an auxiliary faucet, connect it to the designated outlet on the unit. This faucet provides ozonated water for other household uses.
5. **Restore Water Supply:** Slowly turn on the main cold water supply valve to your washing machine. Check all connections for leaks.
6. **Power On:** Plug the pureWash Pro X2 unit into a standard electrical outlet. The unit should power on and be ready for use.



Figure 3: The pureWash Pro X2 unit installed above a washing machine, illustrating typical setup.

## 4. OPERATING INSTRUCTIONS

Using the pureWash Pro X2 is straightforward, as it integrates seamlessly with your existing laundry routine.

## 4.1. Laundry Cycle

1. **Load Laundry:** Place your clothes into the washing machine as usual. The pureWash Pro X2 allows for mixing lights and darks without color bleeding.
2. **Select Cold Water:** Always select a cold water wash cycle on your washing machine. The pureWash Pro X2 is designed to work optimally with cold water, and using hot water is unnecessary and energy-inefficient.
3. **Detergent Usage:** For most loads, you can eliminate laundry detergent entirely. For heavily soiled items or stubborn stains, you may use a minimal amount (e.g., 25% of your usual amount) of a high-efficiency (HE) detergent. Avoid using fabric softeners, as the pureWash Pro X2 naturally softens fabrics.
4. **Start Washer:** Start your washing machine as you normally would. The pureWash Pro X2 will automatically activate when water flows through it, infusing the water with activated oxygen.



Figure 4: The pureWash Pro X2 cleaning process, showing water flow and ozone infusion.

## 4.2. Auxiliary Faucet (If Applicable)

If your pureWash Pro X2 model includes an auxiliary faucet, you can use the ozonated water for various household cleaning tasks, such as cleaning surfaces or soaking non-leafy produce. Ensure to turn off the faucet when not in use.

## 5. MAINTENANCE

---

Regular maintenance ensures the optimal performance and longevity of your pureWash Pro X2 system.

### 5.1. Desiccant Dryer Bead Replacement

- The pureWash Pro X2 contains desiccant dryer beads that absorb moisture to ensure efficient ozone production.
- These beads are typically bright royal blue when new and turn pink as they absorb moisture and become saturated.
- When the beads turn pink, it indicates they need to be replaced. Refer to the indicator window on the unit to monitor their color.
- Replacement desiccant cartridges can be purchased from GreenTech Environmental or authorized retailers. Follow the instructions provided with the replacement cartridge for proper installation.
- The lifespan of the desiccant is typically 6-12 months, but this can vary based on humidity levels and usage.

### 5.2. General Cleaning

- Wipe the exterior of the unit with a soft, damp cloth as needed to keep it clean.
- Do not use harsh chemicals or abrasive cleaners on the unit.

## 6. TROUBLESHOOTING

---

If you encounter issues with your pureWash Pro X2, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No ozone smell or reduced cleaning effectiveness.	Saturated desiccant dryer beads. Unit not powered on. Low water flow.	Check the color of the desiccant beads and replace if pink. Ensure the unit is plugged in and receiving power. Verify adequate water pressure and flow to the unit.
Water leaks from connections.	Loose hose connections. Damaged hoses or internal components.	Ensure all hose connections are tightened securely. Check hoses for any visible damage or cracks and replace if necessary. If leaks persist from within the unit, contact customer support.
Clothes not as clean or fresh as expected.	Overloading washing machine. Incorrect water temperature setting. Saturated desiccant.	Avoid overloading the washing machine to allow proper water circulation. Ensure your washing machine is set to a cold water cycle. Check and replace desiccant beads if needed.

If troubleshooting steps do not resolve the issue, please contact GreenTech Environmental customer support for further assistance.

## 7. SPECIFICATIONS

---

Attribute	Detail
-----------	--------

Attribute	Detail
Model Number	pureWash Pro X2
Manufacturer	GreenTech Environmental
Package Dimensions	20 x 15.05 x 6 inches
Item Weight	10.65 Pounds
ASIN	B07XSFFHLC
First Available Date	September 11, 2019

## 8. WARRANTY AND SUPPORT

---

GreenTech Environmental is committed to customer satisfaction.

### 8.1. Money-Back Policy

The pureWash Pro X2 comes with a 30-day money-back policy. If you are not satisfied with your product within 30 days of purchase, please contact GreenTech Environmental for return instructions.

### 8.2. Customer Support

For technical assistance, warranty claims, or general inquiries, please visit the GreenTech Environmental website or contact their customer service department. Refer to the product packaging or the official GreenTech Environmental website for the most current contact information.

*Note: Specific warranty terms beyond the 30-day money-back policy may apply. Please consult your product documentation or the manufacturer's website for full warranty details.*