

[Manuals.plus](#) /

> [Jura](#) /

> Jura E8 Automatic Espresso Machine User Manual

Jura 7610917152711

Jura E8 Automatic Espresso Machine User Manual

Model: 7610917152711

Brand: Jura

PRODUCT OVERVIEW

The Jura E8 Automatic Espresso Machine is designed to deliver premium coffee experiences with ease and precision. Featuring a Professional Aroma Grinder, Pulse Extraction Process (P.E.P.), and an intuitive 2.8-inch color display, this machine offers 17 programmed specialties for a wide range of coffee beverages. Its harmonious design, with high-quality materials and precise craftsmanship, ensures both aesthetic appeal and durability.



Figure 1: Front view of the Jura E8 Automatic Espresso Machine, showcasing its sleek design and two espresso cups.

SETUP GUIDE

1. Water Tank

The Jura E8 features a removable 1.9-liter water tank located on the side of the machine. To fill, simply lift the tank from its position, fill with fresh, cold water, and reinsert securely. Ensure the tank is properly seated to prevent leaks and ensure proper operation.



Figure 2: Accessing the removable water tank for refilling.

2. Bean Hopper and Ground Coffee Chute

The bean hopper, located on top of the machine, can hold up to 280 grams of whole coffee beans. Lift the aroma preservation lid to add beans. For pre-ground coffee, use the dedicated chute located next to the bean hopper. Only add one serving of pre-ground coffee at a time to this chute.



Figure 3: The bean hopper with whole coffee beans.

3. Milk System Connection

For milk-based specialties, connect the milk hose to the milk frother on the side of the machine. The frother is detachable for easy cleaning. An external milk container (not included with all models) can be used to keep milk chilled and ready for use.

OPERATING INSTRUCTIONS

1. Display and Navigation

The Jura E8 features a 2.8-inch color display and six control buttons for intuitive navigation. The display guides you through various options and prompts for maintenance. Product settings and names can be customized or hidden via the Cockpit menu.

2. Brewing Coffee and Espresso

To brew a drink, select your desired specialty from the display. The machine will automatically grind the beans (if using whole beans) and initiate the Pulse Extraction Process (P.E.P.) for optimal flavor extraction. The coffee spout is adjustable to accommodate various cup sizes, from small espresso cups to travel mugs.



Figure 4: A selection of coffee specialties prepared by the machine.

3. Milk Frothing and Specialty Drinks

The Jura E8 can prepare 17 programmed specialties, including:

- Espresso
- Coffee
- Cappuccino
- Caffè Barista
- Americano
- Espresso doppio
- Macchiato
- Cortado
- Latte macchiato
- Flat white
- Portion of milk foam
- Lungo

The milk frother allows for adjustable foam consistency. Simply turn the dial on the frother to achieve your preferred level of froth for lattes, cappuccinos, and other milk-based beverages.



Figure 5: The Jura E8 preparing a milk-based drink with an external milk container.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Jura E8. The machine features integrated rinsing, cleaning, and descaling programs to simplify upkeep.

1. Cleaning the Drip Tray and Coffee Grounds Container

The drip tray and coffee grounds container are integrated and slide out from the front of the machine for easy emptying and cleaning. It is recommended to empty and rinse these components regularly to maintain hygiene and prevent blockages.

2. Milk System Cleaning

The milk frother and its components should be cleaned daily, especially after preparing milk-based drinks. The detachable design allows for thorough rinsing under running water. Follow the machine's prompts for automated milk system cleaning cycles.

3. Descaling and Filter Replacement

The Jura E8 will prompt you when descaling or filter replacement is necessary. Use only Jura-approved descaling tablets and CLARIS water filters to ensure proper machine function and water quality. These processes are guided by the machine's display.

TROUBLESHOOTING

Should you encounter any issues with your Jura E8, consult the following general advice. For detailed troubleshooting or persistent problems, refer to the comprehensive user manual or contact Jura customer support.

- **No Coffee Dispensed:** Check water tank level, ensure beans are in the hopper, and verify no blockages in the coffee spout.
- **Poor Coffee Quality:** Adjust grind settings (finer for stronger, coarser for weaker), ensure fresh beans, and perform a cleaning cycle.
- **Milk Not Frothing:** Ensure milk system components are clean, milk is cold, and the milk frother dial is set correctly.
- **Error Messages:** Follow the instructions displayed on the machine's screen. Most error messages indicate a specific action required (e.g., "Fill water tank," "Empty grounds").

SPECIFICATIONS

Feature	Detail
Brand	Jura
Model Number	7610917152711
Color	Chrome
Product Dimensions	17"D x 20.2"W x 12.8"H
Special Feature	Programmable
Coffee Maker Type	Espresso Machine
Filter Type	Reusable
Operation Mode	Fully Automatic
Voltage	230 Volts
Item Weight	1 pounds
Date First Available	September 11, 2019

WARRANTY AND SUPPORT

For information regarding your product's warranty, please refer to the warranty card included with your Jura E8 Automatic Espresso Machine. For technical support, service, or to purchase genuine Jura accessories and cleaning

products, please visit the official Jura website or contact their customer service department.

You can find more information and support at the [Jura Store on Amazon](#).