

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Enchen](#) /

> [Enchen Blackstone Electric Shaver User Manual](#)

## Enchen Blackstone

# Enchen Blackstone Electric Shaver User Manual

Model: Blackstone

## INTRODUCTION

---

Thank you for choosing the Enchen Blackstone Electric Shaver. This manual provides essential information for the safe and effective use, maintenance, and care of your new electric shaver. Please read these instructions thoroughly before first use and retain them for future reference.

## IMPORTANT SAFETY INFORMATION

---

To reduce the risk of electric shock, injury, or damage to the appliance, always follow these basic safety precautions:

- Do not immerse the shaver or charging cable in water or other liquids.
- Keep the appliance away from children. This device is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Only use the charging cable provided with the shaver.
- Do not use the shaver if it is damaged, especially the cutter head or power cord.
- Unplug the shaver before cleaning it under running water.
- Avoid using the shaver on irritated or broken skin.
- Store the shaver in a dry place when not in use.

## PRODUCT FEATURES

---

The Enchen Blackstone Electric Shaver is designed for a comfortable and efficient shaving experience, incorporating several advanced features:

- **3D Independent Floating Cutter Heads:** Three sets of independently floating cutter heads adapt to facial contours, increasing shaving area and efficiency.
- **Ultra-thin Double Ring Cutter Net:** The dual-loop design of the knife net blades maximizes contact area with the face for a closer shave.

- **ESM Smart Shaving System:** Maintains constant cutter speed even when the battery is low, preventing hair pulling. Features 5W high power and low noise operation.
- **Split Design for Easy Cleaning:** The cutter head assembly can be easily detached for rinsing under water.
- **Automatic Grinding Blades:** Blades are made from imported Japanese steel and self-sharpen during operation, ensuring long-lasting sharpness.
- **Type-C Fast Charging:** Convenient and quick charging via a Type-C USB interface.
- **Pop-up Trimmer:** Integrated trimmer for styling and maintaining longer beard hair.

# Ultra-thin Double Ring Cutter High Efficient Shaving No Stubble

The cutter net and blades are double-loop design, which greatly increases the contact area between the cutter and the face to improve the shaving efficiency. Ultra-thin cutter improve the high-efficiency shaving



Double  
Ring Cutter



Ultra-thin  
Net



Image: Close-up view of the shaver's ultra-thin double ring cutter heads, highlighting the efficient design for a smooth shave.



The shell is made of ABS and the head cover is molded by PC. Strong and durable.

Pop-up scraper on the back, one button to open, easy to trim longer beard.



Image: Details of the shaver's construction, including the durable ABS shell and the pop-up trimmer for precision grooming.

## SETUP

---

### Initial Charging

Before using your Enchen Blackstone Electric Shaver for the first time, it is recommended to fully charge the device. This typically takes approximately 1 hour.

1. Connect the provided Type-C USB charging cable to the charging port at the bottom of the shaver.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
3. The charging indicator light will flash while charging. Once fully charged, the light will remain steadily on.

# Products Details



It has overcharging and circuit protection. When lack of power or charging, the red breathing light flashes. When the battery is fully charged, the working light is always on.

Type-C USB Charging interface, can be charging from computer and mobile power. It is portable for travel.



Image: Close-up of the shaver's Type-C USB charging interface and the charging indicator light, which flashes during charging and stays on when fully charged.

## OPERATING INSTRUCTIONS

---

### Shaving

The Enchen Blackstone shaver can be used for both wet and dry shaving.

1. **Power On:** Press the power button to turn on the shaver.
2. **Dry Shaving:** For a dry shave, ensure your face is clean and dry. Move the shaver in small, circular motions against the direction of hair growth.
3. **Wet Shaving:** For a wet shave, apply shaving foam or gel to your face. Move the shaver in small, circular motions. Rinse the shaver head under running water during and after shaving to prevent clogging.
4. **Optimal Contact:** The 3D floating heads will adjust to the contours of your face. Apply gentle pressure to maintain optimal contact.
5. **Power Off:** Press the power button again to turn off the shaver.

## Using the Pop-up Trimmer

The integrated pop-up trimmer is ideal for shaping sideburns, mustaches, or trimming longer beard hair before shaving.

1. With the shaver turned on, push the release button on the back of the shaver to activate the pop-up trimmer.
2. Carefully trim hair to the desired length.
3. Push the trimmer back into its housing when finished.

## MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the lifespan of your shaver.

1. **Daily Cleaning:** After each use, turn off the shaver. Pull out the cutter head cover from the main body. Rinse the cutter heads and the inner chamber under running water.
2. **Drying:** Shake off excess water and allow the cutter heads to air dry completely before reattaching the cover. Do not wipe the blades with a towel as this can damage them.
3. **Deep Cleaning (Monthly):** For a more thorough clean, you can carefully remove the individual cutter blades and rinse them. Ensure all parts are completely dry before reassembling.
4. **Lubrication:** Periodically apply a small drop of shaver oil (not included) to the cutter heads to maintain smooth operation.
5. **Storage:** Store the shaver in a clean, dry place away from direct sunlight and extreme temperatures.

## CHARGING

---

Your Enchen Blackstone shaver features convenient Type-C fast charging and an intelligent battery management system.

- A full charge takes approximately 1 hour.
- A fully charged shaver provides up to 2 months of usage (based on typical shaving habits).
- The ESM Smart Shaving System ensures consistent power output even when the battery level is low, preventing performance degradation.
- The charging indicator light will flash during charging and remain solid when charging is complete.

## TROUBLESHOOTING

---

If you encounter issues with your shaver, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 1 hour.
Poor shaving performance / pulling hair.	Cutter heads are dirty or dull.	Clean the cutter heads thoroughly. If performance does not improve, consider replacing the cutter heads.
Shaver not charging.	Charging cable or adapter is faulty; poor connection.	Ensure the Type-C cable is securely connected. Try a different USB adapter or port.
Excessive noise or vibration.	Cutter heads are not properly seated or are damaged.	Check that the cutter head assembly is correctly attached. If noise persists, the cutter heads may be damaged and require replacement.

## SPECIFICATIONS

---

Model Name	Blackstone
Model Number	GADGETS69301101
Dimensions (LxWxH)	16.5 x 5.1 x 5.1 cm
Item Weight	215 g
Power Source	Battery Powered
Battery Life	Up to 2 Months
Charging Type	Type-C Fast Charging
Blade Material	Stainless Steel
Manufacturer	Shenzhen Dynamic8 Technology CO.,LMT.

## WARRANTY AND SUPPORT

---

### Warranty Information

This Enchen product comes with a **1-Year after Sale service** from the date of purchase.

### Customer Support

For any support inquiries, technical assistance, or warranty claims, please contact:

- **Email:** [support@enchen.in](mailto:support@enchen.in)
- **Phone (Importer):** +91 93541 70767 (Eccentric Enterprises Private Limited)