

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Dell](#) /

› [Dell 2208WFPT 22" Widescreen LCD Monitor Instruction Manual](#)

Dell 2208WFPT

Dell 2208WFPT 22" Widescreen LCD Monitor Instruction Manual

Model: 2208WFPT | Brand: Dell

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Dell 2208WFPT 22" Widescreen LCD Monitor. Designed for clarity and performance, this monitor offers a crisp visual experience for various applications.

Key Features:

- **1680 x 1050 Native Resolution:** Experience stunning detail and expanded viewable real estate without compromising desk space.
- **5 Millisecond (Grey-to-Grey) Response Time:** Helps reduce ghosting and motion blur, ideal for dynamic content.
- **1000:1 Dynamic Contrast Ratio:** Produces darker blacks for sharper images, crisp text, and better color saturation.



Figure 1: Front view of the Dell 2208WFPT 22" Widescreen LCD Monitor.

SETUP AND ASSEMBLY

Your Dell 2208WFPT monitor comes in two main parts: the display panel and the stand. Assembly is tool-less and straightforward.

- 1. Attach the Stand:** Align the stand with the mounting slots on the back of the monitor panel. Gently push until it clicks securely into place.
- 2. Position the Monitor:** Place the assembled monitor on a stable, flat surface. Ensure adequate ventilation around the monitor.
- 3. Connect Power:** Plug the power cord into the monitor's power input port, typically located on the underside of the rear ledge, and then into a wall outlet.
- 4. Connect to Computer:** Use an appropriate video cable (HDMI or VGA) to connect the monitor to your computer.

Note: No official seller videos demonstrating setup were available as per embedding criteria.

CONNECTIVITY PORTS

The Dell 2208WFPT monitor provides several ports for connecting to various devices:

- **HDMI Port:** For high-definition digital video and audio connection.
- **VGA Port:** For analog video connection to older systems.
- **Power Input:** Connects the monitor to an electrical outlet.
- **USB Port:** One total USB port for peripheral connectivity.

The monitor also features a cord management system on the back of the stand to help organize cables and maintain a tidy workspace.

OPERATING THE MONITOR

The monitor's controls are located on the bottom edge of the display panel. These buttons allow you to access and adjust the On-Screen Display (OSD) menu.

On-Screen Display (OSD) Menu:

- **Power Button:** Turns the monitor on or off. A small indicator light shows the power status.
- **Menu Navigation Buttons:** Four tactile buttons guide you through the OSD menu. The monitor screen provides on-screen prompts to indicate which button corresponds to which function (e.g., up, down, select, exit).

Common OSD Settings:

- **Brightness and Contrast:** Adjust the overall luminance and contrast levels of the display.
- **Input Source:** Select between HDMI and VGA inputs.
- **Color Settings:** Choose from preset color modes (e.g., Warm, Cool) or customize color profiles to match your preferences or other displays.
- **Display Settings:** Adjust aspect ratio, sharpness, and other visual parameters.
- **Menu Personalization:** Customize the OSD menu's appearance and options.

To access the OSD menu, press the designated menu button (often indicated by an 'X' or menu icon). Use the navigation buttons to browse options and make adjustments.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	2208WFPT-cr
Screen Size	22 Inches
Native Resolution	1680 x 1050
Aspect Ratio	16:9

Response Time	5 ms (grey-to-grey)
Contrast Ratio	1000:1 (dynamic)
Screen Surface	Glossy
Total USB Ports	1
Product Dimensions	22 x 12 x 17 inches
Item Weight	18.01 pounds

TROUBLESHOOTING

If you encounter issues with your monitor, try the following steps:

- **No Power:** Ensure the power cable is securely connected to both the monitor and a working electrical outlet. Check the power indicator light on the monitor.
- **No Signal:** Verify that the video cable (HDMI or VGA) is firmly connected to both the monitor and your computer. Ensure the correct input source is selected in the OSD menu.
- **Image Quality Issues:** Adjust brightness, contrast, and color settings via the OSD menu. Check your computer's display settings for correct resolution output.
- **Flickering/Distorted Image:** Ensure all cables are properly connected. Try a different video cable or port if available.

For further assistance, refer to the Dell support website or contact customer service.

CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your Dell monitor, follow these maintenance guidelines:

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn smudges, lightly dampen the cloth with water or a screen-cleaning solution (avoid harsh chemicals).
- **Cleaning the Casing:** Use a soft, dry cloth to clean the monitor's casing.
- **Ventilation:** Ensure the monitor's ventilation openings are clear and unobstructed to prevent overheating.
- **Storage:** When not in use for extended periods, store the monitor in a cool, dry place, ideally in its original packaging.

WARRANTY AND SUPPORT

This Dell monitor is a renewed product. Renewed products are professionally inspected and tested to work and look like new. If not satisfied with the purchase, renewed products are eligible for replacement or refund under the Amazon Renewed Guarantee.

- **Return Policy:** Eligible for refund/replacement within 90 days of purchase.
- **Manufacturer:** Dell Computers
- **Support:** For technical support or warranty inquiries, please refer to the Amazon Renewed Guarantee details or contact

Dell customer support directly.

© 2024 Dell. All rights reserved. This document is for informational purposes only.