



[Manuals.plus](#) /

› [INTEX](#) /

› INTEX PureSpa Bubble Massage Spa User Manual

INTEX 28428AN

INTEX PureSpa™ Bubble Massage Spa User Manual

Model: 28428AN | Brand: INTEX

INTRODUCTION

This manual provides essential information for the safe and efficient operation, setup, and maintenance of your INTEX PureSpa™ Bubble Massage Spa. Please read this manual thoroughly before installation and use.



Figure 1: INTEX PureSpa™ Bubble Massage Spa and included components.

SAFETY INFORMATION

WARNING: Keep away from naked flame or direct heat sources.

- Always supervise children in and around the spa.
- Do not use electrical appliances near the spa.
- Consult a physician before use if you have health conditions.
- Ensure the spa is placed on a flat, stable surface capable of supporting its weight when filled.

SETUP GUIDE

1. Site Selection

Choose a suitable location for your spa. The area must be flat, level, and free of sharp objects. Ensure adequate drainage is available. The spa dimensions are 216 x 216 x 71 cm and it weighs approximately 46.4 kg when empty, significantly more when filled with water and occupants.

2. Inflation

The PureSpa™ features a FastFill Inflation System for quick and easy setup. Connect the inflation hose from the control unit to the spa's inflation valve. Use the touch button control panel to activate the inflation function.



Figure 2: Connecting the FastFill Inflation System.




Figure 3: FastFill Inflation System operation.

3. Water Filling

Once inflated, fill the spa with water to the recommended level, typically indicated by a fill line inside the spa. Ensure the drain valve is securely closed before filling.

4. Initial Heating

After filling, activate the heater using the control panel. The spa can heat water to a range of 20-40° Celsius. Note that

initial heating may take several hours depending on the ambient temperature and water volume.

OPERATING INSTRUCTIONS

Control Panel

The PureSpa™ features an intuitive touch button control panel. This panel allows you to activate the bubble massage, adjust temperature, and manage filtration.



Figure 4: PureSpa™ Touch Button Control Panel.



Figure 5: Control Panel functionality overview.

Bubble Massage Function

Activate the 140 bubble jets for a therapeutic massage. The Heated Air Bubble Technology ensures the bubbles are

warm, enhancing your spa experience.




Figure 6: High-powered bubble jets for relaxation.

Hard Water Treatment System

The built-in Hard Water Treatment System makes water gentler on skin and helps prevent calcium buildup, which can limit water flow and reduce the spa's lifespan. This system operates automatically to maintain water quality.



Figure 7: Hard Water Treatment System in action.

MAINTENANCE

Water Quality and Filtration

Regular maintenance of water quality is crucial for the longevity of your spa and user health. This includes regular cleaning of the filter cartridge and chemical treatment of the water. Refer to the control panel for filter cleaning indicators.



Figure 8: Spa filter cartridge (S1 type).

Spa Cover

Always use the included insulated spa cover when the spa is not in use. This Energy-Efficient Spa Cover helps maintain water temperature, reduces energy consumption, and keeps debris out of the spa.



Figure 9: PureSpa™ with insulated cover.



Figure 10: Energy-Efficient Spa Cover heat retention.

Cleaning and Storage

For long-term storage, ensure the spa is thoroughly cleaned and completely dry before deflating and packing away. This prevents mold and mildew growth and extends the product's life.

TROUBLESHOOTING

- **Slow Heating:** Ensure the spa cover is on when heating. Check ambient temperature; colder conditions will increase heating time. Verify filter is clean.
- **Bubbles Not Working:** Check power connection. Ensure the bubble function is activated on the control panel.
- **Water Quality Issues:** Regularly test water chemistry and adjust as needed. Clean or replace filter cartridges frequently. The Hard Water Treatment System helps, but additional chemical treatment may be necessary.
- **Display Not Working:** Ensure power supply is stable. If the display remains unresponsive, contact customer support.
- **Air Leakage:** Check all valves and caps are securely tightened. Inspect the spa body for any punctures.

SPECIFICATIONS

Feature	Detail
Model Number	28428AN
Capacity	6 Person
Dimensions (L x W x H)	216 x 216 x 71 cm
Item Weight (empty)	46.4 kg
Bubble Jets	140
Water Temperature Range	20-40° Celcius
Material	PVC 35%, PP 10%, PET 9%, STEEL 46%
Voltage	2.2E+2 Volts (AC)
Construction	Fiber-Tech Beam Construction, Durable Exterior (3-ply laminated material)
Special Features	Hard Water Treatment System, FastFill Inflation System, Insulated Spa Cover




Figure 11: Side view of the PureSpa™.



FastFill Inflation System

Just simply inflate and deflate at a touch of a button, no external hose needed.

Figure 12: Fiber-Tech Beam Construction for durability.



Durable Exterior

Outside, Super Tough™ delivers puncture resistance in a 3-ply, laminated material.

Figure 13: Durable Exterior material layers.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official INTEX website. You can also visit the [INTEX Store on Amazon](#) for additional resources.