Intex 64418NP

Intex Comfort Plush High Rise Electric Airbed - 2 Person (Model 64418NP)

Instruction Manual

1. Important Safety Information

Please read and understand all instructions before using this product. Failure to follow these warnings and instructions could result in injury or product damage.

- Keep out of reach of children.
- Do not use if the product appears damaged.
- Do not leave the airbed plugged in unattended.
- Keep away from heat sources and open flames.
- Ensure the internal pump switch is in the OFF/Stop position once the airbed is fully inflated to prevent air leakage.
- The airbed is designed for indoor use.

2. Package Contents

Verify that all components are present:

- Intex Comfort Plush High Rise Airbed (Model 64418NP)
- Integrated Electric Pump
- Storage/Carry Bag
- Instruction Manual

3. Product Overview & Features

The Intex Comfort Plush High Rise Airbed is designed for comfort and convenience, featuring durable Fiber-Tech construction and an integrated electric pump for quick inflation and deflation.

The Intex Dura-Beam Deluxe airbed, showcasing its elevated design.

- **Integrated Electric Pump:** For rapid inflation and deflation.
- **Fiber-Tech Construction:** Provides enhanced stability, durability, and comfort.
- **Comfortable Height:** 56 cm (22 inches) mattress height for ease of getting in and out.
- **Soft Top Surface:** Offers a comfortable sleeping experience.
- **Carry Bag:** Included for easy storage and transport.

Cutaway view demonstrating the internal Fiber-Tech construction for enhanced stability and durability.

4. Setup Instructions (Inflation)

Follow these steps to inflate your airbed:

1. Unroll the airbed on a clean, level surface free of sharp objects.
2. Locate the integrated electric pump on the side of the airbed.
3. Plug the pump's power cord into a standard electrical outlet.
4. Turn the pump switch to the 'Inflate' position. The airbed will begin to inflate.
5. Inflation typically takes approximately 5 minutes. Inflate to your desired firmness.
6. Once inflated, turn the pump switch to the 'OFF/Stop' position and unplug the power cord.

Note: *New vinyl may stretch during initial use. It is normal for the airbed to feel softer after the first few uses. You may need to add air to maintain desired firmness during the first few days.*

Close-up view of the integrated electric pump for inflation and deflation.

Diagram illustrating the airbed's dimensions (203x152x56 cm) and approximate inflation time of 4.45 minutes.

5. Operating Instructions (Deflation)

To deflate and store your airbed:

1. Ensure the airbed is unplugged from the power outlet.
2. Plug the pump's power cord back into a standard electrical outlet.
3. Turn the pump switch to the 'Deflate' position. The pump will begin to extract air from the airbed.
4. Allow the pump to run until most of the air has been removed and the airbed is flat.
5. Once deflated, turn the pump switch to the 'OFF/Stop' position and unplug the power cord.
6. Fold or roll the airbed neatly and place it into the included carry bag for storage.

A person carrying the Intex airbed in its included storage bag.

6. Care and Maintenance

- **Cleaning:** Spot clean the airbed with a mild detergent and damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the deflated airbed in its carry bag in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Puncture Prevention:** Avoid placing the airbed on rough or uneven surfaces. Keep pets away from the airbed to prevent punctures.
- **Repairs:** In case of a small puncture, use a vinyl repair kit (not included) to patch the hole.

7. Troubleshooting

Problem	Possible Cause	Solution
Airbed loses air / becomes soft	• New vinyl stretching (normal for first uses) • Pump switch not in OFF position • Small puncture or leak • Temperature changes	• Add more air to desired firmness. This is normal during the first few days. • Ensure pump switch is fully in the OFF/Stop position. • Inspect for punctures. Use a repair kit if found. • Airbeds can lose pressure in cooler temperatures; add air as needed.
Pump not working	• Not plugged in • Power outage • Pump malfunction	• Ensure power cord is securely plugged into a working outlet. • Check household circuit breaker. • Contact customer support if pump does not operate.

8. Specifications

Feature	Detail
Model Number	64418NP
Dimensions (L x W x H)	203 cm x 152 cm x 56 cm (80 in x 60 in x 22 in)
Weight Capacity	272 kg (600 lbs)
Number of Persons	2
Inflation Time	Approx. 5 minutes
Material	PVC, ABS, CU, RAYON, POLYESTER
Color	Grey
Integrated Pump	Yes
Firmness Description	Plush
Water Resistance Level	Water-repellent

Intex Comfort Plush High Rise Airbed in a bedroom setting.

9. Warranty Information

This Intex Comfort Plush High Rise Electric Airbed comes with a**2-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, punctures, or normal wear and tear.

10. Support

For further assistance, troubleshooting, or to inquire about warranty service, please contact Intex customer support. Refer to the contact information provided on the product packaging or the official Intex website.

© 2024 Intex. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question