

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PlayStation](#) /

› [PlayStation VR Mega Pack \(PS4\) Instruction Manual](#)

PlayStation 9999201

PlayStation VR Mega Pack (PS4) Instruction Manual

Model: 9999201

1. PRODUCT OVERVIEW

The PlayStation VR Mega Pack for PS4 provides an immersive virtual reality experience. This system allows users to engage with a wide selection of virtual reality games and applications, leveraging advanced technology for high-quality visuals, 3D audio, and intuitive controls.

This Mega Pack includes the essential components for getting started:

- PlayStation VR Headset
- PlayStation Camera
- Download codes for five virtual reality games: *VR Worlds*, *ASTRO Bot Rescue Mission*, *Skyrim VR*, *Everybody's Golf VR*, and *Resident Evil 7*.



Figure 1: The PlayStation VR Mega Pack retail box, displaying the VR headset, PlayStation Camera, and included game titles.

2. SETUP INSTRUCTIONS

Follow these steps to correctly set up your PlayStation VR system with your PlayStation 4 console.



Figure 2: Key components of the PlayStation VR system: the VR headset, PlayStation Camera, and Processor Unit.

- 1. Connect the Processor Unit:** Connect the HDMI cable from your PlayStation 4 to the "HDMI PS4" port on the Processor Unit. Then, connect another HDMI cable from the "HDMI TV" port on the Processor Unit to your television's HDMI input.
- 2. Connect the PlayStation Camera:** Plug the PlayStation Camera cable into the AUX port on the back of your PlayStation 4 console. Position the camera in a stable location, typically above or below your TV, ensuring it has a clear view of your play area.
- 3. Connect the VR Headset:** Connect the VR headset cable to the front ports of the Processor Unit. Ensure both cables are securely connected.
- 4. Power the Processor Unit:** Connect the AC adapter to the Processor Unit and then plug it into a power outlet.
- 5. Power On:** Turn on your PlayStation 4 console, then press the power button on the VR headset cable to activate the headset.

Video 1: An official PlayStation VR Mega Pack overview, demonstrating the components and basic setup process. This video provides a visual guide to connecting the headset, camera, and processor unit to your PlayStation 4 and TV.

3. OPERATING THE PLAYSTATION VR

3.1 Wearing and Adjusting the Headset

- 1. Put on the Headset:** Place the headset on your head, ensuring the front display rests comfortably over your eyes.
- 2. Adjust the Headband:** Use the adjustment button on the back of the headband to loosen or tighten it for a snug fit.

The headband should support the headset's weight evenly.

- Adjust the Display:** Press the release button on the bottom right of the headset to slide the display closer to or further from your face until the image is clear and comfortable.
- Focus Adjustment:** If the image is still blurry, use the IPD (Inter-Pupillary Distance) adjustment in the PlayStation 4 settings menu to fine-tune the lens spacing for your eyes.

3.2 Basic Controls and Features

- Power Button:** Located on the inline cable remote, press to turn the headset on or off.
- Volume Buttons:** Adjust audio levels using the volume up/down buttons on the inline remote.
- Microphone Mute:** Mute or unmute the microphone using the dedicated button on the inline remote.
- 3D Audio:** The PlayStation VR system provides immersive 3D audio through connected headphones, enhancing spatial awareness in virtual environments.

4. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your PlayStation VR system.

- Cleaning Lenses:** Use a dry, soft microfiber cloth specifically designed for optical lenses. Do not use water, cleaning solutions, or abrasive materials, as these can damage the lenses.
- Cleaning Headset Exterior:** Wipe the exterior surfaces of the headset and Processor Unit with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying.
- Cleaning Face Cushion:** The removable face cushion can be gently wiped with a damp cloth and mild soap, then air-dried completely before reattaching.
- Storage:** Store the headset in a cool, dry place away from direct sunlight. Avoid placing heavy objects on the headset or cables.
- Cable Management:** Handle cables carefully to prevent kinks or damage. Avoid excessive bending or pulling.

5. TROUBLESHOOTING COMMON ISSUES

Issue	Possible Cause	Solution
Blurry or Unclear Image	Incorrect headset adjustment, dirty lenses, or incorrect IPD setting.	Adjust the headset position and display distance. Clean the lenses with a microfiber cloth. Adjust IPD in PS4 settings.
No Image on TV or Headset	Loose cable connections, Processor Unit not powered, or incorrect HDMI input selected on TV.	Check all HDMI and power connections. Ensure the Processor Unit is powered on. Select the correct HDMI input on your TV.
Tracking Issues (Headset or Controllers)	PlayStation Camera obstruction, poor lighting, or reflective surfaces in the play area.	Ensure the PlayStation Camera has a clear view. Optimize lighting conditions (avoid direct sunlight or very dim rooms). Remove reflective objects from the play area.
Audio Problems	Headphones not connected, volume too low, or mute activated.	Ensure headphones are properly connected to the headset's inline remote. Adjust volume using the remote. Check if the microphone is muted.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	9999201
ASIN	B07XYCQX58
Manufacturer	Sony
Release Date	October 4, 2019
Product Dimensions	8.23 x 13.58 x 10.24 inches
Item Weight	1.65 pounds
Batteries Required	1 Lithium Ion battery (typically for PlayStation Move controllers, which are sold separately and not included in this Mega Pack)

7. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the documentation included with your product or visit the official PlayStation support website. Warranty terms and conditions may vary by region.

For technical support, frequently asked questions, and additional resources, please visit the official PlayStation Support website: www.playstation.com/support



© 2024 PlayStation. All rights reserved.

Related Documents - 9999201

 <small>Gold wireless headset Instruction Manual</small> <small>CUHYA-0080</small>	<p>Sony PlayStation Gold Wireless Headset CUHYA-0080 Instruction Manual</p> <p>This instruction manual provides comprehensive guidance for the Sony PlayStation Gold Wireless Headset, model CUHYA-0080. It details important safety precautions, usage instructions, battery management, and product specifications to ensure an optimal audio experience for PlayStation gaming and other audio needs. Discover how to set up and use your headset effectively, understand its features like Virtual Surround Sound, and learn about its compatibility with PlayStation consoles, PCs, and other portable devices. For additional support, troubleshooting, and detailed information, please visit the official PlayStation support portal at playstation.com/support.</p>
	<p>PlayStation VR CUH-ZVR2 User Manual</p> <p>Comprehensive guide for setting up and using the PlayStation VR CUH-ZVR2 system with PS4 and PS5 consoles. Includes safety warnings, operating instructions, troubleshooting tips, and specifications.</p>

	<p><u>PlayStation VR Headset Lenses Replacement Guide</u></p> <p>A step-by-step guide on how to replace the lenses in a Sony PlayStation VR headset, detailing the necessary tools and procedures for disassembly and reassembly.</p>
	<p><u>PlayStation Wireless Stereo Headset CUHYA-0080 Instruction Manual</u></p> <p>Official instruction manual for the PlayStation Wireless Stereo Headset (CUHYA-0080), covering setup, features, safety precautions, and specifications for PS4, PC, and mobile devices.</p>
	<p><u>PlayStation VR CUH-ZVR2 Quick Start Guide</u></p> <p>A comprehensive quick start guide for setting up and using the PlayStation VR headset, including connections, power-up, and play area guidelines.</p>
	<p><u>Controlling Your PlayStation 4 System with Voice Recognition</u></p> <p>A guide on how to use voice commands to control your PlayStation 4 (PS4) system, enabling features like taking screenshots and navigating menus using voice input.</p>