Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ThunderX3 YAMA1

ThunderX3 YAMA1 Ergonomic Gaming Chair Instruction Manual

Model: YAMA1

Introduction

This manual provides essential information for the safe and efficient use of your ThunderX3 YAMA1 Ergonomic Gaming Chair. Please read these instructions carefully before assembly and use, and retain them for future reference.



Image: The ThunderX3 YAMA1 gaming chair in a typical office or gaming setup, showcasing its design and presence.

Safety Warnings

- **Weight Limit:** Do not exceed the maximum weight limit of 350 lbs (approximately 158 kg). Exceeding this limit may cause damage to the chair and potential injury.
- **Adjustments:** Exercise caution when adjusting the headrest, armrests, lumbar support, and backrest to prevent pinching or injury. Ensure no body parts are in the path of moving components.
- **Assembly:** Ensure all components are securely fastened according to the assembly instructions before use. Periodically check all screws and bolts for tightness.
- **Stability:** Do not stand on the chair. Avoid leaning excessively to one side or rocking vigorously, as this may cause the chair to tip over.
- **Children:** Keep children away from the chair during assembly. Do not allow children to play on or with the chair unsupervised.

Setup and Assembly

The ThunderX3 YAMA1 gaming chair requires assembly. Please follow the detailed assembly instructions provided in the packaging. All necessary tools, typically an Allen key, are usually included.

General Assembly Steps (Refer to packaged manual for specifics):

1. Unpack all components and verify against the parts list in your manual.
2. Attach the casters to the chair base.
3. Insert the gas lift cylinder into the center of the chair base.
4. Assemble the seat and backrest components, attaching armrests and adjustment mechanisms as instructed.
5. Place the assembled seat onto the gas lift cylinder.
6. Attach the headrest and lumbar support.
7. Ensure all screws are tightened securely before first use.



Image: The ThunderX3 YAMA1 gaming chair, showcasing its overall design and components after assembly.

Operating Instructions

Your ThunderX3 YAMA1 chair offers several adjustable features to optimize your comfort and ergonomic support.

- **Seat Height Adjustment:** Use the lever located under the right side of the seat to adjust the chair's height. Pull the lever up to raise the seat; sit on the chair and pull the lever up to lower it. Release the lever to lock the height.
- **Backrest Recline (90-135 degrees):** A lever on the left side of the seat controls the backrest recline. Pull the lever up to recline the backrest to your desired angle (between 90 and 135 degrees). Release the lever to lock the

position.

- **Armrest Adjustment:** The armrests are 1-way adjustable. Typically, a button or lever on the side of the armrest allows you to adjust their height. Press the button/lever and move the armrest up or down. Release to lock.
- **Headrest Adjustment:** The headrest is 2-way adjustable, allowing for height and tilt adjustments. Gently push or pull the headrest to find your preferred position.
- **Lumbar Support Adjustment:** The chair features adjustable lumbar support. This can usually be adjusted by rotating knobs or sliding a mechanism on the backrest to provide optimal lower back support.
- **Seat Depth Adjustment:** The seat can be adjusted forward and backward. Look for a lever or button under the seat that allows you to slide the seat pan to your preferred depth.





Image: Side view of the ThunderX3 YAMA1 chair, highlighting the various adjustable components such as the armrests, backrest, and seat.

Maintenance

Proper maintenance ensures the longevity and performance of your ThunderX3 YAMA1 gaming chair.

- **Cleaning:** The chair's upholstery and mesh back are recommended for dry cleaning. For general cleaning, wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically inspect all bolts, screws, and moving parts to ensure they are secure and functioning correctly. Tighten any loose fasteners.
- **Casters:** Keep the casters clean and free of debris (hair, dust, etc.) to ensure smooth movement.
- **Gas Lift:** Do not attempt to disassemble or repair the gas lift cylinder yourself. Contact professional service if it malfunctions.

Troubleshooting

If you encounter issues with your ThunderX3 YAMA1 chair, refer to the following common solutions:

- **Chair is wobbly:** Check all assembly bolts and screws. Ensure they are fully tightened. Make sure the chair is on a flat, even surface.
- **Chair makes creaking noises:** This can often be resolved by tightening all screws, especially those connecting the seat and backrest. A small amount of silicone lubricant can be applied to moving parts if the noise persists, avoiding contact with upholstery.
- **Gas lift not adjusting height:** Ensure the height adjustment lever is fully engaged or disengaged. If the gas lift still doesn't function, it may need replacement. Contact customer support.
- **Casters not rolling smoothly:** Remove any hair or debris wrapped around the caster wheels. Clean the wheels with a damp cloth.
- **Backrest not reclining/locking:** Check the recline lever and mechanism for any obstructions. Ensure it is fully

engaged or disengaged.

Specifications

Feature	Detail
Model Number	YAMA1
Product Dimensions (D x W x H)	70 x 69 x 132 cm (27.6 x 27.2 x 52 inches)
Item Weight	19.8 kg (43.6 lbs)
Recommended Maximum Weight	350 lbs (approximately 158 kg)
Filling Material	Foam
Back Style	Mesh back
Frame Material	Nylon, Metal
Special Features	Ergonomic design, Adjustable Headrest (2-way), Adjustable Armrests (1-way), Adjustable Lumbar Support, Adjustable Seat Depth, Reclining Backrest (90-135 degrees)
Gas Lift	BIFMA-approved Class 4 Gas Lift
Care Instructions	Dry clean



Image: A diagram illustrating the key dimensions (height, width, depth) of the ThunderX3 YAMA1 gaming chair.

Warranty Information

Specific warranty details for the ThunderX3 YAMA1 gaming chair are typically provided with the product packaging or

can be found on the official ThunderX3 website. Please refer to these sources for information regarding warranty period, coverage, and claims process.

Customer Support

For further assistance, technical support, or inquiries regarding your ThunderX3 YAMA1 gaming chair, please visit the official ThunderX3 website or contact their customer service department. Contact information can usually be found on the product packaging or the manufacturer's website.

© 2023 ThunderX3. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XYL2N5J

More documents and user manuals: **https://manuals.plus/**