

Gigaset AS690HX

Gigaset AS690HX DECT Cordless IP Phone User Manual

Model: AS690HX (S30852-H2876-R101)

1. INTRODUCTION

The Gigaset AS690HX is a reliable DECT cordless IP phone designed for versatile connection to standard DECT base stations. It features a high-contrast graphic display, superior audio quality, and a hands-free function, making it an ideal communication device for both home and office environments. This manual provides essential information for setting up, operating, and maintaining your Gigaset AS690HX phone.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 Gigaset AS690HX Handset
- 1 Charging Base
- 1 Power Supply Unit
- 2 AAA (NiMH) Rechargeable Batteries
- 1 Battery Cover
- 1 User Manual



Image: The Gigaset AS690HX handset resting in its charging base, showcasing its sleek black design and illuminated display.

3. SETUP

3.1 Battery Installation

1. Remove the battery cover on the back of the handset.
2. Insert the two supplied AAA (NiMH) rechargeable batteries, ensuring correct polarity.
3. Replace the battery cover.

3.2 Connecting the Charging Base

1. Connect the power supply unit to the charging base.
2. Plug the power supply unit into a wall outlet.
3. Place the handset in the charging base to charge the batteries. Allow at least 8 hours for the initial charge.

3.3 Registering the Handset to a DECT Base Station

The Gigaset AS690HX is designed to connect to any standard DECT base station. Follow these general steps for registration:

1. Activate registration mode on your DECT base station (refer to your base station's manual for specific instructions). This usually involves pressing and holding a registration/paging button on the base.
2. On the Gigaset AS690HX handset, navigate to the 'Settings' or 'Registration' menu.
3. Select 'Register Handset' and follow the on-screen prompts. You may be asked to enter a PIN (default is usually 0000).
4. Once successfully registered, the handset display will show the internal number (e.g., INT 1) and the signal strength.



Image: The Gigaset AS690HX handset displaying 'INT' (Internal) along with the current time and signal strength, indicating successful registration.

4. OPERATING INSTRUCTIONS

4.1 Making and Receiving Calls

- **Making a Call:** Enter the phone number using the keypad and press the green call button.
- **Receiving a Call:** Press the green call button when the phone rings.
- **Ending a Call:** Press the red end call button.

4.2 Hands-Free Function

During a call, press the hands-free button (speaker icon) to activate or deactivate the hands-free mode. The Gigaset AS690HX offers great sound quality even in hands-free mode.

4.3 Volume Control

The handset features a 5-level volume control for both the ringer and the earpiece/hands-free speaker. Adjust the volume using the navigation keys during a call or through the settings menu.

4.4 Phonebook

The phonebook can store up to 100 contacts. To add a contact:

1. Navigate to the 'Phonebook' menu.
2. Select 'New Entry'.
3. Enter the name and phone number.
4. Save the entry.

4.5 Call Blocking

The Gigaset AS690HX allows you to block up to 32 numbers. This feature helps to prevent unwanted calls. Access the 'Call Blocking' option in the settings menu to add or remove numbers from the block list.

4.6 Jumbo Mode

For enhanced readability, activate the jumbo mode. In this mode, all numbers are displayed larger during dialing, making it easier to see the digits on the high-contrast display.



Image: The Gigaset AS690HX handset showing an incoming call from "Emma Martin" on its clear graphic display, with 'OK' and 'Menu' options.

5. FEATURES OVERVIEW

- **High-Contrast Display:** Large graphic display for excellent readability.
- **Jumbo Mode:** Enlarges numbers during dialing for improved visibility.
- **Hands-Free Function:** Integrated speakerphone with superior audio quality.
- **Volume Control:** 5 adjustable levels for earpiece and ringer.

- **Phonebook Capacity:** Stores up to 100 contacts.
- **Call Blocking:** Blocks up to 32 unwanted numbers.
- **Ergonomic Keypad:** Comfortable and responsive keys for easy dialing.
- **ECO DECT Technology:** Environmentally friendly, ensuring reduced energy consumption.
- **Made in Germany:** Designed and manufactured in Germany, ensuring high quality and reliability.

6. MAINTENANCE

6.1 Cleaning

Wipe the handset and charging base with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the surfaces.

6.2 Battery Care

Use only the recommended NiMH rechargeable batteries. Non-rechargeable batteries or other battery types may cause damage or malfunction. If the phone will not be used for an extended period, remove the batteries to prevent leakage.

7. TROUBLESHOOTING

If you encounter issues with your Gigaset AS690HX, please refer to the following common solutions:

- **No Dial Tone:** Ensure the charging base is properly connected to the power supply and the phone line (if applicable, for the DECT base station). Verify the handset is registered to the base station.
- **Handset Not Charging:** Check that the handset is correctly placed in the charging cradle and that the power supply is connected. Clean the charging contacts on both the handset and the base with a dry cloth.
- **Poor Sound Quality:** Ensure the handset is within range of the DECT base station. Check for interference from other electronic devices.
- **Cannot Register Handset:** Ensure the base station is in registration mode. Double-check the PIN if required. Try restarting both the base station and the handset.

For more complex issues, please consult the full user manual or contact Gigaset customer support.

8. SPECIFICATIONS

Brand	Gigaset
Model Number	S30852-H2876-R101
Color	Black
Phone Type	Cordless
DECT Standard	Yes
Special Features	Cordless
Compatible Devices	Standard telephone networks, answering machines, fax machines
Battery Composition	NiMH

Number of Batteries	2 AAA (included)
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	Battery Powered
Dialer Type	Single Keypad
Item Dimensions (L x W x H)	49 x 28 x 155 millimeters
Answering System Type	IP Phone
Item Weight	119 Grams
Manufacturer	Gigaset




9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or visit the official Gigaset website. If you require technical assistance or have questions not covered in this manual, please contact Gigaset customer support through their official channels.

You can find more information and support on the [Gigaset Brand Store](#).

© 2024 Gigaset. All rights reserved.

Related Documents - AS690HX

	<p>Gigaset C470 User Guide: Features and Operation</p> <p>Discover the Gigaset C470 cordless telephone with this user guide. Learn about its features including ECO DECT, SMS, hands-free calling, and setup. Find support information and operational details.</p>
	<p>Gigaset C330 Cordless Phone User Manual: Setup, Features, and Operation</p> <p>Comprehensive user manual for the Gigaset C330 cordless telephone, covering setup, base and handset features, safety, making calls, managing contacts, and settings. Learn how to get the most out of your Gigaset phone.</p>
	<p>Gigaset E560A Cordless Phone User Manual and Guide</p> <p>Explore the Gigaset E560A cordless phone with this comprehensive user manual. Learn about setup, operation, answer machine features, emergency functions, ECO DECT, and troubleshooting. Access the latest guide at www.gigaset.com/manuals.</p>



Comprehensive user manual for the Gigaset E630 and E630A cordless telephone system. Covers setup, operation, features, troubleshooting, and technical specifications.



Detailed technical specifications and features for the Gigaset N530 IP PRO base station and S700H PRO DECT handset bundle, an optimal communication solution for small businesses.

