

[Manuals.plus](#) /

› [Hemoblo](#) /

› Hemoblo Clip-on Watch Instruction Manual

Hemoblo 50BOXDS22YX19Y

Hemoblo Clip-on Watch Instruction Manual

Model: 50BOXDS22YX19Y

1. PRODUCT OVERVIEW

The Hemoblo Clip-on Watch is a versatile and durable timepiece designed for outdoor enthusiasts. It features a precise quartz movement, an easy-to-read luminous dial, and a robust carabiner clip for secure attachment to belt loops, backpacks, or uniforms. This watch is ideal for activities such as hiking, rock climbing, and mountaineering, providing reliable timekeeping in various conditions.



Image 1.1: Front and back view of the Hemoblllo Clip-on Watch, highlighting the luminous dial and the solid back casing.

Key Features:

- **Precise Quartz Movement:** Ensures accurate timekeeping.
- **Luminous Dial:** Hands and markers glow in the dark for visibility in low-light conditions.
- **Carabiner Clip:** Spring-loaded clip for secure and convenient attachment.
- **Durable Construction:** Made from alloy and glass, suitable for outdoor use.
- **Water Resistant:** Designed to withstand splashes and brief immersion (up to 100 meters).

2. SETUP

Before using your Hemoblllo Clip-on Watch, you will need to set the correct time.

Setting the Time:

1. Locate the crown (small knob) on the side of the watch case.
2. Gently pull the crown outwards until you feel a click. The watch hands will stop moving.
3. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the current time.
4. Once the time is set, push the crown back into its original position. The watch hands will resume movement.



Image 2.1: The Hemoblo Clip-on Watch, showing its dimensions and the crown used for time adjustment.

3. OPERATING INSTRUCTIONS

Attaching the Watch:

The integrated carabiner clip allows for easy and secure attachment:

1. Press the spring-loaded gate of the carabiner inwards to open it.
2. Hook the carabiner onto a belt loop, backpack strap, climbing harness, or uniform.
3. Release the gate to ensure it closes securely, preventing accidental detachment.



Image 3.1: A hand demonstrating how to open the spring-loaded carabiner clip on the watch.



Image 3.2: The watch securely clipped to a backpack strap, ready for outdoor use.

Using the Luminous Feature:

The watch dial features luminous hands and markers that absorb light and glow in the dark. To activate or enhance the glow, expose the watch face to a bright light source (natural or artificial) for a few minutes. The intensity and duration of the glow will depend on the exposure time and light source strength.

4. MAINTENANCE

Cleaning:

To maintain the appearance of your watch, wipe the case and glass with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish or crystal.

Water Resistance:

The watch is water resistant up to 100 meters. This means it can withstand splashes, rain, and brief immersion in water. It is **not** suitable for diving or prolonged submersion. Ensure the crown is fully pushed in before any contact with water to maintain water resistance.

Battery Replacement:

The watch operates on a quartz movement, powered by a battery. When the watch stops keeping time accurately, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

5. TROUBLESHOOTING

Watch Not Running:

- Check if the crown is fully pushed in. If it is pulled out, the watch will not run.
- The battery may be depleted. Refer to the 'Battery Replacement' section under Maintenance.

Inaccurate Timekeeping:

- Ensure the time was set correctly.
- A low battery can affect accuracy. Consider battery replacement.
- Extreme temperatures or strong magnetic fields can temporarily affect quartz watch accuracy.

Luminous Feature Not Glowing:

- The luminous material requires exposure to light to charge. Ensure the watch has been exposed to a sufficient light source.
- The glow intensity naturally diminishes over time after light exposure.

6. SPECIFICATIONS

Model Number	50BOXDS22YX19Y
Product Dimensions	3.07 x 1.57 x 0.39 inches (7.8 x 4 x 1 cm)
Item Weight	1.76 ounces (0.11 Pounds)
Case Material	Alloy Steel
Crystal Material	Glass
Movement Type	Quartz
Display Type	Analog
Water Resistance Depth	100 Meters
Additional Features	Glow In The Dark
UPC	738561939193

7. WARRANTY AND SUPPORT

Warranty Information:

This product is sold without a manufacturer's warranty. Please refer to the retailer's return policy for details on returns or exchanges.

Customer Support:

For any questions or concerns regarding your Hemoblo Clip-on Watch, please contact the retailer where the product was purchased. You may also visit the official [Hemoblo Store](#) for more information on their product range.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question