Soundstream STM-2000

Soundstream Sound Tower Portable Bluetooth Speaker User Manual

Model: STM-2000
Brand: Soundstream

1. Introduction

Thank you for choosing the Soundstream Sound Tower Portable Bluetooth Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.
The Soundstream Sound Tower is a versatile portable speaker designed to deliver high-quality audio with its 5-speaker 360° omnidirectional sound system, including a 5" subwoofer. It features Bluetooth 4.2 for wireless streaming, TWS (True Wireless Stereo) broadcasting to a second speaker, and an HDMI input for home audio integration. Its rechargeable battery allows for use anywhere.

2. Safety Information

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Do not disassemble, repair, or modify the unit. This will void the warranty.
- Keep the speaker away from water and other liquids. While it is waterproof, prolonged submersion is not recommended.
- Use only the provided or recommended charging cables and power adapters.
- Avoid placing the speaker near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Clean only with a dry cloth.
- Ensure proper ventilation and do not block any ventilation openings.

3. What's Included

Carefully unpack the box and ensure all items are present and in good condition. If any items are missing or damaged, contact your retailer.

- Soundstream Sound Tower Speaker
- USB Type-C Cable
- AUX / 3.5mm Cable





Image: The Soundstream Sound Tower speaker shown with its USB Type-C and AUX cables.

4. Product Overview

4.1 Front View





Image: Front view of the Soundstream Sound Tower, showcasing its sleek black cylindrical design with the Soundstream logo at the base.

4.2 Top Panel Controls





Image: Close-up of the top panel of the Soundstream Sound Tower, showing the touch-sensitive controls including mode selection (M), Bluetooth (BT), AUX, HDMI (ARC), Music, Movie, and power (E) buttons, along with a circular play/pause button surrounded by LED indicators.

4.3 Rear Panel Ports



Image: Rear view of the Soundstream Sound Tower, highlighting the input/output ports: RST (Reset), OUT, AUX, USB, and HDMI (ARC).

4.4 Internal Components (Exploded View)



Image: An exploded diagram showing the internal components of the Soundstream Sound Tower, including the main speaker drivers, subwoofer, and circuit boards.

5. Setup

5.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB Type-C cable to the speaker's USB port and the other end to a compatible USB power adapter (not included). The LED indicators on the top panel will show charging status.

- Battery Capacity: 8800mAh NiMh
- Charging Time: Approximately 5 hours via 5V 3A USB Type-C.

5.2 Placement

Place the Sound Tower on a stable, flat surface. For optimal 360° sound dispersion, ensure there are no obstructions around the speaker.

6. Operating Instructions

6.1 Power On/Off

Press and hold the power button (marked 'E' on the top panel) for a few seconds to turn the speaker on or off.

6.2 Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Soundstream Sound Tower" from the list.
4. Once paired, the LED indicator will become solid, and you will hear a confirmation tone.

Bluetooth Range: Up to 10 meters (33 feet).

6.3 AUX Input

Connect one end of the provided 3.5mm AUX cable to the speaker's AUX port and the other end to the audio output of

your device. The speaker will automatically switch to AUX mode or you may need to select it using the 'M' (Mode) button on the top panel.

6.4 HDMI (ARC) Input

Connect an HDMI cable (not included) from your TV's HDMI ARC port to the speaker's HDMI (ARC) port. This allows for high-quality audio transmission from your TV to the speaker. Select HDMI mode using the 'M' (Mode) button.

6.5 USB Playback

Insert a USB flash drive into the USB port on the rear panel. The speaker can play audio files directly from the drive. Use the controls on the top panel to navigate tracks.

6.6 True Wireless Stereo (TWS) Pairing

If you have two Soundstream Sound Tower speakers, you can pair them together for a true wireless stereo experience. Refer to the specific TWS pairing instructions that may be provided with a second unit or on the manufacturer's website.

6.7 Control Buttons

- **M (Mode):** Press to cycle through input modes (Bluetooth, AUX, HDMI, USB).
- **Play/Pause Button:** Press to play or pause audio.
- **Volume Control:** Adjust volume by rotating your finger along the circular LED ring on the top panel.
- **Music/Movie Modes:** Press to switch between optimized audio profiles for music or movies.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use.

8. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker using the provided USB Type-C cable.
Cannot pair via Bluetooth.	Speaker is not in pairing mode; device Bluetooth is off; too far from speaker.	Ensure speaker is in pairing mode (flashing LED). Turn on Bluetooth on your device. Move device closer to speaker (within 10m).
No sound.	Volume too low; incorrect input mode; cable not connected properly.	Increase volume on both speaker and source device. Select correct input mode (Bluetooth, AUX, HDMI). Check cable connections.
Sound distortion.	Volume too high; source audio quality is poor.	Lower the volume. Try a different audio source or file.

9. Specifications

Model Name: Soundstream

Model Number: STM-2000

Speaker Type: Subwoofer

Special Feature: Portable

Recommended Uses: Music

Compatible Devices: Laptop, Tablet, Smartphone

Subwoofer Diameter: 57.15 Centimeters (approx. 22.5 inches)

Controller Type: Button, Touch

Surround Sound Channel Configuration: 4.2

Battery Life: 5 Hours

Included Components: Sound Tower, USB Type-C Cable, AUX / 3.5mm Cable

Item Weight: 4.45 Kilograms (approx. 9.79 pounds)

Is Waterproof: TRUE

Battery Capacity: 8800 Milliamp Hours

Warranty Type: Limited

Wireless Communication Technology: Bluetooth

Speaker Size: 26 Centimeters (approx. 10.2 inches)

Power Source: Battery Powered

Signal-to-Noise Ratio: 95 dB

Woofer Diameter: 5 Inches

Number of Batteries: 1 12V batteries required. (included)

Bluetooth Range: 10 Meters

Connectivity Protocol: Bluetooth

UPC: 709483059634

Manufacturer: Soundstream

Product Dimensions: 0.39 x 0.39 x 0.39 inches (Note: This dimension appears to be a placeholder or error in the source data.)

Date First Available: September 18, 2019

Country of Origin: China

Speaker Maximum Output Power: 100 Watts

Audio Output Mode: Stereo

Mounting Type: Freestanding

SOUNDSTREAM

TECH SPECS

Speaker Drivers: 5" Subwoofer (x1) 2.5" Full Range (x2) 1" Tweeter (x2).

SYSTEM OUTPUT

100W Frequency Response: 30Hz-22kHz
Signal-to-Noise Ratio: ≥95dB Distortion: ≤0.5%

PHYSICAL CHARACTERISTICS

Size: 5.5"d x 5.5"w x 15"h Weight: 7.5 lbs



Image: A graphic summarizing key technical specifications for the Soundstream STM-2000, including speaker drivers, system output, physical characteristics, and what's included.



Image: A graphic detailing the rechargeable battery specifications (8800mAh NiMh, 5 hours operation, 5V 3A charging via USB Type-C) and Bluetooth connectivity (V4.2+EDR, 66ft/20 meters range, A2DP, AVRCP profiles).

10. Warranty and Support

The Soundstream Sound Tower Portable Bluetooth Speaker comes with a Limited Warranty. Please refer to the warranty card included in your package or visit the official Soundstream website for detailed warranty terms and conditions.

For technical support, troubleshooting assistance, or service inquiries, please contact Soundstream customer support through their official website or the contact information provided with your purchase.

Manufacturer: Soundstream

Country of Origin: China

Date First Available: September 18, 2019

© 2024 Soundstream. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question