Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ringke SS-GWA2-BZ-4440

Ringke Bezel Styling for Galaxy Watch Active 2 44mm - Instruction Manual

Model: SS-GWA2-BZ-4440 | Brand: Ringke

Introduction

This manual provides comprehensive instructions for the installation, use, and maintenance of your Ringke Bezel Styling accessory for the Galaxy Watch Active 2 44mm. This product is designed to enhance the aesthetic appeal and provide additional protection to your smartwatch.

The Ringke Bezel Styling allows you to personalize your device while safeguarding its original bezel from scratches and dents. Please read these instructions carefully before installation to ensure proper application and optimal performance.

Product Features

- **Exquisite Style:** Designed to emphasize the round Super AMOLED display, adding a unique and elegant accent to your smartwatch.
- **Astounding Selections:** Available in various styles and colors, allowing for personalized customization to match individual preferences.
- **Smooth and Sound Protection:** Constructed from first-rate stainless steel, providing an anti-scratch layer over the original bezel. It can also cover existing scratches and prevent new ones.
- **High-Class Quality:** Made from premium stainless steel, ensuring durability and a sophisticated appearance that maintains the watch's new look.
- **Secure Design:** Engineered for an optimal fit over the existing watch bezel, ensuring compatibility with various wristbands without interference.
- **Water Resistance:** Utilizes 3M Double-Coated Tapes for a strong adhesive bond, maintaining performance even when exposed to water.

Compatibility

The Ringke Bezel Styling (Model: SS-GWA2-BZ-4440) is specifically designed for the**Galaxy Watch Active 2 - 44mm** model. It is *not* compatible with the Galaxy Watch Active (first generation) or the Galaxy Watch Active 2 - 40mm model.




Image: Compatibility chart for Ringke Bezel Styling, indicating support only for the Galaxy Watch Active 2 44mm.

Setup and Installation

Follow these steps for a smart and simple installation of your Ringke Bezel Styling:

1. **Preparation:** Before installation, ensure your smartwatch bezel is completely clean and free of any oil, dust, or debris. Use a clean, dry cloth for this purpose.
2. **Positioning:** Gently place the Bezel Styling onto the watch to gauge the correct placement and alignment. Ensure it aligns perfectly with the existing ring around the watch face.

3. **Adhesive Application:** Carefully remove the protective film from the adhesive backing of the Bezel Styling by pulling on the tab.
4. **Attachment:** Once aligned, firmly press the Bezel Styling onto the watch, holding the sides and applying even pressure on all sides to ensure it has been securely attached.
5. **Curing Time:** Allow up to 12 hours for the adhesive to fully set and achieve maximum bond strength. Avoid disturbing the bezel during this period.

Disclaimer: *Repeated removal of the Bezel Styling may lower the adhesive performance. This product is not a screen protector.*



Image: Detailed installation steps for the Ringke Bezel Styling, illustrating the cleaning, adhesive removal, and pressing process.



Image: An illustration demonstrating the precise fit of the bezel styling on the Galaxy Watch Active 2, highlighting the adhesive layers for secure attachment.

Operating and Daily Use

Once installed, the Ringke Bezel Styling integrates seamlessly with your Galaxy Watch Active 2 44mm, enhancing both its appearance and durability.

- **Enhanced Aesthetics:** The bezel styling adds a premium and customized look to your smartwatch, allowing you to express your personal style.
- **Unrestricted Functionality:** The design ensures that all watch functions, including the touch screen, buttons, and

digital bezel (if applicable), remain fully accessible and operational.

- **Protection in Daily Life:** The stainless steel bezel acts as a protective barrier against everyday bumps, scratches, and minor impacts, preserving the original condition of your watch.
- **Compatibility with Accessories:** The slim profile of the bezel styling ensures it remains compatible with various watch bands and charging methods, including wireless charging.



Image: The Ringke Bezel Styling being positioned on a Galaxy Watch Active 2 44mm, illustrating its sleek design and how it complements the watch.



Image: A side-by-side comparison demonstrating the aesthetic enhancement provided by the Ringke Bezel Styling on the Galaxy Watch Active 2.




Image: The Ringke Bezel Styling providing daily protection to the metallic surface and screen of the Galaxy Watch Active 2 during regular wear.




Image: The Ringke Bezel Styling allows for free wireless charging of the Galaxy Watch Active 2 without obstruction.

Maintenance

To maintain the appearance and integrity of your Ringke Bezel Styling, follow these simple guidelines:

- **Cleaning:** Wipe the bezel regularly with a soft, damp cloth to remove dust, fingerprints, and smudges. Avoid abrasive cleaners or materials that could scratch the stainless steel finish.
- **Adhesive Care:** The 3M Double-Coated Tapes provide a strong bond, even in water. However, to ensure long-term adhesion, avoid unnecessary removal or repositioning of the bezel once installed.
- **Water Exposure:** While the adhesive is water-resistant, prolonged exposure to harsh chemicals (e.g., strong

detergents, solvents) or extreme temperatures may affect its performance over time. Rinse with fresh water after swimming or exposure to saltwater.



Image: The Ringke Bezel Styling maintains a strong bond even when exposed to water, thanks to its 3M Double-Coated Tapes.

Troubleshooting

If you encounter any issues with your Ringke Bezel Styling, consider the following:

- **Adhesive Not Sticking:**
  - Ensure the watch bezel was thoroughly cleaned and dry before application. Any oil or dust can prevent proper

adhesion.

- Verify that the protective film was fully removed from the adhesive.
- Ensure sufficient pressure was applied during installation and that the 12-hour curing time was observed.
- Note that repeated removal and reapplication will significantly weaken the adhesive.

- **Misalignment:**
  - The bezel styling is designed for a precise fit. If it appears misaligned, it may be due to improper initial placement. Due to the strong adhesive, repositioning after initial contact is difficult and not recommended.

For further assistance, please contact Ringke customer support.

Specifications

Attribute	Detail
Brand	Ringke
Model Number	SS-GWA2-BZ-4440
Colour	Silver (GW-A2-44-40)
Material	Stainless Steel
Compatible Devices	Galaxy Watch Active 2 44mm
Form Factor	Case / Bezel Ring
Item Dimensions (LxWxH)	44 x 44 x 3 Millimeters (approx. 4.39 x 4.39 x 0.25 cm)
Item Weight	15 g
Country of Origin	Republic of Korea

Warranty and Support

Ringke is committed to providing high-quality, innovative products. While specific warranty details are not provided in this manual, Ringke products are designed for durability and performance.

For any product-related inquiries, technical support, or assistance, please contact Ringke customer service through their official channels. You can typically find contact information on the Ringke official website or through the retailer where you purchased the product.

Ringke was established in 2003 with a goal to deliver reliable solutions and protection, ensuring customer satisfaction.

© 2024 Ringke. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Y2W72WG

More documents and user manuals: **https://manuals.plus/**