

Xech X-509

Xech SpeakerPods XL True Wireless Earbuds and Bluetooth Speaker User Manual

Model: X-509

PRODUCT OVERVIEW

The Xech SpeakerPods XL is a versatile audio device combining true wireless earbuds with a powerful 10W Bluetooth speaker. Designed for convenience and high-quality sound, it features Bluetooth 5.0 + EDR for stable connectivity, IPX4 water and sweat resistance, and intuitive touch controls for seamless operation. This manual provides detailed instructions for setting up, operating, and maintaining your device.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Xech SpeakerPods XL (Earbuds and Charging Case/Bluetooth Speaker)
- USB Charging Cable
- Silicone Ear Plugs (various sizes)
- User Manual

SETUP

1. Initial Charging

Before first use, fully charge the SpeakerPods XL case and earbuds. Connect the provided USB charging cable to the charging port on the case and a compatible USB power source. The LED indicators will show charging status. A full charge takes approximately 2 hours.

The case provides up to 100 hours of standby time for the earbuds, while the earbuds themselves offer up to 4 hours of playback on a single charge.

2. Pairing the Earbuds with Your Device

1. Ensure earbuds are charged.

2. Open the charging case and remove both earbuds. They will automatically enter pairing mode.
3. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices and select "Xech SpeakerPods XL" (or similar name) from the list.
5. Once connected, the earbuds will indicate successful pairing (e.g., an audio prompt or LED change).
6. The earbuds will auto-pair with the last connected device when removed from the case in the future.



Image: The Xech SpeakerPods XL earbuds and their charging case, illustrating their compact design and the Xech branding.

OPERATING INSTRUCTIONS

Earbud Controls (Touch Sensitive)

The earbuds feature sensitive touch controls for managing calls and music playback.

- **One Tap:** Answer/End Call, Play/Pause Music.
- **Two Taps:** Hang up a call.
- **Press & Hold (2 seconds):** Previous Track (left earbud), Next Track (right earbud).
- **Three Taps:** Activate Voice Assistant (Siri/Google Assistant).
- **Volume Control:** Specific touch gestures for volume up/down may vary; refer to the quick start guide for

precise details if available.



Image: A diagram illustrating the touch control functions on the earbud, including single tap for calls/play/pause, double tap to hang up, press and hold for track control, and triple tap for voice assistance.

Using the Bluetooth Speaker

The charging case doubles as a 10W Bluetooth speaker. To activate the speaker function:

1. Ensure both earbuds are securely placed back into the charging case.
2. The case will automatically switch to speaker mode, and audio will play through the integrated speaker.
3. The speaker will use the same Bluetooth connection as the earbuds.

10W Surround Sound Speaker



Image: The Xech SpeakerPods XL charging case, highlighting its function as a 10W surround sound speaker with a perforated grille design.

Voice Assistant Integration

The earbuds are optimized for use with Siri and Google Assistant. Triple-tap either earbud to activate your device's voice assistant and issue commands.




Image: A visual representation of the voice assist feature, indicating compatibility and optimization for Siri and Google Assistant.

MAINTENANCE

Cleaning

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Regularly clean the ear tips and mesh grilles to prevent wax buildup, which can affect sound quality.

Water and Sweat Resistance (IPX4)

The SpeakerPods XL earbuds and case are IPX4 rated, meaning they are resistant to splashing water and sweat from any direction. This makes them suitable for workouts and outdoor activities. However, they are not waterproof and should not be submerged in water or exposed to strong jets of water.

- Do not intentionally submerge the device in water.
- Ensure the charging port is dry before charging.
- If the device gets wet, wipe it dry immediately with a soft cloth.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing/connecting.	• Ensure earbuds are charged. • Turn off and on Bluetooth on your device. • Forget "Xech SpeakerPods XL" from your device's Bluetooth list and re-pair. • Place earbuds back in the case, close, then reopen and try again.
No sound or low volume.	• Check volume levels on both your device and the earbuds. • Ensure earbuds are properly seated in your ears. • Clean earbud mesh grilles for any obstructions. • Confirm successful Bluetooth connection.
Speaker not working.	• Ensure both earbuds are correctly placed inside the charging case. • Check if the case is charged. • Verify Bluetooth connection.
Earbuds not charging in case.	• Ensure the charging case itself is charged. • Check that the earbuds are correctly seated in their charging slots. • Clean the charging contacts on both the earbuds and the case.
Connectivity issues (sound breaking).	• Ensure your device is within the 10-meter operating range. • Avoid obstacles between your device and the earbuds. • Minimize interference from other wireless devices.

SPECIFICATIONS

Feature	Detail
Brand	Xech
Model Name	SPEAKER PODS
Model Number	X-509
Colour	Black
Ear Placement	In Ear
Form Factor	In Ear
Bluetooth Version	5.0 + EDR
Speaker Output	10W

Feature	Detail
Water Resistance	IPX4 (Splash & Sweat Resistant)
Control Type	Touch, Volume Control
Earbud Playback Time	Up to 4 Hours
Case Standby Time	Up to 100 Hours
Battery Charge Time	2 Hours
Operating Range	10 Meters
Compatible Devices	Android, Mac, Windows, iOS
Item Weight	440 Grams

WARRANTY INFORMATION

The Xech SpeakerPods XL comes with a **1-year domestic warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your purchase receipt as proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

CUSTOMER SUPPORT

For any queries, technical assistance, or warranty claims, please contact Xech customer support:

- **Manufacturer:** Theo Solutions Pvt Ltd, XECH
- **Importer & Marketer:** Theo Solutions Pvt. Ltd.
- **Address:** 51 Sarvodaya Industrial Estate, Near Paper Box, Off Mahakali Caves Road, Andheri East, Mumbai: 400093, India
- Please refer to the contact information provided on your product packaging or the official Xech website for the most up-to-date support details.

IMPORTANT SAFETY INFORMATION

- Do not disassemble, repair, or modify the device.
- Keep the device away from extreme temperatures, direct sunlight, and open flames.
- Avoid exposing the device to strong magnetic fields.
- Dispose of the device and its battery responsibly according to local regulations.
- Do not use the earbuds at excessively high volumes for prolonged periods to prevent hearing damage.