

Notável NT1315

Notável Móveis NT 1315 TV Rack User Manual

Model: NT1315

1. PRODUCT OVERVIEW

The Notável Móveis NT 1315 TV Rack is designed to accommodate televisions up to 60 inches, offering a stylish and functional solution for your living space. This furniture piece features elegant wooden feet and a meticulously grooved MDF door, combining durability with a unique aesthetic. Its robust structure, made from 15mm and 25mm MDP/MDF, ensures exceptional resistance and longevity.

Key Features:

- **Durable Construction:** Made from MDP and MDF with 15mm and 25mm thickness, ensuring stability and longevity.
- **Spacious Design:** Features a wide top and base (25mm thick) and ample storage space, including a large niche.
- **Gas Piston Door:** Equipped with one door featuring a gas piston for smooth and safe opening, facilitating access to compartments.
- **TV Compatibility:** Supports TVs up to 60 inches, providing an ideal platform for large screens.
- **Elegant Details:** Includes decorative grooves on the MDF door and solid wooden feet for enhanced aesthetic appeal.
- **UV Paint Finish:** Provides a protective and attractive finish.



Figure 1: General view of the Notável Móveis NT 1315 TV Rack, showing its dimensions relative to a person.

2. SETUP AND ASSEMBLY

Assembly of the NT 1315 TV Rack is required. Please ensure you have all components and hardware before beginning.

2.1 Unpacking and Inventory

- Carefully unpack all contents from the box.
- Verify that all parts and hardware (ferragens) listed in the included assembly manual are present. The package includes necessary hardware for assembly.
- Keep packaging materials until assembly is complete to avoid misplacing small parts.

2.2 Assembly Instructions

Follow the detailed step-by-step instructions provided in the separate assembly manual included with your product. Ensure all screws and fasteners are tightened securely, but do not overtighten to avoid damaging the material. It is recommended to assemble the rack on a soft, clean surface to prevent scratches.



Figure 2: Technical drawing illustrating the dimensions of the TV rack and its internal compartments.

3. OPERATION

3.1 Placing Your Television

The NT 1315 TV Rack is designed to support televisions up to 60 inches. Place your TV centrally on the top surface of the rack to ensure even weight distribution and stability. Ensure the TV's base fits securely on the rack's surface.



Figure 3: The TV rack with a television placed on top and various media devices and decorative items in the compartments.

3.2 Using the Storage Compartments

The rack features an ample open niche and a closed compartment with a gas piston door.

- **Open Niche:** Ideal for media players, soundbars, game consoles, or decorative items.
- **Gas Piston Door:** To open the door, gently pull it downwards. The gas piston will assist in a smooth, controlled opening. To close, gently push the door upwards until it latches securely. Avoid forcing the door.



Figure 4: The TV rack with its gas piston door open, showcasing the internal storage capacity for various items.




Figure 5: Close-up view highlighting key features such as the gas piston door mechanism, decorative MDF grooves, and solid wooden feet.

4. MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your TV rack.

- **Cleaning:** Wipe the surfaces with a soft, slightly damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood and finish.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat and Moisture:** Keep the rack away from excessive heat sources and high humidity to prevent warping or damage.
- **Hardware:** Periodically check and tighten any loose screws or fittings to ensure structural integrity.

5. TROUBLESHOOTING

If you encounter any issues with your NT 1315 TV Rack, please refer to the following common solutions:

- **Instability:** Ensure all assembly screws are properly tightened. Check that the rack is placed on a flat, level surface.
- **Door Not Closing/Opening Smoothly:** Verify that the gas piston is correctly installed and not obstructed. Check for any foreign objects preventing the door from moving freely. If the issue persists, inspect the hinges and piston for damage.
- **Scratches/Dents:** For minor cosmetic damage, touch-up pens or furniture repair kits matching the finish may be used.

For problems not addressed here, please contact customer support.

6. SPECIFICATIONS

Feature	Detail
Model Number	NT1315
Brand	Notável Móveis
Color	Freijo Trend/Preto TX
Product Dimensions (Assembled)	Width: 163.4 cm (64.3 inches) Height: 65.5 cm (25.8 inches) Depth: 38 cm (15 inches)
Product Dimensions (Packaged)	39.2 x 171 x 11.5 cm (15.4 x 67.3 x 4.5 inches)
Product Weight	33.60 kg (74.07 lbs)
Shipping Weight	35 kg (77.16 lbs)
Material	MDP and MDF (15mm and 25mm thickness)
TV Size Support	Up to 60 inches
Number of Doors	1 (with gas piston)
Assembly Required	Yes
Items Included in Package	Hardware (Ferragens)

7. WARRANTY INFORMATION

This Notável Móveis NT 1315 TV Rack comes with a **3-month supplier warranty**. The warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. Damage resulting from improper assembly, misuse, neglect, or unauthorized modifications is not covered under warranty.

8. CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your product, please contact Notável Móveis customer support. Refer to the contact information provided on your purchase receipt or the manufacturer's official website. When contacting support, please have your model number (NT1315) and proof of purchase readily available.