

Weehom B07Y4RMJHL

# WeeHom Reversible L Shaped Desk Instruction Manual

Model: B07Y4RMJHL

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your WeeHom Reversible L Shaped Desk. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

## SAFETY INFORMATION

**WARNING:**

- Always assemble according to the provided instructions.
- Ensure the desk is properly anchored to the floor to prevent tipping, especially when using heavy equipment.
- Do not place heavy objects on the desk near the edges to maintain stability.
- Keep small parts away from children during assembly.

## PRODUCT FEATURES

The WeeHom Reversible L Shaped Desk is designed for versatility and durability, suitable for home office or gaming setups. Key features include:

- **Reversible Design:** The L-shape can be configured with the long side on either the left or right to fit various room layouts.
- **Durable Construction:** Made from P2 class engineered wood and a sturdy metal frame.
- **Spacious Work Surface:** Provides ample space for multiple monitors, laptops, and office accessories.

- **Integrated CPU Stand:** A movable stand is included to keep your computer tower off the floor.
- **Adjustable Leg Pads:** Ensures stability on uneven floors.
- **Monitor Mount Hole:** A compatible hole is provided for easy installation of a monitor mount.
- **Easy Maintenance:** The desk surface is designed to be wipe-easily, anti-scratch, and waterproof.



Wipe Easily



Anti-scratch




Waterproof



Image: Desk surface highlighting its wipe-easy, anti-scratch, and waterproof characteristics.




## Modern L Shaped Computer Desk



Round corner safety design,  
avoid colliding or hurting



A compatible hole at round  
corner for monitor mount



Adjustable pads keep the  
desk stable on the uneven floor

Image: Detailed view of the desk's round corner for safety, a pre-drilled hole for monitor mounts, and adjustable leveling feet for stability.



Image: Diagram illustrating the ample legroom and open space underneath the desk, allowing for comfortable movement.

## SETUP AND ASSEMBLY

Assembly of the WeeHom L Shaped Desk typically requires two people and approximately 1-2 hours. All necessary tools and hardware are included. Follow the step-by-step instructions provided in the packaging. Ensure all screws are tightened securely but do not overtighten to avoid damaging the frame.

For a visual guide, please refer to the official assembly video below:

Your browser does not support the video tag.

Video: Official assembly guide for the WeeHom Reversible L Shaped Computer Desk. This video demonstrates the step-by-step process of putting the desk together, including attaching the frame and panels, and configuring the reversible sections.

### Key Assembly Steps:

1. Unpack all components and verify against the parts list.

2. Assemble the main frame sections using the provided screws and tools.
3. Attach the crossbars to connect the frame sections, ensuring proper alignment.
4. Carefully place the desk panels onto the assembled frame, securing them with screws.
5. Install the adjustable leg pads on the bottom of the desk legs.
6. Position the movable CPU stand as desired.



Image: Illustration demonstrating the reversible panel design, allowing users to switch the long and short sides of the L-shaped desk.

## OPERATING INSTRUCTIONS

Your WeeHom L Shaped Desk is designed for flexible use in various environments. Here are some operational considerations:

- **Reversible Configuration:** The desk can be assembled with the longer section on either the left or right side. This allows for optimal placement in your room. If you need to change the configuration after initial assembly,

carefully disassemble the top panels and frame connections, then reassemble in the desired orientation.

- **Monitor Placement:** Utilize the pre-drilled hole for a monitor mount to free up desk space and achieve an ergonomic setup.
- **CPU Stand:** The included CPU stand is movable, allowing you to position your computer tower conveniently under either side of the desk.
- **Adjustable Feet:** Adjust the leveling feet at the bottom of each leg to ensure the desk is stable and level on uneven floor surfaces.



Image: An example setup of the L-shaped desk configured for gaming, showcasing its spacious surface accommodating multiple monitors and accessories.

## MAINTENANCE

To ensure the longevity and appearance of your WeeHom L Shaped Desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desk surface regularly with a soft, damp cloth. For tougher stains, use a mild soap solution and dry immediately. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** The desk surface is waterproof. In case of spills, wipe them up promptly to prevent any potential damage to the engineered wood.
- **Protection:** Use coasters for drinks and pads under hot items to protect the surface.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Extreme Conditions:** Do not expose the desk to extreme temperatures or humidity, as this can affect the wood material.

## TROUBLESHOOTING

If you encounter any issues with your WeeHom L Shaped Desk, refer to the following common problems and solutions:

| Problem                             | Possible Cause                                             | Solution                                                                                                                                                     |
|-------------------------------------|------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Desk is wobbly or unstable.         | Uneven floor; loose screws; incorrect assembly.            | Adjust the leveling feet on the bottom of the legs. Check and tighten all assembly screws. Ensure all parts are correctly installed according to the manual. |
| Parts do not align during assembly. | Incorrect orientation of parts; screws not fully loosened. | Review the assembly instructions carefully, paying attention to part orientation. Loosen screws slightly to allow for adjustment, then tighten once aligned. |
| Surface scratches easily.           | Sharp objects; excessive force.                            | While the surface is anti-scratch, avoid dragging sharp objects across it. Use desk mats for protection.                                                     |

If the problem persists or is not listed here, please contact customer support.

## SPECIFICATIONS


Detailed specifications for the WeeHom Reversible L Shaped Desk:



Industrial Styled - P2  
class partial board



0.6 IN



Weight Capacity: 450 LBS




Image: Technical diagram displaying the overall dimensions (length, width, height) and the maximum weight capacity of the desk.

| Feature                        | Detail                   |
|--------------------------------|--------------------------|
| Brand                          | Weehom                   |
| Model Number                   | B07Y4RMJHL               |
| Shape                          | L-Shape                  |
| Product Dimensions (D x W x H) | 66.1"D x 47.2"W x 29.7"H |
| Color                          | Brown                    |
| Style                          | Modern, Industrial       |
| Base Material                  | Engineered Wood          |
| Top Material Type              | Engineered Wood, Metal   |

| Feature             | Detail                                                                                                                                                    |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Finish Type         | Steel, Wooden                                                                                                                                             |
| Item Weight         | 50.7 pounds                                                                                                                                               |
| Weight Capacity     | 450 LBS                                                                                                                                                   |
| Included Components | Desk, Keyboard Tray (implied by reviews, not explicitly listed in components but often part of L-desks), Monitor Arm (implied by monitor hole), CPU Stand |
| Mounting Type       | Freestanding                                                                                                                                              |

## WARRANTY AND SUPPORT

The WeeHom Reversible L Shaped Desk comes with a limited warranty. For specific details regarding warranty coverage, please refer to the documentation included with your product or contact WeeHom customer support. For any questions, assistance with assembly, or to report missing/damaged parts, please contact WeeHom Customer Support. Contact information can typically be found on the product packaging or the official WeeHom website.

You can also visit the [WeeHom Store on Amazon](#) for more information and support resources.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B07Y4RMJHL>

More documents and user manuals: <https://manuals.plus/>