

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Jada](#) /
- › [Jada Disney Pixar Toy Story 4 Woody Turbo Buggy RC Vehicle \(Model 32398\) User Manual](#)

Jada 32398

Jada Disney Pixar Toy Story 4 Woody Turbo Buggy RC Vehicle User Manual

Model: 32398

1. INTRODUCTION

This manual provides essential instructions for the safe and effective operation, setup, and maintenance of your Jada Disney Pixar Toy Story 4 Woody Turbo Buggy Radio Control Vehicle. Please read this manual thoroughly before use and retain it for future reference. This product is designed for users aged 4 years and up.



Image 1.1: The Jada Disney Pixar Toy Story 4 Woody Turbo Buggy RC Vehicle and its pistol-grip remote control.

2. SAFETY INFORMATION

Observe the following safety precautions to prevent injury or damage to the product:

- **Adult Supervision:** Always ensure adult supervision, especially for younger children.
- **Battery Safety:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Insert batteries with correct polarity. Remove batteries if the product is not used for an extended period. Dispose of used batteries responsibly.
- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age.
- **Operating Environment:** Operate the vehicle on flat, dry surfaces. Avoid water, sand, or excessively dusty areas. Do not operate near roads, people, or pets.
- **Impacts:** Avoid collisions with hard objects or walls, as this may damage the vehicle or controller.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Woody Turbo Buggy RC Vehicle
- 1 x 2.4 GHz Pistol Grip Remote Control

Note: Batteries are not included and must be purchased separately.



Image 3.1: Front view of the product packaging, showing the vehicle and Woody figure.

4. SETUP

4.1 Battery Installation

The vehicle requires 3 x 'AA' batteries and the remote control requires 2 x 'AAA' batteries (not included).

1. Vehicle Battery Installation:

- Locate the battery compartment on the underside of the Woody Turbo Buggy.
- Using a screwdriver, open the battery compartment cover.
- Insert 3 x 'AA' batteries, ensuring correct polarity (+/-).
- Replace the cover and secure it with the screw.

2. Remote Control Battery Installation:

- Locate the battery compartment on the back of the remote control.
- Using a screwdriver, open the battery compartment cover.
- Insert 2 x 'AAA' batteries, ensuring correct polarity (+/-).
- Replace the cover and secure it with the screw.

4.2 Pairing the Vehicle and Remote Control

The 2.4 GHz frequency allows for multiple vehicles to operate simultaneously without interference. Follow these steps to pair your vehicle and remote:

1. Ensure fresh batteries are installed in both the vehicle and the remote control.
2. Turn on the vehicle using the ON/OFF switch located on its underside.
3. Turn on the remote control. The indicator light on the remote may blink.
4. To pair, turn the steering wheel on the remote control fully to the right and hold it for a few seconds. The remote's indicator light should stop blinking and remain solid, indicating a successful connection.
5. If pairing is unsuccessful, turn off both the vehicle and remote, then repeat steps 2-4.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Functions



Image 5.1: The pistol-grip remote control for the Woody Turbo Buggy.

- **Trigger (Forward/Backward):** Pull the trigger towards you to move the vehicle forward. Push the trigger away from you to move the vehicle backward.
- **Steering Wheel (Left/Right):** Turn the steering wheel left to turn the vehicle left. Turn the steering wheel right to turn the vehicle right.
- **Turbo Button/Lever:** Activate the turbo feature by pressing or engaging the designated button/lever on the remote control for a temporary speed boost.



Image 5.2: Demonstrating the turbo lever on the remote control.

5.2 Driving Tips

- Start slowly to get accustomed to the controls.
- Practice steering in open areas before attempting more complex maneuvers.
- The 2.4 GHz frequency allows for a range of up to 100 feet. Keep the vehicle within this range for optimal control.
- The vehicle is designed for indoor and outdoor use on smooth, dry surfaces.




Image 5.3: The vehicle features dynamic steering for responsive control.

6. MAINTENANCE

6.1 Cleaning

- Turn off the vehicle and remove batteries before cleaning.
- Wipe the vehicle and remote control with a soft, dry cloth.
- Do not use water, solvents, or chemical cleaners, as these can damage electronic components.

6.2 Storage

- Store the vehicle and remote in a cool, dry place away from direct sunlight.
- Remove all batteries from both the vehicle and remote control if storing for an extended period to prevent leakage and damage.

6.3 Battery Care

- Always use fresh, high-quality batteries.
- Replace all batteries at the same time; do not mix old and new batteries.
- Never attempt to recharge non-rechargeable batteries.

7. TROUBLESHOOTING

If you encounter issues with your Woody Turbo Buggy, refer to the following table:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Vehicle does not move or respond.	<ul style="list-style-type: none"> Batteries are low or incorrectly installed. Vehicle and remote are not paired. Vehicle is turned off. 	<ul style="list-style-type: none"> Replace batteries in both vehicle and remote, ensuring correct polarity. Follow pairing instructions in Section 4.2. Ensure vehicle's ON/OFF switch is in the 'ON' position.
Short operating range or intermittent control.	<ul style="list-style-type: none"> Low batteries. Interference from other 2.4 GHz devices. Vehicle is out of range. 	<ul style="list-style-type: none"> Replace batteries. Move to an area with less electronic interference. Operate the vehicle within 100 feet of the remote control.
Vehicle moves slowly.	Low batteries in the vehicle.	Replace the 'AA' batteries in the vehicle.







8. SPECIFICATIONS

- **Model Number:** 32398
- **Product Dimensions:** 7 x 4.5 x 5 inches
- **Item Weight:** 1.15 pounds
- **Scale:** 1:24
- **Frequency:** 2.4 GHz
- **Vehicle Batteries:** 3 x 'AA' (not included)
- **Remote Control Batteries:** 2 x 'AAA' (not included)
- **Recommended Age:** 4 years and up
- **Manufacturer:** Dickie Toys
- **Release Date:** June 1, 2021

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Jada Toys website. Keep your purchase receipt as proof of purchase.

Related Documents - 32398

	<p>Jada 1/16\" RC Vehicle: User Manual and Operation Guide</p> <p>Get detailed instructions for your Jada 1/16" remote control vehicle. This guide covers setup, charging, playing, troubleshooting, safety, and regulatory information for model F84228-KMAR-1SH-EN01A.</p>
	<p>Jada FF19 7.5\" RC Car Instruction Manual</p> <p>This document provides instructions for operating and maintaining the Jada FF19 7.5" RC Car, including features like the vapor function and turbo boost. It covers battery installation, troubleshooting, and safety precautions.</p>
	<p>Spider-Man RC Standing Drift Function - Five Wheel Stunt FCC Test Report</p> <p>FCC test report for the Spider-Man RC Standing Drift Function - Five Wheel Stunt by Jada Toys Co. Ltd., detailing radiated emission and bandwidth measurements according to FCC Part 15, Subpart C.</p>
	<p>Jada Toys RC Buggy Woody Toy Story Edition Instruction Manual</p> <p>Official instruction manual for the Jada Toys RC Buggy Woody, featuring Toy Story branding. Includes setup, operation, battery installation, safety warnings, and customer support information.</p>
	<p>Jada Toys Back to the Future Time Machine R/C 1:16 Scale - User Manual</p> <p>Comprehensive user manual and safety guide for the Jada Toys Back to the Future Time Machine R/C 1:16 scale remote control vehicle. Learn how to charge, operate, troubleshoot, and maintain your RC car, along with important safety information and warranty details.</p>
	<p>Jada Toys Marvel F35981-0000-ISH-4L01A Remote Control Car User Manual</p> <p>Comprehensive user manual for the Jada Toys Marvel F35981-0000-ISH-4L01A remote control car. Includes setup, operation, safety guidelines, and troubleshooting tips.</p>