

WallarGe Westminster Chime Wall Clock

WallarGe Westminster Chime Wall Clock User Manual

Model: Westminster Chime Wall Clock

Brand: WallarGe

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your WallarGe Westminster Chime Wall Clock. Designed with a cherry tone wood finish and a classic pendulum, this clock offers both aesthetic appeal and precise timekeeping with a silent quartz movement and hourly chimes.



Front view of the WallarGe Westminster Chime Wall Clock, showcasing its cherry tone wood frame, classic dial with Arabic numerals, and decorative pendulum.

2. PRODUCT FEATURES

- **Pendulum Wall Clock:** Features an extra-large display with a swinging pendulum and five crystal adornments.
- **Chime Options:** Offers 3-way chiming with BIMBAM or Westminster melodies every hour, and 4x4 Westminster sound every quarter.
- **Silent Quartz Movement:** High-precision mechanism ensures accurate timekeeping without ticking noise.
- **Battery Operated:** Requires 2 C-size batteries for the clock and chime, and 1 AA battery for pendulum movement (batteries included).
- **Cherry Tone Wood Frame:** Constructed with a high-end solid wood frame and clear anti-fog glass for durability and clear visibility.
- **Night Mute Feature:** Chime sound can be muted automatically between 11:00 PM and 6:00 AM to avoid disturbance.
- **Adjustable Chime:** Option to completely disable chime sounds if preferred.

3. PACKAGE CONTENTS

Please verify that all items are present in the package:

- WallarGe Westminster Chime Wall Clock
 - 2 x LR14 C CELL Batteries
 - 1 x AA Battery
 - Mounting Nails
 - User Manual (this document)
-

4. SETUP

4.1 Battery Installation

Locate the battery compartments on the back of the clock. Insert 2 C-size batteries into the designated slots for the quartz clock movement and chiming function. Insert 1 AA battery into the separate slot for the pendulum swinging mechanism. Ensure correct polarity (+/-) as indicated.

4.2 Time Setting

After installing batteries, locate the 'Time Set Wheel' on the back of the clock. Gently rotate this wheel to set the correct time. It is recommended to set the time by moving the minute hand clockwise.

4.3 Mounting the Clock

Choose a suitable wall location. Use the provided mounting nails and the 'Hanging Hole' on the back of the clock to securely mount it. Ensure the clock is level for optimal pendulum operation.



Rear view of the WallarGe Wall Clock, highlighting the hanging hole, speaker, time set wheel, and battery compartments for 2 C-size batteries (for clock and chime) and 1 AA battery (for pendulum).



The WallarGe Wall Clock displayed on a wall, illustrating its dimensions: 22 inches high, 14.5 inches wide, and 3 inches deep.

5. OPERATING INSTRUCTIONS

5.1 Chime Settings

Your WallarGe clock offers multiple chime options. Controls for selecting the chime melody (BIMBAM or Westminster) and chime frequency (hourly or 4x4 Westminster every quarter) are located on the back of the clock, typically near the battery compartments or speaker. Refer to the specific markings on your clock for precise adjustments.

5.2 Night Mute Feature

The clock is equipped with a 'Sleep Model' feature that automatically mutes the chime sounds between 11:00 PM and 6:00 AM to ensure undisturbed sleep. This feature is typically activated via a switch or setting on the back of the clock.

5.3 Disabling Chimes

If you prefer no chiming at all, there is an option to completely disable the chime sounds. This setting is usually found on the back panel of the clock, often a switch labeled 'Chime On/Off' or similar.

6. MAINTENANCE

6.1 Cleaning

To clean the clock, gently wipe the wood frame and glass screen with a soft, dry, lint-free cloth. Avoid using abrasive cleaners or chemical sprays, as these may damage the finish or internal components.

6.2 Battery Replacement

Replace batteries annually or when the clock's performance (timekeeping accuracy, chime volume, pendulum swing) diminishes. Always replace all batteries at once with new ones of the specified type (2 C-size, 1 AA). Dispose of old batteries responsibly.



High-grade solid wood frame



Delicate and retro pendulum



High-grade paint process metal pointer



Super-mute movement

Detailed views of the WallarGe Wall Clock, showing the high-grade solid wood frame, the delicate and retro pendulum with crystal adornments, the high-grade paint process metal pointer, and the super-mute quartz movement mechanism.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Clock not running	Dead or incorrectly installed C-size batteries.	Check battery polarity. Replace C-size batteries.
Chime not sounding	Chime feature is off, night mute is active, or C-size batteries are low.	Check chime settings on the back. Verify time is outside night mute hours. Replace C-size batteries.
Pendulum not swinging	Dead or incorrectly installed AA battery.	Check battery polarity. Replace AA battery.
Incorrect time display	Time not set correctly.	Adjust time using the 'Time Set Wheel' on the back.

8. SPECIFICATIONS





Feature	Detail
Brand	WallarGe
Display Type	Analog
Style	Pendulum
Special Features	Silent Clock, Timer, Chime with Night Mute
Power Source	Battery Powered (2 C-size, 1 AA)
Room Type	Hotel, Office, Home
Shape	Oval
Material	Wood
Theme	Vintage
Frame Material	Glass, Plastic, Wood
Batteries Included	Yes
Mounting Type	Wall Mount
Alarm Clock	No
Operation Mode	Mechanical
Manufacturer	quartz
UPC	700355110774



Feature	Detail
ASIN	B07Y65PWM7
Item Weight	2 kg 70 g
Dimensions (H x W x D)	22" x 14.5" x 3"

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. You may also visit the official WallarGe website for further assistance.

Related Documents - Westminster Chime Wall Clock

	<p>Westminster Chime Clock Instructions and Desk Clock Guide</p> <p>Comprehensive guide to setting up, operating, and maintaining Westminster chime clocks, including battery replacement, time setting, chime melody selection, and volume adjustment. Also features a review of various desk clocks with their pros and cons.</p>
	<p>Lovely Home Quartz Pendulum Wall Clock Operating Instructions</p> <p>Operating instructions and troubleshooting guide for the Lovely Home Quartz Pendulum Wall Clock. Covers battery installation, time setting, cleaning advice, and solutions for common issues such as the pendulum or hands not moving, a bent pendulum, or the pendulum hitting the clock's side.</p>
	<p>Installation Instructions and Usage Functions for World Menagerie Polaris Solid Wood Floor Clock</p> <p>Comprehensive installation instructions and usage guide for the World Menagerie Polaris solid wood floor clock (model sonq1325 / W113530379). Learn how to set up accessories, start the clock, adjust time, control chime functions, fine-tune speed, and properly wind the mechanical movement.</p>
	<p>Karlsson KA6044 Cuckoo Light Wall Clock Instruction Manual</p> <p>Comprehensive instructions for setting up and operating the Karlsson KA6044 Cuckoo Light Wall Clock, including battery replacement and maintenance tips.</p>

<div data-bbox="145 107 282 172" data-label="Text"><p>From: Jen@coasterfinefurniture.com</p><p>Analog Alarm Clock, 4 inch Super Silent Non Ticking Small Clock with Night Light, Battery Operated, Simply Design, for Bedroom, Bedside, Desk</p></div> <div data-bbox="150 176 268 264" data-label="Image"></div> <div data-bbox="145 336 282 344" data-label="Text"><p>From: Jen@coasterfinefurniture.com</p></div>	<div data-bbox="341 132 1200 165" data-label="Section-Header"><p>Analog Alarm Clock - Silent, Non-Ticking, Battery Operated with Night Light</p></div> <div data-bbox="341 174 1465 324" data-label="Text"><p>A detailed overview of the 4-inch Analog Alarm Clock. Features include silent, non-ticking operation, a night light, battery operation, and a simple design suitable for bedrooms, bedside tables, and desks. Includes instructions for setup, alarm, and night light usage, along with warranty information.</p></div>
<div data-bbox="116 405 311 667" data-label="Image"></div>	<div data-bbox="341 483 1308 517" data-label="Section-Header"><p>Coaster Fine Furniture 900723 Grandfather Clock Assembly Instructions and Manual</p></div> <div data-bbox="341 526 1455 598" data-label="Text"><p>Complete assembly instructions, parts identification, setting guide, and troubleshooting tips for the Coaster Fine Furniture 900723 Grandfather Clock. Learn how to set up and maintain your clock.</p></div>