

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tribesigns](#) /

› [Tribesigns Computer Desk with 2 Storage Drawers and Monitor Stand Riser \(Model f1146-us-tt\) Instruction Manual](#)

Tribesigns f1146-us-tt

Tribesigns Computer Desk with 2 Storage Drawers and Monitor Stand Riser

Model: f1146-us-tt

[List](#) [Assembly](#) [Operation](#) [Introduction](#) [Safety Information](#) [Parts](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Tribesigns Computer Desk with 2 Storage Drawers and Monitor Stand Riser. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk. This desk is designed to provide a spacious and organized workspace for your home office, study room, or bedroom.



Image 1.1: Tribesigns Computer Desk in a home office setting, showcasing its monitor stand and integrated drawers.

2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure all parts are present and undamaged before beginning assembly. Do not use if any parts are missing or broken.
- Assemble the desk on a soft, clean surface (e.g., carpet) to prevent scratches.
- Always use the correct tools as specified in the assembly instructions.
- Do not overtighten screws, as this may damage the material.
- Keep small parts and packaging materials away from children and pets.
- Ensure the desk is placed on a level surface to prevent wobbling. Use the adjustable leg pads for stability on uneven floors.
- Do not exceed the weight capacity of the desk or monitor stand.

- Periodically check all connections and tighten hardware as needed to maintain stability.

3. PARTS LIST

Before assembly, verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- A.** Desktop Panel with Integrated Drawers (1)
- B.** Monitor Stand Riser (1)
- C.** Left Support Frame (1)
- D.** Right Support Frame (1)
- E.** Bottom Crossbar (1)
- F.** Drawer Fronts (2)
- G.** Drawer Sides (4)
- H.** Drawer Backs (2)
- I.** Drawer Bottoms (2)
- J.** Drawer Slides (4 pairs - 2 for desk, 2 for drawers)
- K.** Adjustable Leg Pads (4)

Hardware List

S1. M6 x 30mm Screws (Quantity: X)

S2. M4 x 15mm Screws (Quantity: Y)

S3. M3 x 10mm Screws (Quantity: Z)

W1. Allen Wrench (1)

W2. Screwdriver (1)

Note: Exact quantities for screws (X, Y, Z) are not provided in the product data. Please refer to your physical instruction manual for precise counts.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Tribesigns Computer Desk. It is recommended to have two people for assembly, especially for lifting heavier components.

Step 4.1: Attach Support Frames to Desktop

1. Carefully place the Desktop Panel (A) upside down on a soft, clean surface.
2. Align the Left Support Frame (C) and Right Support Frame (D) with the pre-drilled holes on the underside of the desktop.
3. Secure the support frames using M6 x 30mm Screws (S1) and the Allen Wrench (W1). Do not fully tighten yet.

Step 4.2: Install Bottom Crossbar

4. Connect the Bottom Crossbar (E) between the lower sections of the Left (C) and Right (D) Support Frames.
5. Secure with M6 x 30mm Screws (S1). Now, fully tighten all screws from Step 4.1 and 4.2.
6. Attach the Adjustable Leg Pads (K) to the bottom of the support frames.

Step 4.3: Assemble Drawers

This step requires careful attention, especially with the drawer slides.

7. Take one Drawer Front (F), two Drawer Sides (G), and one Drawer Back (H). Connect them to form the drawer box.
8. Slide the Drawer Bottom (I) into the grooves of the assembled drawer box.
9. Repeat for the second drawer.
10. **Drawer Slide Installation:** The drawer slides (J) come in two parts: one for the drawer and one for the desk.
 - Separate the two parts of each drawer slide. Look for a small lever or clip to release them.
 - Attach the narrower part of the slide to the sides of the assembled drawers using M3 x 10mm Screws (S3). Ensure they are flush with the drawer front.
 - Attach the wider part of the slide to the pre-drilled holes inside the desk's drawer compartments using M4 x 15mm Screws (S2). Ensure the slides are level and aligned.
 - Carefully align the drawer slides and push the assembled drawers into the desk compartments until they click into place. Test for smooth operation.



Image 4.1: Illustration of the desk's features, including the smooth pull-out drawers with metal rails.

Step 4.4: Install Monitor Stand Riser

11. Place the Monitor Stand Riser (B) onto the designated area on the desktop.
12. Secure it from underneath the desktop using M4 x 15mm Screws (S2) and the Screwdriver (W2).

Your Tribesigns Computer Desk is now assembled. Carefully move it to its desired location and adjust the leg pads for optimal stability.

5. OPERATING INSTRUCTIONS

This section details the proper use of your Tribesigns Computer Desk's features.

5.1 Monitor Stand Riser

The integrated monitor stand riser is designed to elevate your monitor(s) to an ergonomic eye-level, promoting better posture and reducing neck strain. It can accommodate one or two monitors depending on their size. The open compartments beneath the riser provide additional storage for small items like notebooks or office supplies.

5.2 Storage Drawers

The two large storage drawers are ideal for organizing your study and office items, including documents, stationery, and laptops. Pull the drawers gently to open and push firmly to close. Avoid overloading the drawers to ensure smooth operation and prevent damage to the slides.

5.3 Spacious Work Area

The 47-inch L x 23.6-inch W desktop provides ample space for your laptop, keyboard, mouse, and other accessories. Keep the surface clear of excessive clutter to maintain an efficient workspace.

6. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your desk.

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. For stubborn marks, use a mild soap solution and dry immediately. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** The desk surface is designed to be waterproof. In case of spills, wipe them up immediately to prevent any potential damage or staining.
- **Scratch Resistance:** While the surface is scratch-resistant, avoid dragging sharp or heavy objects across it. Use coasters for drinks and protective pads under electronics to prevent marks.
- **Hardware Check:** Periodically (e.g., every 3-6 months) check all screws and bolts to ensure they are tight. Retighten as necessary to maintain the desk's stability.
- **Environmental Conditions:** Avoid placing the desk in direct sunlight or near heat sources, as this can cause material degradation or discoloration over time. Maintain a stable room temperature and humidity.

Spacious Desktop with Elegant Wooden Grain

Provides large storage space for home office supplies



Scratch Resistant



Waterproof



Easy to Clean

Image 6.1: Close-up of the desktop surface highlighting its scratch-resistant, waterproof, and easy-to-clean properties.

7. TROUBLESHOOTING

This section addresses common issues you might encounter and their solutions.

Issue: Desk is wobbly or unstable.

- **Solution 1:** Ensure the desk is on a level surface.
- **Solution 2:** Adjust the leg pads (K) at the bottom of the support frames. Turn them clockwise or counter-clockwise until the desk is stable and all four pads are firmly on the floor.
- **Solution 3:** Check all assembly screws (S1) and ensure they are fully tightened. Overtightening should be avoided, but loose screws can cause instability.

Issue: Drawers do not slide smoothly or get stuck.

- **Solution 1:** Verify that the drawer slides (J) are correctly installed. Ensure the two parts of the slide are properly engaged and that the drawer-side part is flush with the drawer front.

- **Solution 2:** Check that the screws securing the drawer slides to both the drawer and the desk are not overtightened or misaligned. Loose or crooked screws can impede movement.
- **Solution 3:** Ensure the drawers are not overloaded. Remove some items to see if the movement improves.
- **Solution 4:** Inspect the drawer tracks for any obstructions or debris. Clean if necessary.

Issue: Missing parts or damaged components.

- **Solution:** Do not proceed with assembly. Contact Tribesigns customer service immediately with your purchase details and a description of the missing or damaged parts.

8. SPECIFICATIONS

Feature	Detail
Brand	Tribesigns
Model Number	f1146-us-tt
Product Dimensions	119.89 x 59.94 x 89.92 cm (47.2 x 23.6 x 35.4 inches)
Weight	27.95 kg (61.6 lbs)
Material Type	0.59" Particle Board with Wood Grain + Heavy-Duty Metal Frame
Color	Oak Grey
Style	Vintage
Number of Drawers	2
Special Features	Adjustable Leg Pads, Monitor Riser, Storage Drawers
Room Type	Bedroom, Living Room, Office, Study Room




Image 8.1: Dimensional drawing of the Tribesigns Computer Desk, showing overall and component measurements.

9. WARRANTY AND CUSTOMER SUPPORT

Tribesigns offers an 18-month quality assurance for this product. If you encounter any issues or have questions regarding assembly, missing parts, or product functionality, please do not hesitate to contact our customer service team.

Please have your purchase information and model number (f1146-us-**tt**) ready when contacting support to ensure efficient service.

For the most up-to-date contact information, please refer to the Tribesigns official website or your purchase documentation.

