

[Manuals.plus](#) /

> [Brightech](#) /

> Brightech Sky Dome Dimmable LED Floor Lamp (Model FL-DME-BLK) Instruction Manual

## Brightech FL-DME-BLK

# Brightech Sky Dome Dimmable LED Floor Lamp Instruction Manual

Model: FL-DME-BLK

Brand: Brightech

## INTRODUCTION

---

Thank you for choosing the Brightech Sky Dome Dimmable LED Floor Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read these instructions carefully before assembly and operation, and retain them for future reference.



Image: The Brightech Sky Dome Dimmable LED Floor Lamp in Jet Black, showcasing its sleek design and upward-facing light.

## SAFETY INSTRUCTIONS

---

- **Electrical Safety:** Always unplug the lamp from the power outlet before cleaning, changing the bulb, or performing any maintenance. Do not use with a damaged cord or plug.
- **Indoor Use Only:** This lamp is designed for indoor use in dry locations. Do not expose to water or moisture.
- **Stability:** The lamp features a weighted base for stability. Ensure the lamp is placed on a flat, stable surface to prevent tipping. Keep away from areas with high traffic or where it could be easily knocked over by children or pets.
- **Heat:** The integrated LED light source is designed to remain cool to the touch, reducing the risk of burns.
- **Bulb Type:** Use only the specified E26 base A19 LED bulb. Do not exceed the maximum wattage indicated on the lamp.

## PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly:

- Lamp Base
- Multiple Pole Sections (typically 4-5)

- Lamp Head with Rotary Switch
- White Plastic Dome Shade
- A19 LED Bulb (E26 base)

## ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Brightech Sky Dome Floor Lamp:

1. Carefully unpack all components and lay them out on a clean, flat surface.
2. Thread the lowest pole section into the lamp base, turning clockwise until secure. Ensure the power cord passes freely through the pole sections.
3. Continue threading the remaining pole sections together, one by one, ensuring each connection is tight and the cord is not pinched.
4. Attach the lamp head to the top pole section, again turning clockwise until secure.
5. Gently pull any excess power cord from the bottom of the lamp base to ensure a taut fit through the pole sections.
6. Screw the provided A19 LED bulb into the socket in the lamp head.
7. Place the white plastic dome shade over the lamp head, ensuring it rests securely.

## Media Endorsement



 <p><b>Brightech's bugted-friendly options approximate the clean lines and metal-heavy construction of their designer counterpart—minus the nasty sticker shock.</b></p>	<p><b>BUSINESS INSIDER</b></p> <p><b>"If you're looking for inexpensive, modern, lamps that will last you many years, Brightech a great choice."</b></p>	 <p><b>"I truly didn't feel like there was a go-to spot these days for design-friendly lighting for a fraction of the cost, but thanks to Brightech, I know exactly where I'm beelining it to when I need a new light in my space."</b></p>	<p><b>MY DOMAINE</b></p> <p><b>"I've been on the hunt for an affordable, good-looking floor lamp for my living area, and I finally found it at Brightech."</b></p>
---	--	---	--

Image: An exploded view diagram illustrating the assembly sequence of the lamp's pole sections, base, and head.  
For a visual guide, watch the assembly video:

Video: A demonstration of how to easily assemble the Brightech Sky Dome Floor Lamp.

## OPERATING INSTRUCTIONS

Your Brightech Sky Dome Floor Lamp features a convenient 3-way dimmer rotary switch:

1. **Power On:** Plug the lamp into a standard 110V electrical outlet. Rotate the switch clockwise to turn the lamp on to its lowest brightness setting.
2. **Adjust Brightness:** Continue rotating the switch clockwise to cycle through the medium and high brightness

settings.

3. **Power Off:** Rotate the switch counter-clockwise past the lowest setting to turn the lamp off.



Image: A detailed view of the rotary dimmer switch located on the lamp head for easy brightness adjustment. See the dimmer function in action:

Video: A short clip demonstrating the 3-way dimmable feature of the floor lamp.

## MAINTENANCE

---

- **Cleaning:** Always unplug the lamp before cleaning. Use a soft, dry cloth to wipe down the lamp. Avoid abrasive cleaners or solvents that may damage the finish.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled completely before attempting to replace it. This lamp uses a standard E26 base A19 LED bulb.

## TROUBLESHOOTING

---

- **Lamp does not turn on:**
  - Check if the power cord is securely plugged into a working outlet.
  - Ensure the bulb is screwed in tightly.

- Verify the bulb is not burnt out. Replace if necessary.
- **Dimmer function not working:**
  - Ensure you are using a 3-way dimmable LED bulb. Standard LED bulbs may not be compatible with the dimmer function.
  - Check the rotary switch for any obstructions or damage.

## SPECIFICATIONS

<b>Model Number</b>	FL-DME-BLK
<b>Dimensions (H x Base Dia. x Shade Dia.)</b>	72" x 10" x 11"
<b>Item Weight</b>	8.77 pounds (3.99 kg)
<b>Color</b>	Jet Black
<b>Light Source Type</b>	LED
<b>Wattage</b>	16 watts (max)
<b>Color Temperature</b>	3000 Kelvin (Warm White)
<b>Bulb Base</b>	E26
<b>Material</b>	Metal, Plastic
<b>Switch Type</b>	3-Way Dimmer Rotary Switch
<b>Power Source</b>	Corded Electric
<b>Voltage</b>	110 Volts
<b>UPC</b>	850004456828



Image: A diagram detailing the dimensions (72" height, 10" base, 11" shade) and key features of the Sky Dome LED Floor Lamp.

## **WARRANTY AND SUPPORT**

---

Brightech USA offers an industry-leading **3-year warranty** covering defects, malfunctions, or sudden failures to your standing lamp when purchased through authorized channels. For warranty claims or technical support, please refer to the contact information provided with your purchase or visit the official Brightech website.