

STAPLES Ayalon

STAPLES Workplace 2.0 Ayalon Ergonomic Office Desk Chair User Manual

Model: Ayalon

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your STAPLES Workplace 2.0 Ayalon Ergonomic Office Desk Chair. Please read this manual thoroughly before use to ensure proper function and longevity of your chair.

PRODUCT FEATURES

- High-back office chair with breathable mesh backing for enhanced airflow.
- Contoured padded fabric swivel seat for comfort.
- Padded armrests for support.
- Ergonomic design promoting proper posture with good lumbar support.
- Adjustable height, tilt tension, and tilt lock options.
- 3D armrest configuration: arms move up and down, pads move forward, backward, and twist in or out.
- Durable base with 360° swivel casters, supporting up to 275 lbs.



Breathable
mesh back

Integrated lumbar
designed to
support back

Padded
fabric seat

Image: Detail of the chair's breathable mesh back, integrated lumbar support, and padded fabric seat, designed for comfort and support.

SETUP

The STAPLES Workplace 2.0 Ayalon Ergonomic Office Desk Chair comes with all necessary hardware and tools for assembly. Follow the included visual instructions for quick and easy setup. Ensure all components are securely fastened before use.



Image: The fully assembled STAPLES Workplace 2.0 Ayalon Ergonomic Office Desk Chair, ready for use.

OPERATING INSTRUCTIONS

Your Ayalon chair offers multiple adjustments to customize your seating experience for optimal comfort and ergonomic support. Familiarize yourself with these features:

1. Seat Height Adjustment

To adjust the seat height, locate the lever on the right side of the chair, beneath the seat. While seated, pull the lever up to raise the seat. To lower the seat, pull the lever up while applying your weight to the seat. Release the lever to lock the height.

Your browser does not support the video tag.

Video: Demonstrates the seat height adjustment feature of the Ayalon chair. The user pulls a lever to raise or lower the seat to their desired ergonomic position.

2. Seat Slide Adjustment

The seat slide allows you to adjust the depth of the seat. Locate the lever on the left side of the chair, beneath the seat. Pull the lever to unlock the seat, then slide the seat forward or backward to achieve comfortable leg positioning. Release the lever to lock the seat in place.



Image: A diagram illustrating the various dimensions of the chair, including the adjustable seat depth, which can be optimized using the seat slide feature.

3. Tilt Tension Adjustment

Adjust the resistance of the chair's recline by turning the knob located under the front of the seat. Turn clockwise to increase tension (making it harder to recline) and counter-clockwise to decrease tension (making it easier to recline).

4. Tilt Lock/Unlock

To recline, pull the lever on the left side of the chair (the same lever as seat slide) outwards to unlock the tilt mechanism. Lean back to recline. To lock the chair in an upright or reclined position, push the lever inwards. The chair offers multiple tilt positions for varied comfort.

5. Armrest Adjustments (3D Arms)

The 3D armrests provide versatile positioning:

- **Height Adjustment:** Press the button on the side of each armrest and slide the armrest up or down to your desired height. Release the button to lock.
- **Front/Back Adjustment:** Slide the armrest pads forward or backward to find the optimal position for your forearms.
- **Pivot/Twist:** Twist the armrest pads inwards or outwards to support your arms during different tasks.

3D Arms

Arms move up and down, while pads move forward, backward, and twist in or out.



Image: A detailed view of the 3D adjustable armrests, illustrating their ability to move up/down, forward/backward, and pivot for personalized comfort.

MAINTENANCE

To ensure the longevity and appearance of your STAPLES Workplace 2.0 Ayalon Ergonomic Office Desk Chair, follow these simple maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Casters:** Keep the casters free of debris (hair, dust, etc.) to ensure smooth movement on both hardwood and carpet surfaces.

Durable base holds up to 275 lbs.



360° swivel casters

Image: The durable five-star base of the chair, equipped with 360-degree swivel casters, designed for effortless movement across various floor types.

TROUBLESHOOTING

If you encounter any issues with your chair, please refer to the following common solutions:

- **Chair not adjusting height:** Ensure the height adjustment lever is fully engaged and the gas lift cylinder is not damaged.
- **Chair squeaks or wobbles:** Check all assembly bolts and screws and tighten them. Lubricate moving parts if necessary.
- **Casters not rolling smoothly:** Clean any debris from the wheels. Ensure the chair is on a suitable surface.
- **Difficulty reclining:** Adjust the tilt tension knob to a lower setting. Ensure the tilt lock is disengaged.

For persistent issues, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	STAPLES
Model Name	Ayalon
Color	Black
Product Dimensions (D x W x H)	28.5"D x 30"W x 45.7"H
Back Style	Mesh
Seat Fill Material	Foam
Maximum Weight Recommendation	150 Kilograms (330 lbs)
Arm Style	Track (3D Adjustable)
Leg Style	Wheels (360° swivel casters)
Reclining Position Count	4
Item Weight	40 pounds
Date First Available	September 24, 2019

WARRANTY AND SUPPORT

The STAPLES Workplace 2.0 Ayalon Ergonomic Office Desk Chair comes with a**Limited Lifetime Warranty**. For detailed information regarding warranty coverage, claims, or technical support, please refer to the official STAPLES website or contact STAPLES customer service directly.

For additional assistance, you may visit the[STAPLES Store on Amazon](#).

© 2024 STAPLES. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question