

[Manuals.plus](#) /

› [Bose](#) /

› Bose SoundLink Mini II Bluetooth Speaker Special Edition - User Manual

Bose 835799-0100

Bose SoundLink Mini II Bluetooth Speaker Special Edition User Manual

Model: 835799-0100

INTRODUCTION

This manual provides essential information for the safe and effective use of your Bose SoundLink Mini II Bluetooth Speaker Special Edition. Please read it thoroughly before operating the device and retain it for future reference.



Figure 1: Front view of the Bose SoundLink Mini II Bluetooth Speaker Special Edition. The speaker features a black grille and a sleek, compact design.

WHAT'S IN THE BOX

- Bose SoundLink Mini II Bluetooth Speaker Special Edition
- USB-C Charging Cable

SETUP

Charging the Battery

Before first use, fully charge the speaker. The speaker features a USB-C charging port.

1. Connect the small end of the USB-C cable to the USB-C port on the speaker.
2. Connect the other end of the cable to a USB wall charger (not included) or a computer's USB port.
3. The battery indicator light will pulse white during charging and turn solid white when fully charged. A full charge provides up to 12 hours of playtime.



Figure 2: Side view of the speaker, highlighting the USB-C charging port and auxiliary input for wired connections.

Powering On/Off

Press the **Power** button ( - refer to top view image for button location) located on the top panel to turn the speaker on or off. A tone will indicate the power status.

OPERATING THE SPEAKER

Bluetooth Pairing

The SoundLink Mini II can connect wirelessly to Bluetooth-enabled devices such as smartphones, tablets, and laptops.

1. Turn on the speaker. The Bluetooth indicator light will blink blue, indicating it's ready to pair.

2. On your device, enable Bluetooth and select "Bose Mini II SoundLink" from the list of available devices.
3. Once connected, the Bluetooth indicator light will glow solid white, and you will hear a voice prompt confirming the connection.
4. The speaker remembers the last 8 devices it connected to, making reconnection easier.



Figure 3: Top panel controls including Power, Volume Down, Multi-function, Volume Up, and Bluetooth buttons.

Controlling Playback and Volume

- **Volume Buttons (- / +):** Press to decrease or increase the volume.
- **Multi-function Button (•••):**
 - Press once to play/pause audio.
 - Press twice quickly to skip to the next track.
 - Press three times quickly to skip to the previous track.
 - Press and hold to activate your device's voice assistant (e.g., Siri, Google Assistant).

Taking Calls

The speaker has a built-in microphone for hands-free calling.

- **Answer/End Call:** Press the Multi-function button once.
- **Decline Call:** Press and hold the Multi-function button.

MAINTENANCE

Cleaning

- Wipe the surface of the speaker with a soft, dry cloth.
- Do not use any solvents, chemicals, or cleaning sprays.
- Avoid getting moisture into any openings.

Storage

Store the speaker in a cool, dry place away from extreme temperatures and direct sunlight when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Solution
No power	Ensure the speaker is charged. Connect to a power source using the USB-C cable.
Cannot pair via Bluetooth	Ensure the speaker is in pairing mode (blinking blue light). Turn Bluetooth off and on again on your device. Forget "Bose Mini II SoundLink" from your device's Bluetooth settings and try pairing again. Move the speaker closer to your device.
No sound	Increase the volume on both the speaker and your connected device. Ensure the speaker is correctly paired via Bluetooth or connected via auxiliary cable.
Poor audio quality	Move the speaker closer to your device to reduce interference. Avoid placing the speaker near other wireless devices. Try playing audio from a different source or device.

SPECIFICATIONS

- **Model Name:** 835799-0100
- **Dimensions (H x W x D):** 2.31 x 7.06 x 2 inches (5.87 x 17.93 x 5.08 cm)
- **Weight:** 1.56 pounds (0.71 kg)
- **Connectivity:** Bluetooth 3.0, 3.5mm Auxiliary input
- **Wireless Range:** Up to 30 feet (9 meters)
- **Battery Life:** Up to 12 hours
- **Charging Port:** USB-C
- **Included Components:** Speaker, USB-C charging cable

WARRANTY AND SUPPORT

Your Bose SoundLink Mini II Bluetooth Speaker Special Edition comes with a limited warranty. For detailed warranty information, product support, or to contact customer service, please visit the official Bose website or refer to the warranty card included with your product.
Official Bose Website: www.bose.com