

AVERA EV18

AVERA EV18 18-Bottle Thermoelectric Wine Cooler Instruction Manual

Model: EV18 | Brand: AVERA

1. INTRODUCTION

Thank you for choosing the AVERA EV18 18-Bottle Thermoelectric Wine Cooler. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read these instructions thoroughly before use and retain them for future reference.

2. SAFETY INFORMATION

- **Electrical Safety:** Ensure the unit is plugged into a properly grounded electrical outlet. Do not use extension cords or adapters. Disconnect power before cleaning or performing any maintenance.
- **Placement:** Place the wine cooler on a stable, level surface. Ensure adequate ventilation around the unit (at least 10 cm clearance on sides and back). Avoid direct sunlight, heat sources (stoves, heaters), and areas with high humidity.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- **Usage:** This appliance is designed exclusively for storing wine bottles. Do not store perishable food items or other beverages that require different temperature ranges.
- **Temperature Limitations:** Thermoelectric wine coolers perform optimally in moderate ambient temperatures. In environments with high ambient temperatures (e.g., above 25°C), the unit may struggle to maintain very low internal temperatures.

3. PRODUCT OVERVIEW

The AVERA EV18 wine cooler is designed to preserve your wine collection at optimal temperatures. It features a sleek design and user-friendly controls.

Key Features:

- **Capacity:** Stores up to 18 standard wine bottles (50 Liters).
- **Cooling System:** Thermoelectric technology provides quiet, vibration-free cooling, ideal for wine preservation.
- **Control Panel:** Digital touch panel for precise temperature adjustment and control.
- **Door:** Tempered glass door protects wine from harmful UV light.
- **Interior Lighting:** Soft LED light illuminates your collection.
- **Shelving:** Features 4 sliding metal shelves and 1 bottom rack for versatile bottle organization.

Product Components:




Figure 1: Front view of the AVERA EV18 wine cooler with bottles on shelves.

VIVE LA EXPERIENCIA AVERA



Marca 100% mexicana.



Estamos seguros de que estarás satisfecho con tu compra pero en caso de que tengas algún problema, comunícate con nosotros antes de iniciar una devolución.



Servicio técnico con cobertura nacional.



Con tu compra ayudas a programas de reforestación en Chiapas.



Figure 2: Dimensional diagram showing the depth (52 cm), width (34.5 cm), and height (64.5 cm) of the EV18 wine cooler.



Características

Cava de vinos enfriadora para 18 botellas | EV18

Figure 3: Diagram illustrating the main features of the EV18: 18-bottle capacity, silent thermoelectric cooling, LED interior light, digital temperature control (8-18°C), and vibration prevention.

4. SETUP AND INSTALLATION

4.1 Unpacking

Carefully remove all packaging materials, including foam and tape. Inspect the unit for any shipping damage. Keep packaging materials for future transport if needed.

4.2 Placement

- Place the wine cooler on a firm, level floor that can support its weight when fully loaded.
- Ensure at least 10 cm (4 inches) of space on the sides and back of the unit for proper air circulation.
- Avoid placing the unit in direct sunlight or near heat sources such as ovens, radiators, or heating vents. High ambient temperatures can affect cooling performance.
- Do not install in areas with excessive humidity.

4.3 Leveling

The wine cooler has adjustable leveling legs. Turn the legs clockwise to raise the unit or counter-clockwise to lower it until it is perfectly level. Proper leveling is crucial for efficient operation and to prevent vibrations.

4.4 Power Connection

Plug the unit into a dedicated, grounded electrical outlet. Allow the wine cooler to stand upright for at least 24 hours before plugging it in and loading it with bottles. This allows the cooling system fluids to settle.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Overview

The control panel is located on the top front of the unit and features touch-sensitive buttons and a digital display.



Figure 4: Digital touch control panel.

5.2 Temperature Adjustment

1. To adjust the temperature, press the **Settings/Gear** icon (or the **Snowflake/Fan** icon, depending on the model variation) on the control panel. The display will flash.
2. Use the **Up (^)** and **Down (v)** arrows to set your desired temperature. The temperature range for this model is typically 8°C to 18°C (46°F to 64°F).
3. The display will stop flashing after a few seconds, indicating the new temperature setting is active.

5.3 Switching Temperature Units (°C/°F)

To switch between Celsius (°C) and Fahrenheit (°F), press and hold the **Settings/Gear** icon for approximately 3 seconds until the display changes units.

5.4 Internal LED Light Control

Press the **Light Bulb** icon on the control panel to turn the interior LED light on or off.

5.5 Loading Bottles

Carefully place your wine bottles on the metal shelves. The shelves are designed to accommodate standard-sized wine bottles. The bottom rack can be used for larger bottles or additional storage. Ensure bottles are placed securely to prevent rolling or damage.

5.6 Video Demonstrations

Your browser does not support the video tag.

Video 1: Official AVERA video demonstrating the wine cooler and its temperature preservation features.

Your browser does not support the video tag.

Video 2: General overview of elegant wine coolers, showcasing features and usage.

6. MAINTENANCE

6.1 Cleaning

- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. For stubborn stains, use a mild, non-abrasive cleaner.
- **Interior:** Clean the interior with a soft cloth dampened with a solution of mild detergent and warm water. Rinse thoroughly and dry completely before reloading bottles.
- **Shelves:** Remove the metal shelves and wash them with mild soap and water. Dry them completely before placing them back in the unit.
- **Door Seal:** Regularly clean the door gasket to ensure a tight seal, which is essential for efficient cooling.

6.2 Defrosting

The AVERA EV18 wine cooler features a frost-free system, minimizing ice buildup. If any significant ice accumulation occurs, unplug the unit, open the door, and allow the ice to melt naturally. Wipe away excess water and dry the interior thoroughly before restarting the unit.

6.3 Power Outage

In case of a power outage, keep the wine cooler door closed to help maintain the internal temperature for as long as possible. Avoid opening the door unnecessarily.

7. TROUBLESHOOTING

Before contacting customer service, please review the following common issues and solutions:

Problem	Possible Cause	Solution
Unit does not operate	No power; unit unplugged; circuit breaker tripped.	Check power supply, ensure plug is secure, reset circuit breaker.
Unit is not cooling sufficiently	Temperature set too high; door not closed properly; excessive door openings; poor ventilation; high ambient temperature.	Lower temperature setting; ensure door is sealed; reduce door openings; ensure adequate clearance for ventilation; consider ambient room temperature.

Problem	Possible Cause	Solution
Excessive noise	Unit not level; bottles vibrating against each other; fan obstruction.	Adjust leveling legs; rearrange bottles; check for fan obstructions.
Water on floor (condensation)	High humidity; door left open; drain hole blocked.	Ensure door is closed; clean drain hole if present (refer to diagram in full manual).

8. SPECIFICATIONS

Feature	Specification
Model Number	EV18
Capacity	18 Bottles / 50 Liters
Dimensions (D x W x H)	52 x 34.5 x 64.5 cm
Weight	18.52 kg
Cooling Technology	Thermoelectric
Temperature Range	8°C - 18°C (46°F - 64°F)
Shelves	4 Sliding Metal Shelves + 1 Bottom Rack
Door Material	Tempered Glass, Stainless Steel Frame
Defrost System	Frost-free
Color	Black

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This AVERA EV18 wine cooler comes with a 1-year limited warranty from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper installation, misuse, accidents, or unauthorized repairs.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your AVERA EV18 wine cooler, please contact AVERA customer service. Refer to your purchase documentation or the AVERA website for specific contact details.