

Flamaker B07YCL3BL5

Flamaker Modern Rectangular Patio Furniture Set User Manual

Model: B07YCL3BL5

Brand: Flamaker

1. IMPORTANT SAFETY INFORMATION

Please read and understand all safety information before assembling or using this product. Failure to follow these instructions may result in injury or damage to the product.

- Always secure furniture to the wall or floor to prevent tipping.
- Read and follow assembly instructions carefully.
- Inspect furniture regularly for any damage or wear and tear.
- Keep away from children when assembling or disassembling.
- Do not exceed the weight capacity of 330 pounds per seating unit.
- Avoid placing hot items directly on the tempered glass table surface without protection.

2. PRODUCT OVERVIEW

The Flamaker Modern Rectangular Patio Furniture Set is designed to enhance your outdoor living space with comfort and style. This set includes a coffee table, a double chair (loveseat), and two single chairs, perfect for family leisure or entertaining guests.

Key features include a sturdy, weather-resistant handwoven PE rattan wicker construction over a strong powder-coated steel frame. The design incorporates anti-slip mats for stability and floor protection, widened armrests for comfort, and thickened cushions for enhanced seating experience. The tempered glass tabletop is removable for easy cleaning.



Image 2.1: The complete Flamaker Modern Rectangular Patio Furniture Set, featuring a double chair, two single chairs, and a coffee table, arranged on an outdoor patio with a scenic mountain backdrop.

Product Features

- **Sturdy and Durable:** Constructed with weather-resistant handwoven PE rattan wicker and a strong powder-coated steel frame. The triangular design at the bottom of the chairs enhances stability.
- **Comfortable Seating:** Features breathable PE rattan wicker backs and thick sponge cushions for both back and seat, ensuring comfort even in warm weather.
- **Convenient to Clean:** Smooth, waterproof rattan wicker and removable, washable cushion covers simplify maintenance.
- **Widened Armrests:** 3.15-inch armrests provide ample space for relaxation and prevent accidental slipping.
- **Anti-slip Mat Design:** Prevents skidding and protects floors from scratches.




Image 2.2: Detailed view highlighting the widened armrest for comfort, the cross-structure design for enhanced frame stability, and the thickened cushion for improved seating comfort.



Image 2.3: Detailed view illustrating the non-slip mat at the base of the furniture, the waterproof quality of the rattan material, and a powerful suction cup for securing the table's glass top.

3. PACKAGE CONTENTS

Upon opening the package, please verify that all components listed below are present and undamaged.

- 1 x Coffee Table with Tempered Glass Top
- 1 x Double Chair (Loveseat)
- 2 x Single Chairs
- Cushions for all seating units
- Assembly Hardware (bolts, washers, wrench - typically included)

Note: The exact number and type of hardware may vary slightly. Refer to the specific assembly diagram included in your product box.

4. ASSEMBLY INSTRUCTIONS

Assembly of the Flamaker Patio Furniture Set is designed to be straightforward. It is recommended to assemble the furniture on a soft, clean surface to prevent scratches. Two people are recommended for easier assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a protected surface. Check against the package contents list to ensure all pieces are present.
2. **Identify Parts:** Familiarize yourself with the different frame pieces, rattan panels, and hardware. Refer to the assembly diagram provided in your product box for specific part identification.
3. **Assemble Chairs:**
 - Attach the backrest to the seat frame using the provided bolts and washers. Do not fully tighten bolts yet.
 - Connect the side panels (armrests) to the seat and backrest.
 - Once all parts are loosely connected, gently place the chair on a flat surface and gradually tighten all bolts evenly until secure. Avoid over-tightening.

- Repeat for the remaining single chair and the double chair.

4. Assemble Coffee Table:

- Attach the legs to the table frame.
- Ensure all connections are secure, then place the tempered glass top onto the table frame. The powerful suckers (if included) will help secure the glass.

5. Add Cushions: Place the thickened cushions onto the assembled chairs.

For detailed visual instructions, please refer to the assembly manual or diagrams included in your product packaging. If any parts are missing or damaged, please contact customer support.

5. USAGE GUIDELINES

To ensure the longevity and safe use of your Flamaker Patio Furniture Set, please observe the following guidelines:

- **Placement:** Position the furniture on a flat, stable surface. While weather-resistant, prolonged exposure to extreme weather conditions (heavy rain, snow, direct intense sunlight) may affect its lifespan. Consider using a furniture cover when not in use for extended periods.
- **Weight Capacity:** Do not exceed the stated weight capacity of 330 pounds per seating unit.
- **Glass Tabletop:** Avoid placing excessively hot or heavy objects directly on the tempered glass tabletop. Use coasters or placemats to protect the surface.
- **Movement:** When moving the furniture, lift it rather than dragging to prevent damage to the legs or frame and to protect your flooring.
- **Children and Pets:** Supervise children and pets around the furniture to prevent accidents.

6. MAINTENANCE AND CARE

Regular maintenance will help preserve the appearance and extend the life of your patio furniture set.

- **Cleaning Rattan and Frame:** Wipe with a damp cloth to remove dust and dirt. For more stubborn stains, use a mild soap solution and rinse thoroughly with water. Ensure the furniture is completely dry before storing or covering.
- **Cushion Care:** The cushion covers are removable and can be cleaned. Follow the care instructions on the cushion labels, typically machine wash cold on a gentle cycle and air dry. Do not bleach.
- **Glass Tabletop:** Clean the tempered glass with a standard glass cleaner and a soft cloth. The glass is removable for easier cleaning.
- **Hardware Check:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Winter Storage:** During off-season or harsh weather, it is recommended to store the furniture indoors or cover it with a waterproof outdoor furniture cover to protect it from elements.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your patio furniture set.

- **Issue: Furniture feels wobbly after assembly.**
Solution: Ensure all bolts are tightened evenly. Sometimes, tightening bolts while the furniture is on an uneven surface can cause wobbling. Loosen all bolts slightly, place the furniture on a flat surface, apply

gentle pressure to each corner, and then re-tighten all bolts securely.

- **Issue: Rattan appears faded or damaged.**

Solution: While the rattan is weather-resistant, prolonged exposure to direct sunlight can cause fading over time. Consider using a UV-protective spray designed for outdoor furniture or covering the furniture when not in use. For minor damage, repair kits for rattan furniture may be available.

- **Issue: Cushions are getting wet or dirty quickly.**


Solution: The cushions are designed for outdoor use but are not fully waterproof. Bring cushions indoors during heavy rain or when not in use. Regularly clean cushion covers as per maintenance instructions.

If you encounter issues not listed here or require further assistance, please contact Flamaker customer support.

8. PRODUCT SPECIFICATIONS

Detailed specifications for the Flamaker Modern Rectangular Patio Furniture Set.

Specification	Detail
Brand	Flamaker
Model Number	B07YCL3BL5
Color	Black (Rattan), Beige (Cushions)
Frame Material	Steel (Powder Coated)
Rattan Material	PE Rattan
Coffee Table Dimensions (W x D x H)	20.1 inches (W) x 35.2 inches (D) x 14.9 inches (H)
Single Chair Dimensions (W x D x H)	27.4 inches (W) x 27.4 inches (D) x 31.5 inches (H)
Double Chair Dimensions (W x D x H)	27.4 inches (W) x 50.9 inches (D) x 31.5 inches (H)
Overall Package Dimensions (L x W x H)	45.3 x 28 x 13 inches (Approximate shipping dimensions)
Item Weight	115.8 pounds (Total package weight)
Weight Capacity	330 pounds per seating unit
Product Care Instructions	Wipe with Damp Cloth



Single Chair



Table



Loveseat




Image 8.1: Dimensional diagram illustrating the width, depth, and height measurements for the coffee table, single chair, and double chair components of the Flamaker patio furniture set.

9. WARRANTY AND CUSTOMER SUPPORT

Flamaker is committed to providing high-quality products. While specific warranty details are not provided in this manual, most products come with a limited manufacturer's warranty covering defects in materials and workmanship.

For warranty claims, missing parts, assembly assistance, or any other product-related inquiries, please contact Flamaker customer support through the retailer where the product was purchased or visit the official Flamaker website for contact information.

Please retain your purchase receipt as proof of purchase for any warranty claims.