HJM NOOR 750

HJM Noor 750 Electric Aluminum Towel Rail User Manual

Model: NOOR 750

1. Introduction

Thank you for choosing the HJM Noor 750 Electric Aluminum Towel Rail. This appliance is designed to provide rapid heating and maximum comfort in your bathroom, ensuring your towels are always dry and warm. Featuring an intuitive digital thermostat and fluid-free technology, it offers efficient and safe operation. Its elegant white design seamlessly integrates into both classic and modern bathroom environments.



Figure 1: HJM Noor 750 Electric Aluminum Towel Rail, front view.

2. Important Safety Information

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in

electric shock, fire, or serious injury.

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not install the towel rail directly above or too close to a bathtub, shower, or swimming pool. Maintain a safe distance from water sources.
- This appliance is for indoor use only.
- Do not cover the towel rail with clothing or other materials while it is operating, as this may cause overheating.
- Keep children and pets away from the appliance during operation.
- Always disconnect the power supply before cleaning or performing any maintenance.
- Do not operate the appliance with a damaged cord or plug. Contact qualified service personnel for repairs.
- The appliance is designed for wall mounting. Ensure it is securely fixed using the provided mounting kit.
- This product is manufactured from high-quality aluminum, which is resistant to corrosion in humid bathroom environments.

3. Package Contents

Verify that all components are present in the package:

- 1 x HJM Noor 750 Electric Towel Rail
- 1 x Set of Wall Mounting Brackets
- 1 x Simple Template for Installation
- User Manual (this document)

4. Setup and Installation

The HJM Noor 750 is designed for easy wall mounting. Follow these steps for secure installation:

1. **Choose Location:** Select a suitable wall location in your bathroom, ensuring it is away from direct water spray and has access to a power outlet. Consider the dimensions of the unit (110 cm height, 50.5 cm width, 10 cm depth) for optimal placement.
2. **Mark Drilling Points:** Use the provided simple template to mark the drilling points on the wall for the mounting brackets. Ensure the marks are level and accurately spaced.
3. **Drill Holes:** Drill holes at the marked points using an appropriate drill bit for your wall type.
4. **Insert Wall Plugs:** Insert the wall plugs (if required for your wall type) into the drilled holes.
5. **Attach Brackets:** Securely attach the wall mounting brackets to the wall using screws.
6. **Mount Towel Rail:** Carefully lift the towel rail and align its mounting points with the installed wall brackets. Secure the towel rail to the brackets.
7. **Connect Power:** Plug the towel rail into a grounded electrical outlet (230 Volts).




Figure 2: Product dimensions for installation reference (110 cm height, 50.5 cm width, 10 cm depth).

5. Operating Instructions

The HJM Noor 750 features an intuitive digital chrono-thermostat for easy programming and control of your bathroom

heating and towel drying needs.



Figure 3: Digital Chrono-thermostat control panel.

5.1. Control Panel Overview

- **Display:** Shows current temperature, time, and active mode.
- **Power Button:** Turns the unit On/Off.
- **Mode Button:** Cycles through different operating modes (Comfort, Economic, Anti-freeze, Timer 2h, Chrono, Standby).
- **Temperature Adjustment Buttons (+/-):** Adjusts the desired temperature setting.
- **Programming Button:** Accesses daily/weekly programming settings.

5.2. Operating Modes

The towel rail offers several operating modes to suit your needs:

- **Comfort Mode:** Maintains a comfortable temperature setting, ideal for when the bathroom is in use.
- **Economic Mode:** Operates at a lower, energy-saving temperature, suitable for maintaining warmth when the bathroom is not actively used.
- **Anti-freeze Mode:** Prevents the room temperature from dropping below a certain point (e.g., 7°C), protecting against freezing.
- **Timer 2h (Turbo) Mode:** Provides immediate, intense heat for a duration of 2 hours, perfect for quickly warming the bathroom or drying towels.
- **Chrono Mode:** Allows for daily/weekly programming, enabling you to customize heating schedules with specific on/off times and temperature settings.
- **Standby Mode:** The unit is powered on but not actively heating.

5.3. Special Features

- **Open Window Detector:** The appliance can detect sudden drops in temperature caused by an open window. When detected, it temporarily suspends heating to save energy. Heating resumes automatically once the window is closed or after a set period.



Figure 4: Open Window Detector feature icon.

- **Keypad Lock (Child Lock):** This feature prevents accidental changes to settings. To activate/deactivate, refer to the specific instructions in the full manual (usually involves pressing and holding a combination of buttons).



Figure 5: Keypad Lock feature icon.

6. Maintenance

Regular maintenance ensures the longevity and efficient operation of your HJM Noor 750 towel rail.

- **Cleaning:** Before cleaning, always unplug the appliance from the power outlet and allow it to cool down completely. Wipe the surface with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Inspection:** Periodically check the power cord and plug for any signs of damage. Ensure the wall mounting remains secure.
- **Storage:** If storing the appliance for an extended period, ensure it is clean and dry. Store it in a cool, dry place, protected from dust.

7. Troubleshooting

If you encounter any issues with your towel rail, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	No power supply; power cord not properly plugged in; circuit breaker tripped.	Check if the appliance is plugged in correctly. Verify the power outlet is functional. Check your household circuit breaker.
No heat output.	Incorrect mode selected; temperature setting too low; Open Window Detector activated.	Ensure a heating mode (e.g., Comfort, Turbo) is selected. Increase the temperature setting. Check if a window is open and close it.
Display shows an error code.	Internal malfunction or sensor issue.	Unplug the unit for a few minutes, then plug it back in. If the error persists, contact customer support.
Keypad is unresponsive.	Keypad lock (child lock) is activated.	Deactivate the keypad lock. Refer to the full manual for specific instructions on how to do this.

8. Technical Specifications

Feature	Specification
Brand	HJM
Model Number	NOOR 750
Dimensions (L x W x H)	10 x 50.5 x 110 cm (3.9 x 19.9 x 43.3 inches)
Weight	5 kg (11 lbs)
Color	White
Material	Aluminum
Power Source	Electric
Voltage	230 Volts
Power Output	750 Watts
Heating Method	Radiant
Mounting Type	Wall Mount
Special Features	Digital Display, Energy Efficiency, Adjustable Temperature, Programmable Thermostat, Child Lock (Keypad Lock), Open Window Detector
Recommended Use	Heating towels and bathroom environment
Country of Manufacture	Spain

9. Warranty and Support

HJM products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or spare parts availability, please refer to the warranty card included with your purchase or visit the official HJM website. Spare parts are generally available for up to 10 years.

If you require assistance with installation, operation, or troubleshooting beyond the scope of this manual, please contact HJM customer service or your authorized dealer.

For the latest information and support, please visit:www.hjm.es

© 2024 HJM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question