

[Manuals.plus](#) /

› [LITFAD](#) /

› LITFAD Antique Lantern Pendant Lighting Rattan Ceiling Fixture LT516915 User Manual

LITFAD LT516915

LITFAD Antique Lantern Pendant Lighting Rattan Ceiling Fixture LT516915 User Manual

Model: LT516915

INTRODUCTION

This manual provides comprehensive instructions for the safe installation, operation, and maintenance of your LITFAD Antique Lantern Pendant Lighting fixture, Model LT516915. Please read this manual thoroughly before proceeding with installation or use to ensure proper function and safety.

The LITFAD Antique Lantern Pendant Lighting is a 23.5-inch (60 cm) ceiling fixture crafted from rattan and wood, designed to provide ambient lighting in various indoor settings such as dining rooms, living rooms, and restaurants. It features an adjustable cord for customizable hanging height.



Image: The LITFAD Antique Lantern Pendant Lighting fixture, showcasing its woven rattan design and overall form.

SAFETY INFORMATION

- **WARNING:** To avoid electric shock, ensure power is turned off at the circuit breaker or fuse box before installation, servicing, or changing bulbs.

- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Use only the specified bulb type and wattage. Exceeding the maximum wattage may cause overheating and damage to the fixture or create a fire hazard.
- Do not install this fixture in wet or damp locations. It is designed for indoor use only.
- Handle the fixture with care. Avoid dropping or subjecting it to strong impacts.
- Keep flammable materials away from the light source.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, contact customer support.

- Rattan Pendant Shade (1)
- Ceiling Canopy (1)
- Adjustable Cord with Wiring (1)
- Mounting Hardware (screws, wire connectors, etc.)
- Instruction Manual (this document)

SETUP AND INSTALLATION

Tools Required (Not Included): Screwdriver, Wire Strippers, Pliers, Electrical Tape, Ladder.

Step 1: Prepare for Installation

1. **Turn off power:** Locate the circuit breaker or fuse box that controls the power to the light fixture location. Turn off the power completely. Verify the power is off using a voltage tester.
2. **Remove existing fixture:** Carefully remove any existing light fixture from the ceiling junction box. Disconnect all wiring.

Step 2: Adjust Cord Length

The pendant light features an adjustable cord. Determine the desired hanging height before proceeding. The cord length can be adjusted by pushing the cord through the canopy. Secure the cord at the desired length within the canopy mechanism.




Image: Diagram illustrating the fixture's dimensions, including the 23.5-inch width, 10-inch height, and 39-inch adjustable cord length.

Step 3: Mount the Ceiling Canopy

1. Attach the mounting bracket (if separate) to the ceiling junction box using the provided screws. Ensure it is securely fastened.
2. Thread the fixture wires through the center hole of the mounting bracket and ceiling canopy.



Image: A detailed view of the black ceiling canopy, showing where the adjustable cord exits the fixture.

Step 4: Wire the Fixture

1. Connect the fixture's wires to the house wires using the provided wire connectors.
2. Connect the **black** fixture wire to the **black** (hot) house wire.
3. Connect the **white** fixture wire to the **white** (neutral) house wire.
4. Connect the **ground** wire (usually bare copper or green) from the fixture to the **ground** wire from the house.
5. Carefully tuck all wires into the junction box.

Step 5: Secure the Fixture

1. Push the ceiling canopy up against the ceiling, covering the junction box.
2. Secure the canopy to the mounting bracket using the provided screws or fasteners.

Step 6: Install the Bulb

1. Screw one E27/E26 base bulb (not included) into the socket. Ensure the bulb wattage does not exceed 40W.

Step 7: Restore Power

1. Turn the power back on at the circuit breaker or fuse box.
2. Test the light fixture to ensure it functions correctly.

OPERATING INSTRUCTIONS

Once installed, the LITFAD Antique Lantern Pendant Lighting operates like any standard ceiling fixture. Control the light using a wall switch connected to the fixture's circuit. This fixture is compatible with LED, incandescent, and fluorescent bulbs with an E27/E26 base, up to a maximum of 40 watts.



Image: A close-up view of the fixture's woven rattan exterior and the white parchment paper diffuser inside, which softens the light.

MAINTENANCE

Cleaning

- Always turn off the power to the fixture before cleaning.
- Wipe the rattan and metal surfaces with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- Avoid getting moisture directly on electrical components.

Bulb Replacement

- Ensure the power is off and the bulb has cooled before attempting to replace it.
- Unscrew the old bulb counter-clockwise.
- Screw in a new E27/E26 base bulb, ensuring it does not exceed 40 watts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on	1. Power is off 2. Loose wiring connection 3. Faulty bulb	1. Check circuit breaker/fuse 2. Verify all wire connections are secure (power off first) 3. Replace bulb

Problem	Possible Cause	Solution
Light flickers	1. Loose bulb 2. Incorrect bulb type/wattage 3. Loose wiring	1. Tighten bulb 2. Ensure bulb is compatible and within wattage limits 3. Check wiring connections (power off first)
Fixture appears unstable	Mounting hardware not secure	Ensure mounting bracket and canopy are tightly secured to the ceiling junction box.

SPECIFICATIONS

Feature	Detail
Brand	LITFAD
Model Number	LT516915
Fixture Width	23.5 inches (60 cm)
Fixture Height	10 inches (25 cm)
Chain/Cord Length	39 inches (100 cm), Adjustable
Material	Metal, Bamboo, White Parchment Paper
Bulb Base	E27/E26
Number of Lights	1
Max Wattage	40W
Voltage	110 Volts
Light Source Type	LED/Incandescent/Fluorescent (Bulb Not Included)
Indoor/Outdoor Usage	Indoor
Item Weight	2.42 pounds (1.1 kg)

WARRANTY AND SUPPORT

Warranty

This LITFAD product comes with a **2-year warranty** from the date of purchase, covering manufacturing defects. This warranty does not cover damage caused by improper installation, misuse, accidents, or normal wear and tear. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, missing parts, or warranty inquiries, please contact LITFAD customer support through the retailer where the product was purchased. Provide your model number (LT516915) and a detailed description of the issue to expedite service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07YD2ZD2D>

More documents and user manuals: <https://manuals.plus/>