

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Soundcore](#) /

› Soundcore Trance Bluetooth Speaker User Manual

## Soundcore A3393011

# Soundcore Trance Bluetooth Speaker Instruction Manual

Model: A3393011

## INTRODUCTION

The Soundcore Trance Bluetooth Speaker is designed to deliver powerful, immersive sound with dynamic lighting effects, suitable for outdoor environments. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your speaker.

## PRODUCT OVERVIEW



The Soundcore Trance speaker features a robust design with integrated LED lights and a convenient carry handle, making it ideal for portable use.

## WHAT'S IN THE BOX

- Soundcore Trance Bluetooth Speaker
- AC Power Adapter
- User Manual

## KEY FEATURES

- **101dB Sound:** A 5.25-inch woofer, 2-inch tweeter, and a passive radiator deliver powerful audio.
- **BassUp Technology:** Real-time analysis and enhancement of bass frequencies for a powerful sonic punch.
- **IPX7 Waterproof:** Fully sealed against liquids, making it suitable for outdoor and poolside use.
- **Beat-Driven Light Show:** LEDs sync to the beat with an independent DSP and custom Party Lighting algorithm.
- **Soundcore App:** Access Indoor and Outdoor sound modes, LightDJ for light show customization, and party games.
- **Portable Build:** Features a built-in flexible handle for easy transportation.
- **18-Hour Playtime:** Extended listening from a single charge.
- **Wireless Stereo Pairing:** Connect two Trance speakers for double the volume or stereo sound.
- **Charge Your Devices:** Built-in USB port to charge external devices.
- **Dual Phone Connection:** Connect two devices simultaneously to switch between playlists.
- **Bluetooth 5:** Fast, ultra-stable connection for skip-free sound.

## SETUP

1. **Unpack:** Carefully remove the speaker and all accessories from the packaging.
2. **Charge:** Before first use, fully charge the speaker using the provided AC power adapter. The charging time is approximately 4.5 hours.
3. **Power On:** Press and hold the power button on the top panel until the LED indicators light up.

## OPERATING INSTRUCTIONS

### Power On/Off

- Press and hold the power button ( ) on the top panel to turn the speaker on or off.

### Bluetooth Pairing

1. Turn on the Soundcore Trance speaker. The Bluetooth indicator will flash blue, indicating it's in pairing mode.
2. On your mobile device, enable Bluetooth and select "Soundcore Trance" from the list of available devices.
3. Once connected, the Bluetooth indicator will turn solid blue.

### Soundcore App Usage

Download the Soundcore app from your device's app store to unlock full features and customization options.

# SOUNDCORE APP

Use LightDJ to customize the light show and add sound effects.



The Soundcore App allows for advanced control over sound modes, lighting, and party games.

## Light Modes

The speaker features a beat-driven light show. You can control the light modes via the Soundcore App or directly from the speaker's control panel.

# BEAT-DRIVEN LIGHT SHOW



Dynamic LED lights synchronize with your music, creating an engaging visual experience.

## **BassUp Technology**

Activate BassUp technology for enhanced bass performance. This can be toggled on/off via the Soundcore App or the dedicated 'Bass' button on the speaker.

# EXTREME BASS

Exclusive BassUp technology and an oversized passive radiator intensifies the low frequencies.



BassUp technology analyzes and intensifies your audio's bass frequencies in real-time.

## Wireless Stereo Pairing

Connect two Soundcore Trance speakers for a true wireless stereo experience. Follow the instructions in the Soundcore App for seamless pairing.

## Charging Devices

Use the built-in USB port (5V 2.4A Max) on the rear panel to charge your mobile devices.

## Dual Phone Connection

Connect two Bluetooth devices to the speaker simultaneously to easily switch between music sources.

## Video Demonstration

Official product video demonstrating features and sound performance of the Soundcore Trance speaker.

## MAINTENANCE

- Clean the speaker with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.
- Ensure the charging port cover is securely closed when not in use to maintain IPX7 waterproof rating.
- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

- **No Power:** Ensure the speaker is fully charged.
- **No Sound:** Check the volume level on both the speaker and your connected device. Ensure the speaker is properly paired via Bluetooth.
- **Connectivity Issues:** Move the speaker closer to your device and away from potential interference sources. Try unpairing and re-pairing the device.
- **Distortion at High Volume:** Reduce the volume level. Playtime may vary depending on volume and whether lights/BassUp mode are used.

## SPECIFICATIONS

Model Number	A3393011
Output Power	80 W (PEAK)
Battery Capacity	4900 mAh / 7.4 V
Playtime	18 hours (varies by volume/features)
Charging Time	4.5 hours
Waterproof Level	IPX7
Bluetooth Version	5.0
Bluetooth Range	20 m / 66 ft
Dimensions	7.5"D x 13.35"W x 6.97"H
Item Weight	7.72 Pounds

## WARRANTY AND SUPPORT

The Soundcore Trance Bluetooth Speaker comes with a Limited Warranty. For detailed warranty information or technical support, please visit the official Soundcore website or contact customer service.

**Website:** [www.soundcore.com](http://www.soundcore.com)

**Email:** [support@soundcore.com](mailto:support@soundcore.com)