

ALLIMITY SHW/RMC/0103

ALLIMITY SHW/RMC/0103 Replacement Remote Control User Manual

For Sharp Aquos LCD LED Smart TVs

1. INTRODUCTION

This ALLIMITY SHW/RMC/0103 replacement remote control is designed to function seamlessly with a wide range of Sharp Aquos LCD LED Smart TV models. It serves as a direct replacement, eliminating the need for complex programming or setup procedures. The remote is engineered to replicate all original remote functions, ensuring reliable performance and an effective transmission range.

Compatible models include, but are not limited to: LC-32HG3141K, LC-32HG3241K, LC-32HG3341K, LC-40CFE4040E, LC-40CFE4041E, LC-40CFE4041K, LC-40CFE4042E, LC-40CFF4041K, LC-40FG3141K, LC-40FG3241K, LC-40FG3341K, LC-43CFE4140E, LC-43CFE4141E, LC-43CFE4142E, LC-48CFE4041E, LC-48CFE4041K, LC-48CFE4042E, LC-48CFE4042K, LC-49CFE4041E, LC-49CFE4042E, LC-22CFE4000ES, LC-22CFE4012E, LC-22CFE4012ES, LC-22CFF4011E, LC-22CFF4011ES, LC-22CFF4012E, LC-22CFF4012ES, LC-22DFE4011K, LC-22DFF4011E, LC-22DFF4011ES, LC-24CHE4000E, LC-24CHE4000ES, LC-24CHE4012E, LC-24CHE4012ES, LC-24CHF4011E, LC-24CHF4011ES, LC-24CHF4011K, LC-24CHF4012E, LC-24CHF4012ES, LC-24DHE4011K, LC-24DHF4011E, LC-24DHF4011ES, LC-24DHF4011K, LC-32CHE4041K, LC-32CHF4041K, LC-32DHE4041K, LC-32DHF4041K.





Figure 1: Front view of the ALLIMITY SHW/RMC/0103 Replacement Remote Control.

2. SETUP

2.1 Battery Installation

The remote control requires two AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.

2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote is ready for use without any additional programming.

Video 1: Demonstration of battery installation for a similar remote control. This video illustrates the process of opening the battery compartment, inserting batteries, and closing the cover.

3. OPERATING INSTRUCTIONS

The ALLIMITY SHW/RMC/0103 remote control is designed for intuitive operation. Simply point the remote at your Sharp Aquos TV and press the desired button. Ensure there are no obstructions between the remote and the TV's infrared (IR) receiver.



Figure 2: Angled view of the ALLIMITY SHW/RMC/0103 Replacement Remote Control, highlighting button layout.

3.1 Key Functions

- **ON/OFF (Power):** Turns the TV on or off.
- **MUTE:** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** Selects channels directly.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes channels sequentially.
- **MENU:** Accesses the TV's main menu.
- **SOURCE:** Selects input sources (HDMI, AV, etc.).
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **EXIT:** Exits the current menu or function.
- **TV GUIDE:** Displays the electronic program guide.
- **P.MODE (Picture Mode):** Adjusts picture settings.
- **S.MODE (Sound Mode):** Adjusts sound settings.
- **FAV:** Accesses favorite channels.
- **INFO:** Displays information about the current program.
- **TEXT:** Activates teletext.
- **SUBTITLE:** Toggles subtitles on/off.
- **NETFLIX, YouTube:** Direct access buttons for streaming services.
- **DVD/PVR Buttons:** Controls for DVD playback and PVR functions (if supported by your TV).

Video 2: Overview of the Sharp Aquos remote control. This video demonstrates the physical appearance and general handling of the remote.

4. MAINTENANCE

To ensure optimal performance and longevity of your remote control, follow these maintenance guidelines:

- **Cleaning:** Clean the remote with a soft, dry cloth. Avoid using liquid cleaners, abrasive materials, or solvents, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always use new alkaline batteries of the specified type (AAA). Do not mix old and new batteries, or different types of batteries.
- **Storage:** Do not expose the remote to extreme temperatures, high humidity, or direct sunlight. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Handling:** Avoid dropping the remote or subjecting it to strong impacts, which can damage internal circuitry.

5. TROUBLESHOOTING

If you experience issues with your remote control, refer to the following troubleshooting tips:

- **Remote not responding:**
 - Check battery orientation and ensure batteries are fresh. Replace them if necessary.
 - Point the remote directly at the TV's IR receiver.
 - Remove any obstructions between the remote control and the TV.
 - Ensure the TV is powered on.
- **Limited range or intermittent response:**
 - Replace batteries with new ones.
 - Ensure there are no strong light sources (like direct sunlight or fluorescent lights) interfering with the IR signal.
 - Verify that the remote control's IR emitter is not blocked or dirty.

- **Specific buttons not working:**
 - Clean the remote control, especially around the problematic buttons, to remove any debris that might be preventing proper contact.
 - If only a few buttons are unresponsive after trying new batteries and cleaning, the remote may be damaged and require replacement.

6. SPECIFICATIONS

Model	SHW/RMC/0103
Brand	ALLIMITY
Dimensions	4 x 0.9 x 19 cm
Weight	80 g
Battery Type	AAA Alkaline (not included)
Connectivity Technology	Infrared
Number of Buttons	45
Maximum Range	10 meters
Compatible Devices	Sharp Aquos LCD LED Smart TVs (various models, see Introduction)

7. WARRANTY AND SUPPORT

For specific warranty information regarding your ALLIMITY SHW/RMC/0103 replacement remote control, please refer to the purchase documentation or the seller's policy. If you require further assistance or have questions not covered in this manual, please contact ALLIMITY customer service or the retailer from whom you purchased the product.