

BONTEC ST13

BONTEC Universal TV Stand ST13 Instruction Manual

Model: ST13 | For 26-65 Inch LCD/LED/Plasma TVs

1. PRODUCT OVERVIEW

The BONTEC Universal TV Stand ST13 is designed to provide a stable and adjustable mounting solution for a wide range of televisions. This stand is compatible with most LCD, LED, OLED, QLED, and Plasma TVs ranging from 26 to 65 inches.

Key features include:

- **Compatibility:** Supports VESA patterns from 75x75mm up to 600x400mm.
- **Height Adjustment:** Offers multiple levels of height adjustment for optimal viewing.
- **Stability:** Constructed from high-quality cold-rolled steel with an 8mm tempered safety glass base, supporting up to 45 kg.
- **Cable Management:** Integrated system to keep cables organized and out of sight.
- **Easy Assembly:** Designed for straightforward installation without the need for wall drilling.



Image 1.1: The BONTEC Universal TV Stand ST13 with a television mounted, showcasing its sleek design and functionality.

2. PARTS LIST

Before assembly, please ensure all parts listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

Product Fitting Details




Image 2.1: An exploded view showing all components, including TV mounting screws (M4, M6, M8 in various lengths), spacers, square washers, and assembly hardware (wire clips, buckles, rubber feet, Allen key, metal pad, plastic socket).

Included Hardware:


- Central Column
- Tempered Glass Base
- TV Mounting Plate
- TV Mounting Arms (2x)
- Various TV Screws (M4, M6, M8)
- Spacers (D8*5mm, D8*10mm)
- Washers (M4/M6/M8 Square)
- Assembly Screws (M6*10mm, M5*30mm, M6*30mm)
- M6.5 Washer, Metal Pad, Plastic Socket
- Wire Clips, Buckle, Rubber Feet, Allen Key

3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your BONTEC Universal TV Stand. It is recommended to have a second person assist with mounting the TV.

Étape 1 »»

Assemblez la plaque de montage, le pilier en acier et la base en verre trempé avec les fixations fournies.



Étape 2 »»

Placez la partie support sur un sol plat ou un bureau.




Étape 4 »»

Accrochez votre téléviseur sur le support.



Étape 3 »»

Montez les rails de support à l'arrière de votre téléviseur à l'aide d'un tournevis.



Étape 5 »»

Gérez les fils en les acheminant par le centre de la colonne.



Image 3.1: Visual guide for the assembly process, detailing each step from base assembly to cable management.

1. **Step 1: Assemble the Base.** Attach the mounting plate, steel pillar, and tempered glass base using the provided fixings. Ensure all screws are tightened securely.
2. **Step 2: Position the Stand.** Place the assembled stand on a flat, stable surface such as a desk or TV cabinet.
3. **Step 3: Attach TV Rails.** Mount the support rails to the back of your television using a screwdriver and the appropriate VESA screws and spacers from the hardware kit. Ensure the rails are securely fastened and level.
4. **Step 4: Hang the TV.** Carefully lift your television and hook the mounted rails onto the central mounting plate of the stand. Secure the TV to the stand using the safety screws or clips provided.
5. **Step 5: Manage Cables.** Route your TV cables through the integrated cable management system in the central column to keep them tidy and out of sight.

4. OPERATING INSTRUCTIONS

4.1 Height Adjustment


The BONTEC TV Stand offers flexible height adjustment to achieve your preferred viewing level.

- The main mounting plate can be adjusted to 6 different height levels, with each adjustment providing a 50mm change.
- Additionally, the TV mounting arms can be set at 2 different height levels, offering a 60mm adjustment for fine-tuning.

8 Levels of Height Adjustable



6 Height for Plate



2 Hook Heights

Image 4.1: Illustration of the 6 height settings for the mounting plate and 2 height settings for the TV hooks, totaling 8 possible height configurations.

4.2 Cable Management

Utilize the integrated cable management system to maintain a clean and organized appearance for your entertainment setup.

- Route all TV and device cables through the central column using the provided wire clips and buckles.
- This helps to conceal unsightly wires, preventing clutter and potential tripping hazards.




Image 4.2: Detail of the cable management clips on the central column, designed to keep wires tidy.

5. MAINTENANCE

To ensure the longevity and optimal performance of your BONTEC Universal TV Stand, follow these maintenance guidelines:

- **Cleaning:** Wipe the stand with a soft, dry cloth. For stubborn marks on the glass base, use a mild glass cleaner. Avoid abrasive cleaners or solvents that could damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Loose connections can compromise stability.
- **Weight Limit:** Do not exceed the maximum load capacity of 45 kg (99 lbs).
- **Placement:** Ensure the stand is always placed on a level and stable surface to prevent tipping.

6. TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common problems and solutions:

- **Problem:** The TV appears unstable or wobbly.
Solution: Ensure all assembly screws are fully tightened. Verify that the stand is placed on a flat, level surface. Check that the TV mounting arms are securely hooked onto the plate and the safety screws are engaged.
- **Problem:** TV mounting screws do not fit.
Solution: The stand includes a variety of screws (M4, M6, M8) and spacers. Refer to your TV's manual for the correct VESA screw size. Try different screw lengths with appropriate spacers to ensure a snug fit without overtightening.
- **Problem:** Cables are difficult to manage.
Solution: Ensure you are using the provided wire clips and routing cables through the designated channels in the central column. If you have many cables, consider using additional cable ties for better organization.
- **Problem:** TV is not at the desired height.
Solution: Adjust the height of the mounting plate and/or the TV mounting arms as described in Section 4.1. Ensure the TV is removed before making height adjustments to the plate.

If the problem persists, please contact BONTEC customer support for further assistance.


7. SPECIFICATIONS

Brand	BONTEC
Model Number	ST13
Compatible Screen Sizes	26-65 Inches
Max Load Capacity	45 kg (99 lbs)
VESA Compatibility	75x75mm, 100x100mm, 200x100mm, 200x200mm, 300x200mm, 300x300mm, 400x200mm, 400x300mm, 400x400mm, 600x400mm
Material	Alloy Steel, Tempered Glass (8mm)
Color	Black

Movement Type	Swivel and Height Adjustable
Mounting Type	Floor Mount (Tabletop)

Compatible with 26-65" Screens

Overall Dimensions



Need Your Attention

1. If your TV screen is less than 640 mm x 420 mm, the TV mounting arms will protrude from behind the TV.



2. For TVs with VESA size of 600x400 mm, the distance from the lowest mounting hole of your TV to the glass base must be less than 355 mm.

VESA Patterns

75 x 75	100x100	200x100
200x200	300x200	300x300
400x300	400x400	600x400

Image 7.1: Detailed dimensions and VESA pattern compatibility for the BONTEC TV Stand ST13.

8. WARRANTY AND SUPPORT

Specific warranty information for the BONTEC Universal TV Stand ST13 is not provided in this manual. For details regarding warranty coverage, spare parts availability, or technical support, please contact BONTEC customer service directly through their official website or the retailer where the product was purchased.

Please retain your proof of purchase for any warranty claims.