

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GlocalMe](#) /

› [GlocalMe G4 Pro 4G LTE Mobile Hotspot User Manual](#)

GlocalMe G4 Pro

GlocalMe G4 Pro 4G LTE Mobile Hotspot User Manual

MODEL: G4 PRO

Brand: GlocalMe

Your guide to seamless global connectivity with the GlocalMe G4 Pro.

1. PRODUCT OVERVIEW

The GlocalMe G4 Pro is a portable 4G LTE mobile hotspot designed to provide reliable internet access in over 200 countries. It utilizes patented CloudSIM technology, eliminating the need for physical SIM cards in many regions, and offers flexible data plans. With its 5-inch HD touchscreen, it provides an intuitive user experience for managing data and device settings.



The GlocalMe G4 Pro is a compact and portable 4G LTE mobile hotspot, designed for global travel. It features a 5-inch HD touchscreen and supports Cloud SIM technology, eliminating the need for physical SIM cards in many regions.

390+ Global Carriers Access Internet Coverage 200+ Countries

No SIM Required, Pay As You Go
Automatically connects to the best 4G network




Experience seamless internet connectivity in over 200 countries and regions worldwide. The G4 Pro automatically connects to the best available 4G network, ensuring optimal signal strength wherever you are.

2. WHAT'S IN THE BOX

Before you begin, please verify that all items are included in your GlocalMe G4 Pro package:

- Mobile Hotspot Device
- Instruction Manual
- USB Cable



GlocalMe G4 Pro

Other Device

Carrier Access

390+

100+

Internet Coverage

200+ Countries

100+ Countries

Frequency Band

2.4GHz & 5GHz

Single Band

Touch Screen Display

5 Inches

Non-touchscreen

Size and Weight

Slim, 188g

Bulky

The GlocalMe G4 Pro package typically includes the mobile hotspot device, a USB charging cable, and a quick start guide. Ensure all components are present upon unboxing.

3. SETUP

Initial Charging

Before first use, fully charge your GlocalMe G4 Pro using the provided USB cable and a compatible power adapter. The device's screen will indicate charging status.

Power On/Off

- To power on: Press and hold the power button until the screen lights up.
- To power off: Press and hold the power button, then select 'Power Off' on the screen.

Account Creation and Data Plans

The G4 Pro operates on CloudSIM technology, meaning no physical SIM card is required for initial setup or data purchase in most regions. You can manage your data plans directly through the device's touchscreen interface or by downloading the GlocalMe App on your smartphone.

- **CloudSIM:** Access global data packages (daily, monthly, GB) without needing local SIM cards. The device intelligently selects the best available network.
- **Physical SIM Slot:** The G4 Pro also includes a physical SIM card slot, allowing you to insert your own local SIM card if preferred.



Upon first use, power on the device. You can manage data plans and settings directly from the 5-inch HD touchscreen or through the GlocalMe mobile application. The device comes with initial global data.

This official video provides a visual guide to the initial setup and key features of the GlocalMe G4 Pro mobile hotspot, including powering on and navigating the interface.

4. OPERATING THE DEVICE

Connecting Your Devices

The G4 Pro can connect up to 10 devices simultaneously. To connect, simply search for the GlocalMe Wi-Fi network on your smartphone, tablet, or laptop, and enter the password displayed on the G4 Pro's screen.



The G4 Pro allows up to 10 devices to connect simultaneously, providing internet access for smartphones, tablets, laptops, and other Wi-Fi enabled devices. It supports both 2.4GHz and 5GHz bands for flexible connectivity.


Dual Band Support

The device supports both 2.4GHz and 5GHz Wi-Fi bands, offering flexibility and minimizing interference for a stable connection.

Pre-installed Applications

The G4 Pro comes with several useful pre-installed applications to assist you during your travels:

- **Map:** Navigate unfamiliar locations.
- **Translator:** Facilitate communication in foreign languages.
- **Currency Calculator:** Convert currencies on the go.



Utilize the pre-installed applications such as Translator, Exchange Rate, and TripAdvisor directly from the device's 5-inch HD touchscreen. These tools are designed to enhance your travel experience.

Touch Screen Interface

The intuitive 5-inch HD touchscreen allows you to easily monitor data usage, manage SIM cards (if inserted), view connected devices, and set up data protection features.

5. MAINTENANCE

Battery Life and Charging

The G4 Pro is equipped with a 3900 mAh battery, providing up to 10 hours of continuous connectivity. It can also serve as a power bank to charge other devices, making it a versatile travel companion.



The G4 Pro is equipped with a 3900 mAh battery, providing up to 10 hours of continuous internet usage. It can also function as a power bank to charge other devices via its USB port.

Care and Storage

To ensure the longevity of your device, store it in a cool, dry place. Avoid exposing it to extreme temperatures, direct sunlight, or moisture. Clean the screen and body with a soft, dry cloth.

6. TROUBLESHOOTING

If you encounter issues with your GlocalMe G4 Pro, consider the following common troubleshooting steps:

- **No Internet Connection:** Check your data plan status on the device or GlocalMe App. Ensure you are within

network coverage. Try restarting the device.

- **Slow Speed:** Verify the signal strength. If multiple devices are connected, try disconnecting some to improve performance.
- **Device Not Responding:** Perform a soft reset by holding the power button until the device restarts.

With Ultra Big 5 inch Touchscreen

Like a smartphone for easy navigation with touch control

Monitor Data Usage

Manage SIM Card

Connected Devices

Data Usage Protection



For common issues, refer to the quick start guide or the GlocalMe app for troubleshooting steps. Ensure your data plan is active and the device is within network coverage.

7. SPECIFICATIONS

Detailed technical specifications for the GlocalMe G4 Pro:

Feature	Detail

Feature	Detail
Model Name	G4 Pro
Package Dimensions	6.97 x 3.82 x 2.05 inches
Item Weight	6.6 ounces
Operating System	Android 8.1
Frequency	5 GHz (Dual-Band)
Wireless Communication Technologies	4G, Wi-Fi (802.11n, 802.11b, 802.11ac, 802.11g)
Special Features	5" Touch Screen
Human Interface Input	Touchscreen
Battery Power Rating	5 Volts (3900 mAh)
Max Connected Devices	10
Country of Origin	China

The Ideal Network of Life



RV Internet



Outdoor Camping



Business Meeting



International Trip

A visual comparison highlighting key features of the GlocalMe G4 Pro.

8. WARRANTY AND SUPPORT


GlocalMe offers a flexible 'Pay as you go' model, meaning there are no long-term contracts or hidden roaming fees. You can choose data plans that suit your needs directly from the GlocalMe App.


For any inquiries or support, GlocalMe provides customer service. While specific warranty details are not provided in this manual, please refer to the official GlocalMe website or contact their customer support for comprehensive warranty information and assistance.

Visit the official GlocalMe Store for more information and support: [GlocalMe Store](#)

Related Documents - G4 Pro

	<p>GlocalMe Numen Air Quick Start Guide: Setup and Usage</p> <p>Your essential guide to setting up and using the GlocalMe Numen Air mobile WiFi hotspot. Learn to connect via Cloud SIM or physical SIM, manage data plans, and access global internet.</p>
	<p>GlocalMe UPP Quick Start Guide: Connecting to the Internet</p> <p>This guide provides instructions on how to set up and use the GlocalMe UPP device, including Cloud SIM and physical SIM card usage, network optimization, and regulatory information.</p>
	<p>GlocalMe TriForce Quick Start Guide: Setup, Features, and Compliance</p> <p>Comprehensive quick start guide for the GlocalMe TriForce portable WiFi hotspot and power bank. Learn how to set up your device, connect to Wi-Fi, use the power bank feature, and understand safety and compliance information.</p>
	<p>GlocalMe GuardFlex Pro User Guide: Setup, Specs, and Support</p> <p>Get started with your GlocalMe GuardFlex Pro 4G LTE Wireless Router. This user guide provides step-by-step setup instructions, Wi-Fi connection details, SIM card usage, indicator status explanations, troubleshooting tips, and technical specifications. Learn how to optimize your network experience.</p>
	<p>GlocalMe U3 Quick Start Guide</p> <p>A concise guide to using the GlocalMe U3 device for cloud SIM services and physical SIM card usage, including app integration, device setup, and network connection.</p>





Function Introduction

- 1. Power on: Press power button for 2 seconds
- 2. Power off: Press power button for 4 seconds
- 3. Restart: Press power button for 14 seconds

02 / Technical Specification

Model: GLA2020
Box content: Device * 1, User manual * 1, Type-C cable * 1, SIM card pin * 1

Technical Specification

Size: 101.0x149.4x8.3mm
Weight: 194g
Screen: 2.4 inch
Screen resolution: 432x240px
CPU: MT6739
LTE: 4G/3G/2G
WCDMA: 3G
GSM: 2G/3G
USB port: Type-C (input)
Battery capacity: 5400mAh/4000mAh
Power: DC 5V

03 / Quick Start Guide

How To Use GlocalMe Cloud SIM Service?

1. Download GlocalMe App

- ① Download and install GlocalMe app on your mobile phone
- ② Register an account on the App
- ③ Press Log in → Create a new account
- ④ Enter the account information (username, password, mobile number, etc.)

2. Turn on Numer Air

- ① Press and hold the power button for 2 seconds
- ② Scan the QR code on the home page and the device QR code on the screen

3. Activate Numer Air

- ① GlocalMe App → Device → [Select Device] → [Scan QR code] → Turn on Numer Air
- ② The start of Numer Air is the activation success

4. Connect the WiFi

- ① Press WiFi logo [WIFI] on Numer Air and then the WiFi icon on the screen
- ② Connect your mobile device in WiFi setting

For more information, please download the complete guide on glocalme.com/
The information is subject to change without notice.

How To Use a Physical SIM Card?

1. Insert A SIM Card

- ① Please turn off your device when inserting/removing SIM card
- ② Please use the SIM card provided by the operator. If you want to use the picture above Numer Air device, you require non-SIM card
- ③ Press SIM card removed, turn on [SIM Card Network]

2. Set The APN


- ① If you are not connected to the network after the above steps, you can connect to the network
- ② SIM card removed → [APN] → Enter the APN of your SIM card provider
- ③ Click [OK] to save the APN and return to the setting

Note

- 1. After successful binding, please restart the device and then it can be normally used
- 2. Before you run out of the initial data, please recharge your account as soon as possible. You can recharge via GlocalMe App or go to the recharge center of APN We. We support Alipay, WeChat, and other means to pay. After recharging, you can purchase any data package in the package center of APN We.
- 3. This product has "Data Flow Protection" turned on by default to prevent connected device from consuming large data due to automatic system updates and other reasons. If you do not want to use this function, you will be restricted from accessing the APN store or unable to download applications. If needed, you can temporarily disable the restriction via "Flow Protection" on Numer Air's screen.

For more information, please pay a visit to GlocalMe website:
www.glocalme.com/

04 / Display



Slide the touch screen to unlock it before you can manipulate the screen to prevent being operated.



① Number of active connections
② Signal strength
③ Battery level
④ Data plan usage
⑤ QR code data plan usage
⑥ APN code Scan binding or download GlocalMe App
⑦ SIM card and PWD Show SIM card pin or PWD to modify it.
⑧ Setting A network connection with WiFi 2.4G or 5G network, hide SSID, etc.



① Network setting: Please set the function when user own SIM or Switch 5G or 4G networks etc.
② Connected device Management: It is possible to block/allow the devices which have download data to connect with device.
③ Data usage protection: Please try this function when data communication is not stable.
④ Data usage protection: Data management, Enable this function to

GlocalMe Numen Air User Manual: Portable Wi-Fi Hotspot Guide

Comprehensive user manual for the GlocalMe Numen Air portable Wi-Fi hotspot. Includes setup instructions for Cloud SIM and physical SIM cards, technical specifications, device interface details, USB tethering, safety guidelines, and regulatory information.