EUGAD 0142XJYJ

EUGAD Telescopic Metal Clothes Rack User Manual

Model: 0142XJYJ | Brand: EUGAD

1. INTRODUCTION

This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your EUGAD Telescopic Metal Clothes Rack. Please read these instructions carefully before use and retain them for future reference.

The EUGAD clothes rack is designed to provide a stable and convenient solution for organizing and storing garments. Its robust metal construction ensures durability and stability for everyday use.

2. SAFETY GUIDELINES

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.

- Assemble the clothes rack on a soft, clean surface to prevent scratches to the product or your floor.

- Tighten all screws and connections securely, but do not overtighten to avoid stripping threads.

- Do not exceed the maximum load capacity of 39.92 kg (88 lbs) to prevent collapse or damage.

- Keep children and pets away from the assembly area. Small parts can be a choking hazard.

- Place the clothes rack on a flat, stable surface to prevent tipping.

- Avoid hanging excessively heavy items on one side, which could cause imbalance.

3. PACKAGE CONTENTS

Please verify that all the following components are included in your package:

- Horizontal Hanging Bar (1x)

- Vertical Support Poles (2x)

- Base Feet (2x)

- Connecting Joints/Screws (as required for assembly)

- Assembly Tool (e.g., Allen key, if applicable)

If any parts are missing or damaged, please contact EUGAD customer support.

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your EUGAD clothes rack:

1. **Prepare the Base:** Attach each vertical support pole to one of the base feet. Ensure the connection is firm and stable.

2. **Connect the Horizontal Bar:** Insert the ends of the horizontal hanging bar into the top of the vertical support poles. Secure these connections using the provided joints or screws.

3. **Secure All Connections:** Double-check that all connections are tightly secured. Gently shake the rack to ensure it is stable before use.

An empty white metal clothes rack with three detailed close-ups: the top bar connection, a central pole joint, and the base foot connection, illustrating key structural points.

5. OPERATING INSTRUCTIONS

Using your EUGAD clothes rack is straightforward:

- **Hanging Garments:** Use hangers to place clothes on the horizontal bar. Distribute the weight evenly

across the bar to maintain stability.

- **Placement:** Position the rack in a location where it will not obstruct pathways and is on a level surface.

- **Moving the Rack:** If you need to move the rack, lift it carefully from the vertical poles rather than dragging it, especially if it is loaded with clothes.

A white metal clothes rack with three shirts hanging on it, showcasing its primary function.

6. CARE AND MAINTENANCE

To ensure the longevity and appearance of your clothes rack:

- **Cleaning:** Wipe the metal surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all connections and screws to ensure they remain tight. Retighten if necessary.
- **Storage:** If not in use, store the rack in a dry environment to prevent rust.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Rack is Unstable:**
  - Ensure all screws and connections are fully tightened.
  - Verify the rack is placed on a flat, level surface.
  - Check if the weight of the clothes is evenly distributed.
- **Parts Do Not Fit:**
  - Refer to the assembly instructions and diagrams to ensure you are using the correct parts for each step.
  - Do not force parts together. If a part seems incorrect, contact customer support.

8. PRODUCT SPECIFICATIONS

Brand	EUGAD
Model Number	0142XJYJ
Color	White
Material	Metal (Steel tubes)
Product Dimensions (L x W x H)	99 x 46 x 152 cm (approximately)
Item Weight	2.82 Kilograms
Maximum Load Capacity	39.92 Kilograms

A diagram illustrating the dimensions of the white metal clothes rack, showing a width of 99cm, a depth of 46cm, and a height of 152cm.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. EUGAD is committed to providing quality products and customer satisfaction.

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact EUGAD customer support through their official website or the retailer where the product

was purchased.