

[Manuals.plus](#) /

› [PROALLER](#) /

› PROALLER Electric Heated Foot Warmer (Model B07YFM3KXW) - Instruction Manual

PROALLER B07YFM3KXW

PROALLER Electric Heated Foot Warmer (Model B07YFM3KXW) - Instruction Manual

Brand: PROALLER | Model: B07YFM3KXW



1. PRODUCT OVERVIEW

The PROALLER Electric Heated Foot Warmer is designed to provide warmth and comfort for your feet and can also be used for other body areas. It features multiple heat settings, an automatic shut-off function for safety, and a soft, machine-washable fabric construction.



Image: The PROALLER Electric Heated Foot Warmer in use, showing feet inserted into the soft, grey fabric pocket.

2. SAFETY INFORMATION

- Avoid direct contact with skin to prevent burns.
- Use the auto-off feature for safety.
- Do not use while sleeping unless specifically designed for overnight use and monitored.
- Do not use on infants, children, incapacitated persons, or persons insensitive to heat.
- Do not use if the product appears damaged or frayed.
- Always unplug the unit when not in use or before cleaning.
- Keep away from pets and sharp objects.

3. SETUP

1. Remove the heated foot warmer from its packaging.
2. Ensure the power cord and controller are securely connected to the foot warmer.
3. Plug the power cord into a standard electrical outlet.

Temperatures Control Heating pad



ETL Intertek
Certified Safe



Fast
Heating



Machine
Washable



Good
Comfort



3 Heating
Levels



10ft Extra-
Long Cord



Image: A hand connecting the detachable power cord to the foot warmer unit.

4. OPERATING INSTRUCTIONS

1. Place the foot warmer on a flat, dry surface.
2. Insert your feet into the dual-pocket design for warmth. The soft, thick sherpa lining helps retain heat.
3. Press the power button on the controller to turn the unit on.
4. Select your desired heat level (Low, Medium, High) using the controller. The temperature settings are approximately 104°F, 122°F, and 149°F.
5. The unit will automatically shut off after 2 hours to prevent excessive heating and save energy.
6. For use on other body parts (abdomen, back, shoulders), place the heating pad directly on the affected area.



Image: A woman sitting on the floor with her feet in the foot warmer, adjusting the heat settings on the controller.

Video: Demonstrates the use of the Electric Heated Foot Warmer, highlighting its soft material, adjustable temperature, and auto-shutoff feature. The video shows a user inserting feet into the warmer and adjusting settings.

Video: Official demonstration of the Electric Heated Foot Warmer, showcasing its features and ease of use.

5. MAINTENANCE

Cleaning Instructions:

1. Always unplug the power cord from the wall outlet and detach the controller from the foot warmer before cleaning.
2. The foot warmer is machine washable. Use a gentle cycle with cold water.
3. Do not bleach, iron, or dry clean.
4. Tumble dry on low heat or air dry. Ensure the product is completely dry before reattaching the controller and plugging it in.

Machine Washable



Do not
iron



Do not
tumble dry



Image: A woman placing the foot warmer into a front-loading washing machine, illustrating its machine-washable feature.

6. TROUBLESHOOTING

- **Unit not heating:** Ensure the power cord is securely plugged into both the wall outlet and the foot warmer. Check if the controller lights are on. If not, try a different outlet.
- **Auto-off feature activating too soon:** The unit is designed to automatically shut off after 2 hours. If it shuts off earlier, ensure the connections are secure and the product is not folded or bunched up, which could trigger overheat protection.
- **Controller blinking/unresponsive:** If the controller is blinking and unresponsive, unplug the unit from the wall outlet, wait a few seconds, and then plug it back in to reset the device.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Model Number	B07YFM3KXW
Dimensions	16" x 22" (41cm x 56cm)
Material	Soft Flannel (outer), Skin-friendly Sherpa (inner)
Heat Settings	3 levels (104°F, 122°F, 149°F)
Auto-Off Timer	2 hours
Power Cord Length	10 ft
Safety Certification	ETL Certified

8. WARRANTY & SUPPORT

The PROALLER Electric Heated Foot Warmer comes with a Lifetime Warranty. If you encounter any issues or have questions beyond the return window, please contact customer support via the order page. Resolutions are typically provided within 12 hours.

Video: A customer demonstrating the heated foot warmer, showing its soft texture and how it can be used to warm feet.

Video: Customer demonstration of the heated foot warmer, highlighting its comfort and effectiveness.

