

[manuals.plus](#) /› [CHESONA](#) /› [CHESONA Wireless Keyboard Case User Manual for iPad Pro 11-inch and iPad Air 10.9/11-inch](#)

## CHESONA A2301, A2459, A2460

# CHESONA Wireless Keyboard Case User Manual

**MODEL: A2301, A2459, A2460****Brand: CHESONA**

---

## 1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your CHESONA Wireless Keyboard Case. Designed to enhance your tablet experience, this case offers protection, versatile viewing angles, and a detachable Bluetooth keyboard for increased productivity.

---

## 2. Compatibility

The CHESONA Wireless Keyboard Case is compatible with the following iPad models:

- iPad Pro 11-inch (4th Gen): A2759, A2759, A2761, A2762
- iPad Pro 11-inch (3rd Gen): A2377, A2301, A2459, A2460
- iPad Pro 11-inch (2nd Gen): A2228, A2068, A2230, A2231
- iPad Pro 11-inch (1st Gen): A1980, A2013, A1934
- iPad Air 10.9-inch (5th Gen 2022): A2588, A2589, A2591
- iPad Air 10.9-inch (4th Gen 2020): A2072, A2316, A2324, A2325
- iPad Air 11-inch (M3 2025): A3266, A3267, A3270
- iPad Air 11-inch (M2 2024): A2902, A2903, A2904

# Please Check Before You Buy Compatibility



## Models

### For iPad Air 11" (M3) (2025)

A3266 / A3267 / A3270

### For iPad Air 11" (M2) (2024)

A2902 / A2903 / A2904

### For iPad Pro 11" 4th Gen (2022)

A2759 / A2435 / A2761 / A2762

### For iPad Pro 11" 3rd Gen (2021)

A2377 / A2459 / A2301 / A2460

### For iPad Pro 11" 2nd Gen (2020)

A2228 / A2068 / A2230 / A2231

### For iPad Pro 11" 1st Gen (2018)

A1980 / A2013 / A1934 / A1979

### For iPad Air 5th Gen 10.9"

A2588 / A2589 / A2591

### For iPad Air 4th Gen 10.9"

A2316 / A2324 / A2325 / A2072

Image: Compatibility chart for CHESONA keyboard case.

To ensure proper fit, verify your iPad's model number by navigating to Settings > General > About > Model Number.

Video: Guide on how to identify your iPad Pro 11 or iPad Air 10.9/11 model.

## 3. Package Contents

The package includes:

- CHESONA Wireless Keyboard Case
- USB Cable

## 4. Product Features

- **Magnetically Removable Keyboard:** The wireless Bluetooth keyboard can be easily detached from the case, offering flexibility for various uses.
- **Multiple Stand Angles:** The case features built-in grooves to support your iPad at three different viewing angles, suitable for typing, reading, or gaming.
- **Premium Protection:** An anti-slide design and durable twill material provide 360° protection against scratches, bumps, and drops. Precise cutouts ensure full access to all ports, sensors, speakers, microphone, and cameras.
- **Integrated Pencil Holder:** A dedicated slot is included for storing and charging your Apple Pencil.
- **Long-Life Battery:** The built-in rechargeable battery provides over 80 hours of working time and 120 days of standby time on a 2-3 hour charge.



Image: CHESONA Wireless Keyboard Case with iPad and Apple Pencil.

Video: Overview of the CHESONA Keyboard Case features, including detachable keyboard, multiple viewing angles, and pencil holder.

## 5. Setup Instructions

## 5.1 Inserting Your iPad into the Case

1. Align your iPad with the protective shell of the case.
2. Gently press the iPad into the case, ensuring all corners and edges are securely fitted.

## 5.2 Connecting the Bluetooth Keyboard

1. Ensure the keyboard is charged.
2. Turn on the keyboard using the power switch located on the top right. The Bluetooth indicator light will flash.
3. On your iPad, go to **Settings > Bluetooth**.
4. Turn on Bluetooth. Your iPad will search for nearby devices.
5. Select 'Bluetooth Keyboard' (or similar name) from the list of available devices.
6. Follow any on-screen prompts to complete the pairing process. The indicator light on the keyboard will stop flashing once connected.

# 6. Operating Instructions

---

## 6.1 Using the Keyboard

The keyboard features a standard QWERTY layout with additional hotkeys customized for iPads, including volume control, music control, and brightness adjustment. These function keys are typically accessed by pressing the 'Fn' key in combination with the desired function key.

# Detachable Light-weight Keyboard

Easy to remove and attach whenever you need to.



Image: Detachable wireless Bluetooth keyboard.

## 6.2 Adjusting Viewing Angles

The case allows for multiple viewing angles. Position your iPad in one of the three built-in grooves on the case cover to achieve your preferred angle for typing, watching videos, or browsing.

# Adjustable Viewing Angle

Providing a better and easier typing experience.



Image: iPad case demonstrating adjustable viewing angles.

## 6.3 Using the Apple Pencil Holder

The case includes a specific slot designed to hold your Apple Pencil. This holder allows for convenient storage and supports wireless charging of the Apple Pencil when placed correctly.



Image: iPad case with Apple Pencil charging in the integrated holder.

## 7. Charging

The keyboard features a built-in rechargeable battery. A full charge takes approximately 2-3 hours and provides over 80 hours of continuous use or 120 days of standby time. Use the provided USB cable to charge the keyboard.



## USB-C Rechargeable

2 Hours ↓  
Charging time

80 Hours ↑  
Ultralong  
battery life

Image: USB-C charging port on the wireless keyboard.

### 8. Maintenance

To clean the case, gently wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the surface. Ensure the keyboard is turned off and disconnected from your iPad before cleaning.



# Soft & Smooth Cover

Made of twill material,  
the case gives tablet  
impact-resistant protection.

Image: Close-up of the soft and smooth cover material.

## 9. Troubleshooting

### 9.1 Keyboard Not Connecting

- Ensure the keyboard is powered on and fully charged.
- Verify that Bluetooth is enabled on your iPad.
- If the keyboard was previously paired, try 'forgetting' the device in your iPad's Bluetooth settings and re-pairing it.
- Press the 'Connect' button on the keyboard to initiate pairing mode.

### 9.2 Keyboard Entering Sleep Mode

The keyboard is designed to enter sleep mode after 10 minutes of inactivity to conserve battery. To wake it up and reconnect to your iPad, simply press any key on the keyboard.

## 10. Specifications

---

Feature	Detail
Product Dimensions	9.84 x 8.27 x 0.98 inches
Item Weight	1.49 pounds
Item Model Number	A2301, A2459, A2460
Batteries	1 Lithium Polymer batteries required. (included)
Connectivity Technology	Bluetooth
Keyboard Description	Ergonomic
Special Feature	Ergonomic
Color	Black
Keyboard Backlighting Color Support	Single Color

## 11. Warranty & Support

---

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official CHESONA website. Keep your purchase receipt for warranty claims.