

## Nakamichi Mate

# Nakamichi Mate 25W Wireless Bluetooth Outdoor Speaker User Manual

Model: Mate

## INTRODUCTION

This manual provides comprehensive instructions for the Nakamichi Mate 25W Wireless Bluetooth Outdoor Speaker. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan. Keep this manual for future reference.



Image: Front view of the Nakamichi Mate 25W Wireless Bluetooth Outdoor Speaker in black, showcasing its compact design and speaker grille.

## PRODUCT FEATURES

---

- **25W Peak Power Output:** Delivers robust audio performance.
- **Bluetooth v5.0 Connectivity:** Ensures stable and efficient wireless connection up to 10 meters.
- **Waterproof Design (IPX6):** Resistant to strong jets of water, suitable for outdoor use.
- **600mAh Rechargeable Battery:** Provides up to 5 hours of playback time (at medium volume).
- **Built-in Microphone:** For hands-free calling.
- **Auxiliary Input:** Supports wired audio connections.
- **Full Range Speaker:** Designed for balanced sound reproduction.



Waterproof



Strong Bass



Peak Power  
5W



600mAh  
Charging Time  
About 2hrs



Built-in MIC  
for calling

Image: Visual representation of key features including IPX6 waterproof rating, strong bass, 25W peak power, 600mAh battery, and built-in microphone for calls.



BT V5.0



Wireless Range  
10M



Playback Time  
5H (Med. Vol.)



Support  
AUX

Image: Visual representation of connectivity features including Bluetooth V5.0, 10-meter wireless range, 5 hours playback time, and AUX input support.

## SETUP

### 1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port and a compatible USB power adapter (not included). The charging indicator will illuminate during charging and turn off once fully charged. A full charge takes approximately 2 hours.



Image: Rear view of the Nakamichi Mate speaker, highlighting the covered charging port and AUX input for protection against water.

## 2. Powering On/Off

- **To Power On:** Press and hold the power button (usually marked with a circle or power symbol) located on the top of the speaker until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the power button again until the speaker powers down.

## 3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. A blue LED indicator will typically flash rapidly.
2. On your device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
3. Search for available devices and select "Nakamichi Mate" from the list.
4. Once paired, the speaker will provide an audible confirmation, and the LED indicator will typically glow solid blue.

The speaker will automatically attempt to reconnect to the last paired device when powered on.

## 4. AUX Connection

For wired audio playback, connect one end of a 3.5mm audio cable (not included) to the AUX input port on the speaker and the other end to the audio output jack of your device. The speaker will

automatically switch to AUX mode.

## OPERATING INSTRUCTIONS

---

### Button Functions (Touch Control)

The Nakamichi Mate speaker features touch controls on its top panel. Refer to the image below for button layout.



Image: Top view of the Nakamichi Mate speaker, illustrating the touch-sensitive control panel with symbols for power, volume, and track control.

- **Power Button (Center):**
  - Press and hold: Power On/Off.
  - Double press: Switch between Bluetooth and AUX input modes.
- **Volume Up (+) / Next Track:**
  - Short press: Increase volume.
  - Long press: Skip to the next track.
- **Volume Down (-) / Previous Track:**
  - Short press: Decrease volume.



- Long press: Go to the previous track.
- **Play/Pause Button (Usually a triangle or circle):**
  - Short press: Play/Pause audio.
  - Short press (during incoming call): Answer call.
  - Press and hold (during incoming call): Reject call.
  - Short press (during call): End call.

## Waterproof Functionality

The Nakamichi Mate speaker is rated IPX6 waterproof. This means it is protected against high-pressure water jets from any direction. It is suitable for use in outdoor environments where it may be exposed to splashes or rain. Do not submerge the speaker in water.

Ensure all port covers (charging port, AUX input) are securely closed before exposing the speaker to water to maintain its waterproof integrity.

## MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to clean the speaker's surface. Avoid using abrasive cleaners, solvents, or harsh chemicals.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in constant use.
- **Port Covers:** Always ensure the rubber covers for the charging and AUX ports are properly sealed to maintain water resistance.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; power button not pressed correctly.	Charge the speaker fully. Press and hold the power button for several seconds.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode (flashing blue LED). Turn Bluetooth on your device. Move device closer to speaker (within 10m). Forget "Nakamichi Mate" on your device and try pairing again.
No sound or low volume.	Volume too low on speaker or device; incorrect input mode; AUX cable not fully inserted.	Increase volume on both speaker and connected device. Ensure correct input mode (Bluetooth or AUX). Re-insert AUX cable firmly.
Speaker keeps beeping.	Low battery warning (below 30%).	Recharge the speaker.

Problem	Possible Cause	Solution
Microphone quality is poor during calls.	Environmental noise; speaker too far; inherent microphone limitations.	Move closer to the speaker. Reduce background noise. For critical calls, use your phone's microphone directly.

## SPECIFICATIONS

Model Name	Mate
Speaker Type	Outdoor
Peak Output Power	25 Watts
Connectivity Technology	Bluetooth v5.0, Auxiliary
Wireless Range	Up to 10 meters (33 feet)
Audio Output Mode	Stereo
Water Resistance Level	IPX6 (Waterproof)
Control Method	Touch
Battery Capacity	600mAh Lithium Polymer
Battery Average Life	5 Hours (at medium volume)
Charging Time	Approximately 2 hours
Signal-to-Noise Ratio	60 dB
Tweeter Diameter	1 Inch
Audio Driver Type	Dynamic Driver
Supported Audio Formats	MP3, WMA
Product Dimensions (LxWxH)	6.9 x 8.7 x 3.6 cm
Item Weight	400 Grams
Mounting Type	Tabletop Mount
Manufacturer	Guangzhou Havit Technology Co.






## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Nakamichi website. Keep your proof of purchase for any warranty claims.

For further assistance, you may contact Nakamichi customer service through their official channels.



## Related Documents - Mate

	<p><a href="#">Nakamichi ND435W Dashcam User Manual and Specifications</a></p> <p>Comprehensive user manual and specifications for the Nakamichi ND435W dashcam, covering installation, operation, features, and troubleshooting. Includes details on recording modes, connectivity, and system requirements.</p>
	<p><a href="#">Nakamichi AV-10 Audio/Video Receiver Owner's Manual</a></p> <p>This comprehensive owner's manual guides users through the setup, operation, and features of the Nakamichi AV-10 Audio/Video Receiver, ensuring optimal performance and enjoyment of your home audio system.</p>
	<p><a href="#">Nakamichi Car Audio App Quick Start Guide for Android and iPhone</a></p> <p>Learn how to install and use the Nakamichi App and Caradio App for 2-way wireless control of your Nakamichi Car Head Unit with Android and iPhone devices, featuring music, navigation, and camera alerts.</p>
	<p><a href="#">MATE GO E-bike Owner's Manual: Assembly, Operation, and Maintenance Guide</a></p> <p>Comprehensive owner's manual for the MATE GO electric bicycle, covering assembly, safety, operation, battery care, maintenance, and warranty information for European market users.</p>
	<p><a href="#">Nakamichi PA-5II, PA-5AII, PA-5EII Power Amplifier Service Manual</a></p> <p>Comprehensive service manual for Nakamichi PA-5II, PA-5AII, and PA-5EII power amplifiers, detailing service procedures, parts lists, schematics, wiring diagrams, block diagrams, and technical specifications.</p>

<div><div><div>Appointment of Authorised Representative</div><div>mate.</div></div><div><div><div>1. To verify the identity of the Authorised Representative (AR) and to ensure that the AR is a natural person.</div><div>2. To verify the identity of the AR.</div><div>3. To verify the identity of the AR.</div><div>4. To verify the identity of the AR.</div><div>5. To verify the identity of the AR.</div><div>6. To verify the identity of the AR.</div><div>7. To verify the identity of the AR.</div><div>8. To verify the identity of the AR.</div><div>9. To verify the identity of the AR.</div><div>10. To verify the identity of the AR.</div><div>11. To verify the identity of the AR.</div><div>12. To verify the identity of the AR.</div><div>13. To verify the identity of the AR.</div><div>14. To verify the identity of the AR.</div><div>15. To verify the identity of the AR.</div><div>16. To verify the identity of the AR.</div><div>17. To verify the identity of the AR.</div><div>18. To verify the identity of the AR.</div><div>19. To verify the identity of the AR.</div><div>20. To verify the identity of the AR.</div><div>21. To verify the identity of the AR.</div><div>22. To verify the identity of the AR.</div><div>23. To verify the identity of the AR.</div><div>24. To verify the identity of the AR.</div><div>25. To verify the identity of the AR.</div><div>26. To verify the identity of the AR.</div><div>27. To verify the identity of the AR.</div><div>28. To verify the identity of the AR.</div><div>29. To verify the identity of the AR.</div><div>30. To verify the identity of the AR.</div><div>31. To verify the identity of the AR.</div><div>32. To verify the identity of the AR.</div><div>33. To verify the identity of the AR.</div><div>34. To verify the identity of the AR.</div><div>35. To verify the identity of the AR.</div><div>36. To verify the identity of the AR.</div><div>37. To verify the identity of the AR.</div><div>38. To verify the identity of the AR.</div><div>39. To verify the identity of the AR.</div><div>40. To verify the identity of the AR.</div><div>41. To verify the identity of the AR.</div><div>42. To verify the identity of the AR.</div><div>43. To verify the identity of the AR.</div><div>44. To verify the identity of the AR.</div><div>45. To verify the identity of the AR.</div><div>46. To verify the identity of the AR.</div><div>47. To verify the identity of the AR.</div><div>48. To verify the identity of the AR.</div><div>49. To verify the identity of the AR.</div><div>50. To verify the identity of the AR.</div><div>51. To verify the identity of the AR.</div><div>52. To verify the identity of the AR.</div><div>53. To verify the identity of the AR.</div><div>54. To verify the identity of the AR.</div><div>55. To verify the identity of the AR.</div><div>56. To verify the identity of the AR.</div><div>57. To verify the identity of the AR.</div><div>58. To verify the identity of the AR.</div><div>59. To verify the identity of the AR.</div><div>60. To verify the identity of the AR.</div><div>61. To verify the identity of the AR.</div><div>62. To verify the identity of the AR.</div><div>63. To verify the identity of the AR.</div><div>64. To verify the identity of the AR.</div><div>65. To verify the identity of the AR.</div><div>66. To verify the identity of the AR.</div><div>67. To verify the identity of the AR.</div><div>68. To verify the identity of the AR.</div><div>69. To verify the identity of the AR.</div><div>70. To verify the identity of the AR.</div><div>71. To verify the identity of the AR.</div><div>72. To verify the identity of the AR.</div><div>73. To verify the identity of the AR.</div><div>74. To verify the identity of the AR.</div><div>75. To verify the identity of the AR.</div><div>76. To verify the identity of the AR.</div><div>77. To verify the identity of the AR.</div><div>78. To verify the identity of the AR.</div><div>79. To verify the identity of the AR.</div><div>80. To verify the identity of the AR.</div><div>81. To verify the identity of the AR.</div><div>82. To verify the identity of the AR.</div><div>83. To verify the identity of the AR.</div><div>84. To verify the identity of the AR.</div><div>85. To verify the identity of the AR.</div><div>86. To verify the identity of the AR.</div><div>87. To verify the identity of the AR.</div><div>88. To verify the identity of the AR.</div><div>89. To verify the identity of the AR.</div><div>90. To verify the identity of the AR.</div><div>91. To verify the identity of the AR.</div><div>92. To verify the identity of the AR.</div><div>93. To verify the identity of the AR.</div><div>94. To verify the identity of the AR.</div><div>95. To verify the identity of the AR.</div><div>96. To verify the identity of the AR.</div><div>97. To verify the identity of the AR.</div><div>98. To verify the identity of the AR.</div><div>99. To verify the identity of the AR.</div><div>100. To verify the identity of the AR.</div></div></div><div data-bbox="343 152 1476 309" data-label="Text"><p><a href="#">Mate Internet &amp; Mobile: Appointing an Authorised Representative</a></p><p>Learn how to appoint an authorised representative for your Mate internet and mobile account. This guide explains the process, requirements, and the difference between an authorised representative and an advocate.</p></div></div>
--