ZOKOP HT-1188

ZOKOP HT-1188 Electric Infrared Quartz Heater User Manual

Model: HT-1188 | Brand: ZOKOP

1. Important Safety Instructions

Please read all instructions carefully before using this heater. Failure to follow these instructions may result in fire, electric shock, or injury.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles when moving this heater.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas, and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater has an Overheat Safety Switch and a Tip-Over Safety Switch for enhanced protection.
- Ensure the heater is placed on a stable, level surface.
- Operates on 120 Volts AC.

2. Package Contents

Verify that all components are present and in good condition:

- 1 x ZOKOP Electric Infrared Quartz Heater (Model: HT-1188)

- 1 x Remote Control (requires 2 AAA batteries, not included)
- 1 x User Manual

3. Product Overview

The ZOKOP HT-1188 is a powerful and efficient electric infrared quartz heater designed to provide warmth for large rooms. It features advanced safety mechanisms and user-friendly controls.



Figure 3.1: Front view of the ZOKOP HT-1188 heater with its remote control.

Key Features:

- **Powerful Heating:** Equipped with 4 quartz infrared heating elements, delivering 750W or 1500W of power.
- **Three Heat Settings:** Choose between Low (750W), High (1500W), and ECO mode (maintains a constant 68°F / 20°C).
- **Wide Coverage:** Effectively heats areas up to approximately 150 square feet.
- **Programmable Timer:** Features a 12-hour programmable timer for automatic shut-off or turn-on.
- **Thermostat Control:** Maintains desired room temperature between 50°F and 90°F (10°C and 32°C).
- **LED Display:** Extra-large LED display for clear temperature and setting indication.
- **Advanced Safety:** Includes Overheat Safety Switch, Tip-Over Safety Switch, and Child Safety Lock.
- **Cool Touch Exterior:** The exterior cabinet remains cool to the touch during operation.
- **Remote Control:** Conveniently adjust settings from a distance.
- **Quiet Operation:** Designed for low noise output (≤59db).

- **Compact & Portable:** Features a handle for easy relocation.

Visual Features:



Figure 3.2: Illustration of the heater's fast and instant heat distribution, highlighting its 1500W power and 3-second fast heating capability.



Figure 3.3: Detailed view of the heater's control panel, showing buttons for Safety Lock, Heater Mode, 12H Timer, Temperature Up/Down, Ambient Temp, and Power.



Figure 3.4: The heater positioned in a bedroom, demonstrating the convenience of its Smart 12-hour Timer Function for energy saving and comfortable sleep.



Figure 3.5: Visual representation of the heater's core attributes: Powerful Heater, Whisper Quiet, Portable, Energy Saving, 50°F-90°F temperature range, and Easy to Use.



Figure 3.6: The compact and portable design of the heater, including its dimensions (11.6" L x 9.7" W x 12.1" H) and integrated handle for easy movement.



Figure 3.7: The ZOKOP heater providing comfortable warmth in a home setting, suitable for various indoor spaces.

4. Setup

The ZOKOP HT-1188 heater requires no assembly. Simply follow these steps for initial setup:

1. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 m) of clearance from any walls, furniture, or other combustible materials. Do not place the heater on soft surfaces like rugs or carpets that may block the air intake.
2. **Power Connection:** Plug the power cord directly into a 120V AC, 60Hz wall outlet. Do not use extension cords, power strips, or surge protectors.
3. **Remote Control Batteries:** If using the remote control, insert 2 AAA batteries (not included) into the remote.

5. Operating Instructions

The heater can be operated using the control panel on the unit or the included remote control.

Control Panel Buttons:

- **Power Button ( ):** Turns the heater ON or OFF.
- **Heater Mode Button (☀):** Cycles through heat settings: High (1500W), Low (750W), and ECO (maintains 68°F / 20°C).
- **Temperature Up/Down Buttons (▲ / ▼):** Adjusts the desired temperature between 50°F and 90°F (10°C and 32°C).
- **12H Timer Button ( ):** Sets the operating time from 0 to 12 hours. The heater will automatically turn off or on after the set time.
- **Child Safety Lock Button ( ):** Activates or deactivates the child safety lock to prevent accidental changes to settings.
- **Ambient Temp Button ( ):** Displays the current ambient room temperature.

Remote Control:

The remote control duplicates all functions available on the control panel for convenient operation from a distance.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your heater.

1. **Cleaning:**
    - Always unplug the heater from the power outlet and allow it to cool completely before cleaning.
    - Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use harsh chemicals or abrasive cleaners.
    - Gently vacuum the air intake and exhaust grilles to remove dust and lint.
    - Never immerse the heater in water or allow water to drip into the interior.
2. **Storage:**
    - When not in use, store the heater in a cool, dry location.
    - It is recommended to store the heater in its original packaging to protect it from dust and damage.

7. Troubleshooting

If your heater is not operating correctly, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in securely. Power outlet is not working. Overheat safety switch activated. Tip-over safety switch activated. Child safety lock is on.	Ensure the power cord is firmly plugged into a 120V AC outlet. Check the circuit breaker or try a different outlet. Unplug the heater, wait 10 minutes for it to cool down, then plug it back in. Ensure the heater is on a stable, flat surface. If it was tipped, stand it upright. Deactivate the child safety lock by pressing and holding the lock button.
Heater is not producing enough heat.	Heat setting is too low. Room size exceeds coverage area. Air intakes/exhausts are blocked.	Increase the heat setting to High (1500W). Ensure the heater is appropriate for the room size (up to 150 sq ft). Check for and remove any obstructions from the air grilles.
Heater makes unusual noise.	Dust or debris in the fan.	Unplug the heater and gently clean the fan area as per maintenance instructions.

8. Specifications

Attribute	Value

Attribute	Value
Brand	ZOKOP
Model Number	HT-1188
Heating Product Type	Space Heater / Infrared Heater
Heating Technology Type	Infrared Quartz
Power	750W / 1500W
Voltage	120V AC
Temperature Range	50~90°F / 10~32°C
Programmable Timer	0-12 hours
Heating Coverage	Approx. 150 square feet
Noise Level	≤59db
Certifications	ETL
Product Dimensions (L x W x H)	11.6" x 9.7" x 12" (29.4 x 24.7 x 30.7 cm)
Item Weight	8.2 lb / 3.72 Kg
Special Features	Remote Control, Overheat Protection, Tip-Over Protection, Child Safety Lock

9. Warranty and Support

This ZOKOP HT-1188 Electric Infrared Quartz Heater comes with a **1-Year Warranty** from the date of purchase.
For technical support, warranty claims, or any questions regarding your product, please contact ZOKOP customer service. Refer to the contact information provided on the product packaging or the official ZOKOP website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question