

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Arregui](#) /

› [ARREGUI 51300-S3B Electronic Safe User Manual](#)

Arregui 51300-S3B

ARREGUI 51300-S3B Electronic Safe User Manual

Model: 51300-S3B | Brand: Arregui

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your ARREGUI 51300-S3B Electronic Safe. Please read these instructions carefully before using the safe to ensure proper function and security.

2. SAFETY INFORMATION

- Do not store the emergency keys inside the safe. Keep them in a secure, separate location.
- Ensure the safe is securely mounted to prevent unauthorized removal.
- Replace batteries promptly when the low battery indicator appears to avoid being locked out.
- Keep the safe away from excessive moisture or extreme temperatures.
- Do not attempt to force the safe open if the electronic lock malfunctions. Use the emergency key.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- ARREGUI 51300-S3B Electronic Safe
- Emergency Keys (2)
- AA Batteries (4)
- Mounting Hardware (screws, anchors)
- User Manual (this document)

4. SETUP

4.1. Battery Installation

1. Open the safe door using the emergency key. Insert the key into the keyhole, turn it clockwise, and rotate the handle to open.
2. Locate the battery compartment on the inside of the safe door.

3. Insert the four AA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover.
5. Test the electronic lock by entering the default code (usually "1234" or "123456") and pressing "E" or "#". The display should show "OPEN" and the handle can be turned.



Figure 1: Front view of the ARREGUI 51300-S3B Electronic Safe, showing the keypad and display. This image illustrates the safe in a closed position, ready for use.

4.2. Mounting the Safe

For optimal security, it is recommended to securely mount the safe to a wall or floor.

1. Choose a suitable location, ensuring it is a solid surface capable of supporting the safe's weight.
2. Open the safe door and locate the pre-drilled mounting holes on the back or bottom panel.
3. Mark the drilling points on the wall or floor through the holes.
4. Drill pilot holes using an appropriate drill bit for your wall/floor material.
5. Align the safe with the drilled holes and secure it using the provided mounting hardware (screws and anchors).
6. Ensure the safe is firmly attached and does not wobble.



Figure 2: The ARREGUI 51300-S3B Electronic Safe with its door open, revealing the interior and the electronic keypad mechanism. This view helps in understanding the internal layout and battery compartment location.

5. OPERATING INSTRUCTIONS

5.1. Opening the Safe (User Code)

1. Enter your 4-6 digit user code on the keypad.
2. Press the "E" or "#" button.
3. If the code is correct, the display will show "OPEN". Within 5 seconds, turn the handle clockwise and pull the door open.
4. If the code is incorrect, the display will show "ERROR". Re-enter the code.

5.2. Closing the Safe

Close the door and turn the handle counter-clockwise until it is fully locked. The safe will automatically lock.

5.3. Setting/Changing the User Code

1. With the safe door open, press the red reset button located on the inside of the door (usually near the hinge). The display will show "PROG" or "SET".
2. Enter your new 4-6 digit user code.
3. Press the "E" or "#" button to confirm. The display will show "GOOD" or "SUCCESS".
4. Test the new code with the door open before closing it.

5.4. Using the Master Code (Hotel Function)

The safe includes a master code function, typically used by hotel management. This code can open the safe even if a user code is set. Consult your administrator for the master code if applicable.

1. Enter the master code on the keypad.
2. Press the "E" or "#" button.
3. If the code is correct, the display will show "OPEN". Turn the handle clockwise and pull the door open.

5.5. Using the Emergency Key

The emergency key provides manual access to the safe in case of battery failure or forgotten codes.

1. Locate the emergency keyhole, usually hidden behind a small cover on the keypad panel.
2. Remove the cover.
3. Insert the emergency key and turn it clockwise.
4. While holding the key turned, rotate the handle clockwise to open the safe door.
5. Once open, remove the key and replace the cover.

6. MAINTENANCE

- **Battery Replacement:** When the display shows "LOW BATT" or similar, replace all four AA batteries promptly. Use high-quality alkaline batteries.
- **Cleaning:** Wipe the safe's exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Door Hinges:** Periodically check the door hinges for smooth operation. Apply a small amount of lubricant if necessary.
- **Emergency Keys:** Store emergency keys in a secure location outside the safe. Do not duplicate them without authorization.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Safe does not open with user code.	Incorrect code entered; batteries are low or dead; keypad malfunction.	Re-enter code carefully. Replace batteries. Use emergency key to open.
Display shows "LOW BATT".	Batteries are running low.	Replace all four AA batteries immediately.
Safe beeps continuously after entering code.	Incorrect code entered multiple times.	Wait for 5 minutes for the system to reset, then try again with the correct code.
Door does not close properly.	Obstruction in the door frame; locking bolts misaligned.	Check for any obstructions. Gently push the door while turning the handle.

8. SPECIFICATIONS

Model	ARREGUI 51300-S3B
Exterior Dimensions (H x W x D)	20 cm x 41.8 cm x 38.1 cm (7.87 in x 16.46 in x 15 in)
Interior Dimensions (H x W x D)	19.6 cm x 41.4 cm x 32.6 cm (7.72 in x 16.30 in x 12.83 in)
Weight	10 kg (22 lbs)
Material	Alloy Steel
Lock Type	Electronic Combination, Emergency Key
Combination Digits	4-6 digits (1 million combinations)
Power Source	4 x AA Batteries (included)
Special Features	Master Function, Low Battery Indicator

9. WARRANTY AND SUPPORT

ARREGUI products are manufactured to high-quality standards. For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official ARREGUI website. Keep your purchase receipt as proof of purchase.

For further assistance, you may contact ARREGUI customer service:

Website: www.arregui.es

Email: support@arregui.es