

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ciglow](#) /
- › [Ciglow 500W Electric Mini Stove Instruction Manual](#)

## Ciglow YQ-105

# Ciglow 500W Electric Mini Stove Instruction Manual

MODEL: YQ-105

## INTRODUCTION

Thank you for choosing the Ciglow 500W Electric Mini Stove. This compact and versatile appliance is designed for convenient cooking in various settings. Please read this manual carefully before use to ensure safe and efficient operation.

### Key Features:

- **5.6-inch Mini Stove:** Powered by 120V (500W) for fast heating up to 570 degrees.
- **Cookware Compatibility:** Compatible with 6-inch to 10-inch cookware. For best results, use flat cookware close to 6 inches in diameter.
- **Versatile Use:** Small and portable, suitable for kitchens, properties, camping, travel, and dorms.
- **Easy to Clean:** Smooth electric heater surface can be easily wiped clean with a towel after cooling.
- **Adjustable Temperature:** Features 5 ranges to adjust the temperature for precise cooking control.

## SETUP

### Initial Use:

1. When using the stove for the first time, turn the switch to the fifth gear (maximum setting) and heat for 3-5 minutes.
2. A small amount of smoke may be exhausted during this initial heating. This is normal and caused by the evaporation of the protective film on the stove. It should largely disappear after continuous heating in the fifth gear for 10 minutes or more, repeated 2-3 times.

### Placement:

Ensure the surface where the stove is placed is flat and stable. If the bottom of the stove is not flat, concave, or convex, it cannot be used safely.

## OPERATING INSTRUCTIONS

---

### Temperature Adjustment:

Rotate the electric stove switch to operate. There are 5 ranges to adjust the temperature of the electric stove. Adjust the switch to the appropriate range to achieve the required temperature for your cooking needs.

### Switching Off:

When not in use, always turn the switch to the "0"/"off" position and unplug the power cord from the outlet.

## SAFETY PRECAUTIONS

---

- Do not leave the stove unattended while in use.
- Do not touch the stove while it is heating or immediately after use, as the heating plate and surrounding housing will be hot.
- Do not immerse the electric stove in water or other liquids.
- The electric stove is for cooking food; utensils should be placed on the heating plate when cooking.
- When the electric stove is not in use, ensure the switch is in the "0"/"off" position and unplug the power cord.

## MAINTENANCE

---

### Cleaning:

To clean the electric stove, ensure it is turned off, unplugged, and completely cooled down. Do not wash the unit directly under water. Simply wipe the smooth surface of the electric heater with a damp towel. Avoid using abrasive cleaners or scouring pads that could damage the surface.

## TROUBLESHOOTING

---

- **Smoke/Odor on First Use:** This is normal due to the protective film burning off. Continue heating on the highest setting for 10 minutes, repeating 2-3 times. Ensure adequate ventilation.
- **Unit Overheating/Hot Housing:** The housing around the heating plate will get warm during operation. Always handle with care and avoid touching hot surfaces. Ensure proper ventilation around the unit.
- **Slow Heating:** Ensure the stove is set to the appropriate temperature level for your cooking needs. Higher settings will heat faster. Ensure the cookware is flat-bottomed and makes good contact with the heating plate.
- **No "Click" for Off Position:** The temperature dial operates with a smooth twist rather than a distinct click for the off position. Always visually confirm the dial is set to "0"/"off" and unplug the unit when not in use to prevent accidental activation.
- **Short Power Cord:** The power cord is intentionally short for safety reasons to prevent tripping hazards. If a longer reach is required, use a suitable extension cord rated for the appliance's wattage (500W).

## SPECIFICATIONS

---

Specification	Detail
Brand	Ciglow
Model	YQ-105
Power	500W
Voltage	120V
Heating Plate Diameter	Approx. 107mm / 4.2 inches
Material	Stainless Steel, Cast Iron
Dimensions	5.51 x 5.71 x 2.56 inches
Item Weight	1.65 pounds (0.75 Kilograms)
Controls Type	Knob

## PRODUCT IMAGES



The Ciglow Mini Stove in a kitchen setting, demonstrating its compact size and ease of use with a pot.



A clear top-down view of the mini stove, highlighting its flat cast iron heating plate and control knob.



Side profile of the mini stove,

Heat fast, the surface temperature is high, up to 570 degrees, convenient to use. High surface temperature and low internal temperature, high thermal efficiency.

detailing the temperature control knob, power indicator light, and ventilation.



The underside of the mini stove, showing the non-slip rubber feet for stability and proper airflow.



Rear view of the appliance, illustrating the power cord connection point and product labeling.



An angled view of the mini stove, emphasizing the compact design and accessible temperature control knob.



A close-up shot of the side ventilation slots, crucial for heat dissipation during operation.

## VIDEO DEMONSTRATIONS

### Electric Mini Stove Overview

Your browser does not support the video tag.

This video provides a brief overview of the Electric Mini Stove, demonstrating its compact design and basic functionality. It shows

the unit being turned on and a pot placed on it, highlighting its readiness for use.

## **WARRANTY & SUPPORT**

---

For warranty information, technical support, or any product-related inquiries, please refer to the contact details provided in your product packaging or visit the official Ciglow website. Keep your purchase receipt for warranty claims.