

[Manuals.plus](#) /

› [Longines](#) /

› Longines Master Collection Moon Phase Chronograph Automatic Sunray Blue Dial Men's Watch L2.773.4.92.6 Instruction Manual

Longines L2.773.4.92.6

Longines Master Collection Moon Phase Chronograph Automatic Watch Instruction Manual

Model: L2.773.4.92.6

Brand: Longines

INTRODUCTION

This instruction manual provides essential information for the proper use, care, and maintenance of your Longines Master Collection Moon Phase Chronograph Automatic Watch, model L2.773.4.92.6. This timepiece features a sophisticated automatic movement, a sunray blue dial, and a silver-tone stainless steel case and band. Key functions include a moon phase display, chronograph, and date indication.



Image: The Longines Master Collection Moon Phase Chronograph Automatic Watch, model L2.773.4.92.6, showcasing its sunray blue dial, silver-tone stainless steel case, and matching bracelet. The dial features multiple subdials for chronograph functions, date, and moon phase display.

SETUP AND INITIAL WINDING

Your Longines automatic watch is powered by the motion of your wrist. Before wearing for the first time or after a period of inactivity, it is recommended to manually wind the watch.

1. **Manual Winding:** Unscrew the crown (if applicable) and turn it clockwise approximately 30-40 times in its neutral position (position 0) until you feel resistance. This will provide sufficient power reserve to start the movement.
2. **Setting the Time:** Pull the crown out to position 2 (farthest out). Rotate the crown to set the hour and minute hands. Ensure to distinguish between AM and PM when setting the date. Push the crown back to position 0.
3. **Setting the Date:** Pull the crown out to position 1 (first click). Rotate the crown to adjust the date. For watches with a quick-set date, this will advance the date independently. Avoid setting the date between 9 PM and 3 AM, as this is when the date change mechanism is engaged and could cause damage. Push the crown back to position 0.
4. **Setting the Moon Phase:** The moon phase display is typically set using a small pusher on the side of the case or by rotating the crown in a specific position. Consult the specific movement instructions for precise adjustment. Generally, you will need to know the current moon phase to set it accurately.

OPERATING INSTRUCTIONS

Using the Chronograph Function

The chronograph allows you to measure elapsed time independently of the main time display.

1. **Start:** Press the top pusher (usually at 2 o'clock) to start the chronograph. The central chronograph second hand will begin to move.
2. **Stop:** Press the top pusher again to stop the chronograph. The hands will hold their position, indicating the elapsed time.
3. **Reset:** After stopping, press the bottom pusher (usually at 4 o'clock) to reset all chronograph hands to their zero positions.
4. **Intermediate Times (Flyback):** Some chronographs allow for intermediate time measurement. Refer to specific movement details if this feature is present.

Understanding the Moon Phase Display

The moon phase display tracks the lunar cycle, showing the current phase of the moon (new moon, crescent, quarter, gibbous, full moon).

- The display typically features a rotating disc with two moon depictions.
- It advances automatically once set, but may require manual adjustment after periods of non-use or if the watch stops.

MAINTENANCE AND CARE

Proper care will ensure the longevity and accuracy of your Longines timepiece.

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For the stainless steel bracelet, a slightly damp cloth can be used, followed by drying.
- **Water Resistance:** This watch is water resistant to 30 meters (100 feet). This rating is suitable for splashes or brief immersion in water, but not for swimming, diving, or showering. Always ensure the crown is fully pushed in and screwed down (if applicable) before any contact with water.

- **Avoid Extreme Conditions:** Protect your watch from extreme temperatures (hot or cold), sudden temperature changes, strong magnetic fields, and impacts.
- **Servicing:** An automatic watch should be serviced by an authorized Longines service center every 3-5 years to ensure optimal performance and water resistance.

TROUBLESHOOTING

If you encounter issues with your watch, consider the following common solutions:

- **Watch Not Running:** Ensure the watch is sufficiently wound. If it's an automatic watch, wear it regularly or manually wind it as described in the "Setup" section.
- **Incorrect Time/Date:** Re-set the time and date according to the "Setup" instructions. Ensure the crown is fully pushed in after setting.
- **Chronograph Not Resetting to Zero:** If the chronograph hands do not return precisely to zero, a minor adjustment may be needed. This typically requires professional service.
- **Water Inside Crystal:** If condensation or water appears inside the watch crystal, immediately take it to an authorized service center.

For persistent issues or complex repairs, always contact an authorized Longines service center.

SPECIFICATIONS

Feature	Detail
Brand	Longines
Model Number	L2.773.4.92.6
Movement	Automatic
Dial Color	Sunray Blue
Case Material	Silver-tone Stainless Steel
Band Material	Silver-tone Stainless Steel
Crystal	Scratch Resistant Sapphire
Water Resistance	30 meters / 100 feet
Case Size	42 mm x 14.5 mm
Clasp Type	Fold Over with Push Button Release
Country of Origin	Switzerland

WARRANTY AND SUPPORT

Your Longines watch is covered by a manufacturer's warranty against defects in materials and workmanship. The duration and terms of the warranty are typically provided with your purchase documentation. Please retain your proof of purchase for warranty claims.

For warranty service, repairs, or technical support, please contact an authorized Longines service center or the retailer from whom you purchased the watch. Using unauthorized service providers may void your warranty.

For more information, visit the official Longines website or consult the warranty card included with your watch.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question