

EGO Power+ BBA2100

EGO Power+ BBA2100 Bristle Brush Attachment Instruction Manual

For EGO 56-Volt Lithium-ion Multi-Head System

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your EGO Power+ BBA2100 Bristle Brush Attachment. Designed for the EGO Multi-Head System, this attachment efficiently cleans various surfaces. Please read this manual thoroughly before operation and retain it for future reference.

Key Features:

- 22-inch sweeping surface for efficient debris removal.
- Durable nylon bristles for optimal performance and longevity.
- Detachable guard to prevent debris buildup.
- Tool-free attachment for quick and easy connection and storage.
- 10-inch diameter brush.

SAFETY INFORMATION

Always prioritize safety when operating power tools. Failure to follow these instructions may result in serious injury.

- **Read All Instructions:** Familiarize yourself with the power head and attachment manuals before use.
- **Wear Eye Protection:** Always wear safety glasses or goggles that comply with applicable standards.
- **Keep Bystanders Away:** Ensure children, pets, and other people are at a safe distance from the operating area.
- **Secure Attachment:** Always ensure the bristle brush attachment is securely fastened to the power head before starting.
- **Disconnect Power:** Remove the battery from the power head before making any adjustments, changing accessories, or performing maintenance.
- **Inspect Before Use:** Check the attachment for any damaged or loose parts before each operation.

PACKAGE CONTENTS

Verify that all items are present upon unpacking:

- EGO Power+ BBA2100 Bristle Brush Attachment
- Detachable Guard

SETUP

Follow these steps to attach the bristle brush to your EGO Multi-Head System Power Head:

1. Ensure the EGO Multi-Head System Power Head (PH1400, PH1420) is powered off and the battery is removed.
2. Align the shaft of the Bristle Brush Attachment with the coupling on the power head.
3. Push the attachment shaft into the coupling until it clicks into place.
4. Secure the attachment by tightening the coupling knob.
5. Verify the attachment is firmly seated before use by gently pulling on it.




Figure 1: Attaching the Bristle Brush to the Power Head.

The EGO Power+ BBA2100 Bristle Brush Attachment is compatible with EGO POWER+ Multi-Head System Power Heads (PH1400, PH1420), which are available separately.



Figure 2: EGO Multi-Head System with various attachments.

OPERATING INSTRUCTIONS

Once the bristle brush attachment is securely installed, follow these guidelines for effective operation:

Using the Bristle Brush Attachment:

1. Ensure the attachment is securely fastened to the power head.
2. Insert a fully charged EGO 56-Volt ARC Lithium battery into the power head.
3. Hold the power head firmly with both hands, maintaining a balanced stance.
4. Start the power head according to its specific instructions.
5. Guide the bristle brush over the surface to be cleaned, maintaining a steady pace. The 22-inch sweeping surface is designed for efficient coverage.
6. The attachment is ideal for clearing dust, dirt, leaves, light snow, and small rocks from hard surfaces like patios, decks, and driveways, as well as artificial turf.
7. The detachable guard helps prevent debris from being thrown back towards the operator during operation.



Figure 3: The 22-inch cleaning swath for efficient debris removal.



Figure 4: Durable nylon bristles for effective cleaning.

Tips for Effective Use:

- For optimal results, use the brush on dry surfaces when clearing light debris.
- When clearing snow, work in manageable sections and avoid attempting to clear heavy, wet snow that may overload the brush.
- Adjust your speed and angle of approach based on the type and amount of debris.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your bristle brush attachment.

- **Battery Removal:** Always remove the battery from the power head before performing any maintenance, cleaning, or storage.
- **Clean Bristles:** Regularly clean the bristles to remove accumulated dirt, leaves, and other debris. This prevents clogging and maintains cleaning efficiency.
- **Inspect for Wear:** Periodically inspect the nylon bristles for signs of excessive wear or damage. Replace the attachment if bristles are severely worn or broken to ensure effective cleaning and prevent damage to surfaces.
- **Clean Detachable Guard:** Ensure the detachable guard is clean and free from obstructions. This

helps maintain proper debris deflection.

- **Storage:** Store the bristle brush attachment in a clean, dry place, away from direct sunlight and extreme temperatures. Detaching it from the power head allows for more convenient storage.

TROUBLESHOOTING

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
Attachment does not spin.	Battery not charged or improperly inserted. Attachment not securely connected.	Ensure battery is fully charged and properly inserted. Verify attachment is securely connected to the power head and the coupling knob is tight.
Reduced cleaning performance.	Bristles worn or clogged with debris.	Check bristles for excessive wear or damage; replace if necessary. Clean bristles of tangled debris.
Excessive vibration during operation.	Attachment improperly installed or damaged.	Ensure attachment is correctly installed and all fasteners are tight. Inspect for any damage to the attachment or power head.

SPECIFICATIONS

Feature	Detail
Brand	EGO Power+
Model	BBA2100
Sweeping Surface	22 inches
Bristle Material	Durable Nylon
Brush Diameter	10 inches
Item Weight	17.36 pounds (7.89 Kilograms)
Product Dimensions	40.1 x 22.2 x 11.6 inches
Compatible Power Heads	EGO POWER+ Multi-Head System Power Heads (PH1400, PH1420)

WARRANTY INFORMATION

The EGO Power+ BBA2100 Bristle Brush Attachment comes with a **5-year tool warranty**. This warranty covers defects in material or workmanship from the date of original retail purchase. Please retain your proof of purchase for warranty claims. For full terms and conditions, including exclusions and limitations, refer to the official EGO Power+ warranty documentation or visit their website.



Figure 5: EGO Power+ 5-Year Tool Warranty.

SUPPORT

For further assistance, product registration, or to locate authorized service centers, please visit the official EGO Power+ website or contact their customer support. Contact details can typically be found on the product packaging or the official brand website.