

Manuals.plus /

› HORI /

› Hori Nintendo Switch Mario Kart Racing Wheel Pro Mini By - Officially Licensed By Nintendo

HORI NSW-204U

Hori Nintendo Switch Mario Kart Racing Wheel Pro Mini User Manual

Model: NSW-204U | Brand: HORI

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Hori Nintendo Switch Mario Kart Racing Wheel Pro Mini. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.

The Hori Nintendo Switch Mario Kart Racing Wheel Pro Mini is an officially licensed racing wheel designed for use with the Nintendo Switch console, specifically optimized for Mario Kart and other racing titles. It features an ergonomic wheel design, integrated pedals, and convenient onboard controls to enhance your racing simulation experience.

2. WHAT'S INCLUDED

Upon opening the package, please verify that all components are present and undamaged:

- Hori Nintendo Switch Mario Kart Racing Wheel Pro Mini (Main Unit)
- Pedal Unit
- Instruction Manual (this document)



Image: The Hori Nintendo Switch Mario Kart Racing Wheel Pro Mini, shown with its accompanying pedal unit. The wheel is red and blue with Mario branding, and the pedal unit is also red with black pedals.

3. SETUP INSTRUCTIONS

Follow these steps to set up your racing wheel:

1. **Connect the Pedal Unit:** Insert the pedal unit cable into the designated port on the back of the racing wheel. Ensure the connection is secure.
2. **Secure the Racing Wheel:** Place the racing wheel on a flat, stable surface. The wheel features suction cups or clamps (depending on model, refer to physical product) for secure attachment. Ensure it is firmly in place to prevent movement during gameplay.
3. **Connect to Nintendo Switch Dock:** Plug the USB cable from the racing wheel into an available USB port on your Nintendo Switch Dock.
4. **Power On:** Ensure your Nintendo Switch console is powered on and docked. The racing wheel should be automatically recognized.
5. **Controller Settings:** Navigate to the "Controllers" menu on your Nintendo Switch. Ensure "Pro Controller

Wired Communication" is enabled.



Image: Front view of the Hori Mario Kart Racing Wheel Pro Mini, showcasing its red wheel, blue base, and central Mario 'M' logo. The various buttons and paddle shifters are visible.



Image: The red pedal unit for the Hori Mario Kart Racing Wheel Pro Mini, featuring two black pedals for acceleration and braking.

4. OPERATING INSTRUCTIONS

The Hori Mario Kart Racing Wheel Pro Mini is designed for intuitive control in racing games.

4.1 Basic Controls

- **Steering:** Rotate the wheel left or right to steer your vehicle.
- **Acceleration:** Press the right pedal (accelerator) to increase speed.
- **Braking/Reverse:** Press the left pedal (brake) to slow down or reverse.
- **Paddle Shifters:** Use the left (LSB) and right (RSB) paddle shifters located behind the wheel for gear changes or item usage, depending on game configuration.



Image: Side view of the Hori Racing Wheel Pro Mini, highlighting the ergonomic design and the paddle shifter located behind the wheel.



Image: A close-up view of the central button cluster on the Hori Racing Wheel Pro Mini, showing the D-pad, A/B/X/Y buttons, ZL/ZR triggers, and other function buttons.

4.2 Button Functions

The racing wheel replicates standard Nintendo Switch controller buttons:

Button	Function (Typical)
D-Pad	Navigation, item selection
A, B, X, Y	Action buttons (e.g., accelerate, use item, drift)
ZL, ZR	Triggers (e.g., brake, item use)
LSB, RSB (Paddles)	Left and Right Shoulder Buttons (e.g., item use, drift)
+, -	Start/Pause, Menu access
HOME	Return to Nintendo Switch HOME Menu
ASSIGN	Button assignment function (refer to advanced settings)

4.3 Advanced Features (Button Assignment)

The ASSIGN button allows you to remap certain button functions for personalized control. Refer to the detailed instructions provided with the physical product for specific button assignment procedures.

5. COMPATIBLE GAMES

The Hori Nintendo Switch Mario Kart Racing Wheel Pro Mini is compatible with a wide range of racing titles on the Nintendo Switch. It is officially licensed for Nintendo Switch and optimized for Mario Kart.



Image: A list of compatible games for the Hori Racing Wheel Pro Mini, including Mario Kart 8 DLX, Sonic Racing, Crash Team

Racing, Asphalt 9: Legends, and various other Nintendo Switch and PC racing titles.

For the most up-to-date list of compatible games and PC software information, please visit the official HORI website: <https://stores.horiusa.com/mario-kart-racing-wheel-pro-mini-and-racing-wheel-pro-deluxe-software-compatibility/>

6. MAINTENANCE

Proper care will ensure the longevity of your racing wheel:

- **Cleaning:** Use a soft, dry cloth to wipe down the racing wheel and pedal unit. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharply bending or pulling the cables. Always grasp the plug when disconnecting.
- **Avoid Liquids:** Do not expose the device to water or other liquids.

7. TROUBLESHOOTING

If you encounter issues with your racing wheel, try the following solutions:

- **Wheel not responding:**
 - Ensure all cables are securely connected to the racing wheel, pedal unit, and Nintendo Switch Dock.
 - Verify that "Pro Controller Wired Communication" is enabled in the Nintendo Switch system settings.
 - Try connecting the racing wheel to a different USB port on the dock.
 - Restart your Nintendo Switch console.
- **Pedals not working:**
 - Check the connection between the pedal unit and the racing wheel.
 - Ensure the game you are playing supports pedal input.
- **Buttons not functioning correctly:**
 - Check in-game controller settings to ensure buttons are mapped as expected.
 - If you have used the ASSIGN function, try resetting button assignments to default (refer to the full manual for specific steps).

If the problem persists after attempting these solutions, please contact HORI customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Product Name	Hori Nintendo Switch Mario Kart Racing Wheel Pro Mini
Model Number	NSW-204U
Brand	HORI
Compatibility	Nintendo Switch
Dimensions (Wheel Unit)	Approximately 8.86 x 10.83 x 8.86 inches
Weight	Approximately 3.3 Pounds (Total)
Connection	USB Wired
Release Date	November 12, 2019
Manufacturer	Hori

9. WARRANTY AND SUPPORT

HORI products are designed for durability and performance. For information regarding warranty coverage, technical support, or replacement parts, please refer to the warranty card included with your product or visit the official HORI website.

HORI Official Website: <https://stores.horiusa.com/>

Please retain your proof of purchase for warranty claims.