

[Manuals.plus](#) /

> [Google](#) /

> Google Pixel 4 XL 64GB Unlocked Smartphone User Manual

Google Pixel 4 XL

Google Pixel 4 XL 64GB Unlocked Smartphone User Manual

Model: Pixel 4 XL

1. INTRODUCTION

Welcome to the user manual for your Google Pixel 4 XL smartphone. This guide provides essential information to help you get started, understand its features, and maintain your device. The Google Pixel 4 XL is designed to offer a seamless Android experience with advanced camera capabilities, intuitive gesture controls, and the integrated Google Assistant.





Figure 1.1: Google Pixel 4 XL (Oh So Orange)

2. SETUP

2.1 What's in the Box

- Google Pixel 4 XL Smartphone
- AC Adapter
- USB Cable (USB-C to USB-C)
- OTG Dongle (USB-A to USB-C adapter)
- SIM Tray Ejector Tool
- Quick Start Guide

2.2 Inserting the SIM Card

1. Locate the SIM card tray on the side of your Pixel 4 XL.
2. Insert the SIM tray ejector tool into the small hole next to the tray and press firmly until the tray pops out.

3. Place your Nano SIM card into the tray with the gold contacts facing down. Ensure it fits securely.
4. Carefully push the SIM tray back into the phone until it clicks into place.






Figure 2.1: SIM Card Tray Location

2.3 Initial Power On and Setup

1. Press and hold the Power button (located on the right side) until the Google logo appears.
2. Follow the on-screen instructions to select your language, connect to Wi-Fi, and transfer data from an old device if desired.
3. Sign in with your Google Account or create a new one.
4. Set up security features such as Face Unlock.

2.4 Charging the Device

Connect the USB cable to the AC adapter and plug it into a power outlet. Connect the other end of the USB cable to the USB-C port at the bottom of your Pixel 4 XL. The device supports fast charging. For optimal battery health, avoid fully discharging the battery frequently.

3. OPERATING INSTRUCTIONS

3.1 Basic Navigation

The Pixel 4 XL uses a touchscreen interface for navigation. Swipe up from the bottom to go to the home screen, swipe from the left or right edge to go back, and swipe up and hold to view recent apps.





Figure 3.1: Pixel 4 XL Front Display

3.2 Google Assistant

The new Google Assistant is integrated into the Pixel 4 XL. You can activate it by squeezing the sides of your phone or by saying "Hey Google." Use your voice to send texts, share photos, get directions, and more.

3.3 Camera Features

The Pixel 4 XL camera offers advanced photography capabilities:

- **Point and Shoot:** Capture brilliant color and control exposure balance.
- **Night Sight:** Take clear photos in low-light conditions, including astrophotography for capturing the Milky Way.



Figure 3.2: Using the Pixel 4 XL Camera

3.4 Motion Sense (Quick Gestures)

Utilize Quick Gestures to control your phone without touching it. Wave your hand above the screen to skip songs, silence calls, and more. Motion Sense functionality is available in specific regions including the US, Canada, Singapore, Australia, Taiwan, and most European countries.



Figure 3.3: Motion Sense in Action

3.5 Call Screen

The Google Assistant's Call Screen feature helps filter out spam calls. It can proactively screen unknown callers and provide a transcript of the conversation, allowing you to decide whether to answer.

3.6 Official Product Video

Your browser does not support the video tag.

Video 3.1: An official video from Google Inc showcasing the features of the Google Pixel 4, including Google Assistant and Motion Sense. This video provides a visual overview of key functionalities.

4. MAINTENANCE

4.1 Cleaning Your Device

To clean your Pixel 4 XL, use a soft, lint-free cloth. Avoid abrasive materials, solvents, or aerosol sprays. For stubborn marks, slightly dampen the cloth with water. Do not submerge the device in water.

4.2 Software Updates

Google regularly releases software updates to improve performance, add features, and enhance security. Ensure your

device is connected to Wi-Fi and has sufficient battery life before installing updates. You can check for updates in Settings > System > System update.

4.3 Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Use the provided charger or a compatible Qi-certified wireless charger.
- Enable Adaptive Battery in settings to optimize app usage.
- Disable features like Motion Sense and Always-on Display if not actively needed to conserve power.

4.4 Data Backup

Regularly back up your data to your Google Account. This includes photos, videos, contacts, and app data. Go to Settings > System > Backup to manage your backup settings.

5. TROUBLESHOOTING

5.1 Common Issues and Solutions

- **Device not responding:** Press and hold the Power button for about 30 seconds to force a restart.
- **Apps crashing:** Clear the cache and data for the problematic app in Settings > Apps & notifications > See all apps > [App Name] > Storage & cache.
- **Connectivity problems (Wi-Fi/Bluetooth):** Try toggling Wi-Fi or Bluetooth off and on. If the issue persists, reset network settings in Settings > System > Reset options > Reset Wi-Fi, mobile & Bluetooth.
- **Poor battery life:** Review battery usage in Settings > Battery to identify apps consuming excessive power. Adjust screen brightness and disable unnecessary features.

5.2 Factory Reset

A factory reset will erase all data from your phone and restore it to its original factory settings. This can resolve persistent software issues. **Warning: Back up all important data before proceeding.**

1. Go to Settings > System > Reset options.
2. Tap "Erase all data (factory reset)".
3. Confirm your decision and follow the on-screen prompts.

6. SPECIFICATIONS

Key technical specifications for the Google Pixel 4 XL:

Feature	Specification
Brand	Google
Model Name	Pixel 4 XL
Operating System	Android
Memory Storage Capacity	64 GB
RAM Memory Installed Size	6 GB

Feature	Specification
Screen Size	6.3 Inches
Resolution	1440 x 2960
Refresh Rate	120 Hz
CPU Model	Snapdragon S3
CPU Speed	2.84 GHz
Color	Oh So Orange
SIM Card Slot Count	Single SIM
Connector Type	USB Type C
Biometric Security Feature	Face Recognition
Water Resistance Level	Water Resistant
Headphones Jack	No headphone jack
Front Photo Sensor Resolution	8 MP
Video Capture Resolution	4k (30fps)
Display Type	OLED
Wireless Provider	Unlocked
Battery Average Life	12 Hours

7. WARRANTY INFORMATION

Your Google Pixel 4 XL comes with a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by accidents, misuse, unauthorized repairs, or normal wear and tear.

For detailed terms and conditions, please refer to the warranty card included with your product or visit the official Google support website.

8. SUPPORT

If you require further assistance or encounter issues not covered in this manual, please utilize the following resources:

- **Online Help:** Visit the official Google Pixel Help Center for comprehensive articles, FAQs, and troubleshooting guides.
- **Community Forums:** Engage with other Pixel users and experts in Google's official product forums.
- **Contact Support:** Access direct support options (chat, phone, email) through the Google Pixel Help Center.

Always ensure you are referring to official Google support channels for accurate and up-to-date information.