

Foho DY002

Foho Vacuum Stand DY002 Instruction Manual

For Dyson V11, V10, V8, V7, V6, DC30, DC31, DC34, DC35, DC58, DC59, DC62, DC74 Cordless Vacuum Cleaners

1. INTRODUCTION

Thank you for choosing the Foho Vacuum Stand, model DY002. This freestanding metal storage bracket is designed to provide a stable and organized solution for your Dyson cordless vacuum cleaner and its accessories. It eliminates the need for wall drilling, offering a convenient and space-saving storage option.

Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation.

2. SAFETY INFORMATION

- Ensure all screws are tightened securely during assembly to prevent instability.
- Place the stand on a flat, stable surface to avoid tipping.
- Do not overload the stand beyond its recommended capacity of 6 pounds (2.8 kilograms).
- Keep children and pets away from the stand during assembly and ensure it is placed in a safe location to prevent accidental knocks.
- The charging docking station, vacuum cleaner, and accessories are not included with this stand.

3. PACKAGE CONTENTS

Verify that all components listed below are present in your package:

- 1 x Hexagon Wrench
- 1 x Upper Holder
- 1 x Lower Holder
- 1 x Base
- 1 x Wrench
- 4 x 3M Stick (for base)

- 9 x Short Screw
- 3 x Long Screw
- 2 x Nut

4. ASSEMBLY INSTRUCTIONS

Assembly is straightforward and requires no special tools beyond those provided. Please follow these steps carefully:

1. **Attach Middle and Upper Holders:** Use the provided short screws and Allen wrench to connect the middle and upper holder sections. Ensure the upper holder is correctly oriented to receive the Dyson docking station.
2. **Attach Middle and Base:** Connect the assembled middle section to the base using the remaining short screws and Allen wrench.
3. **Apply 3M Stickers:** Affix the four 3M stickers to the bottom of the base to prevent slipping and protect floor surfaces.
4. **Install Dyson Charging Station:** Before attaching the charging station, ensure the power cord is routed through it. Use the long screws and nuts with the wrench to secure your Dyson charging station to the upper holder.
5. **Final Check:** Verify all screws are tightened. The installation is now complete.

Installation Guide



Image: Detailed installation guide for the Foho Vacuum Stand, showing parts and assembly steps.



Image: Step-by-step visual instructions for assembling the Foho Vacuum Stand.

Note: Bending the cleaner's brush at a 45-degree angle can facilitate optimal installation and fit for some vacuum models.

5. COMPATIBILITY

The Foho Vacuum Stand (Model DY002) is compatible with the following Dyson handheld cordless vacuum cleaner models:


- Dyson V15
- Dyson V11
- Dyson V10
- Dyson V8
- Dyson V7
- Dyson V6
- Dyson DC30
- Dyson DC31
- Dyson DC34
- Dyson DC35
- Dyson DC58
- Dyson DC59
- Dyson DC62
- Dyson DC74

6. OPERATION

Once assembled, the Foho Vacuum Stand provides a dedicated space for your vacuum and its

attachments.

- **Placing the Vacuum:** Gently slide your Dyson cordless vacuum cleaner onto the charging docking station mounted on the upper holder. Ensure it is securely seated and making proper contact for charging (if connected to power).
- **Organizing Accessories:** Utilize the multiple hooks and slots along the stand's frame to store various Dyson accessories and attachments. This keeps them organized and readily accessible.



Hold 8+ Accessories




Image: Diagram illustrating how various Dyson vacuum components and accessories are stored on the Foho Vacuum Stand.

7. MAINTENANCE

To maintain the appearance and functionality of your Foho Vacuum Stand:

- Wipe the metal surfaces with a soft, damp cloth to remove dust and dirt.
- Avoid using abrasive cleaners or solvents, as these may damage the finish.
- Periodically check all screws and connections to ensure they remain tight.

8. TROUBLESHOOTING

- **Stand feels wobbly:**
 - Ensure all screws connecting the base, middle, and upper holders are fully tightened.
 - Verify the stand is placed on a completely flat and level surface.
 - Check that the Dyson charging station is securely attached to the upper holder with the long screws and nuts.
- **Accessories do not fit easily:**

- Some accessory holders may have a snug fit. Gently insert accessories.
- Ensure you are using the correct accessory for the designated slot.

9. SPECIFICATIONS

Model Number	DY002
Material	Metal (Iron)
Color	Black
Product Dimensions (L x W x H)	10.8 x 8.8 x 50 inches (27.4 x 22.4 x 127 cm)
Item Weight	6 pounds (2.72 kg)
Load Capacity	6 pounds (2.8 kg)
Assembly Required	Yes
Special Feature	Freestanding, Handheld, Stick Vacuum Support

10. WARRANTY INFORMATION

The Foho Vacuum Stand (Model DY002) comes with a 1-year manufacturer's warranty. Please retain your proof of purchase for warranty claims. For details regarding warranty coverage and claims, refer to the documentation provided at the time of purchase or contact customer support.

11. CUSTOMER SUPPORT

For any questions, assistance, or to report issues with your Foho Vacuum Stand, please contact our customer support team. Contact information can typically be found on the product packaging or the retailer's website where the product was purchased.